


75.00 mm

75.00 mm

Portable Label Printer



User's Guide


U.S.

Please read carefully before using, and keep it in a safe place for easy reference after delivery.

Statement


Without prior notice, we have the right to modify the contents of this manual. Our company will not be responsible for any consequences caused by your failure to operate according to the instructions. Our company is not responsible for any property loss and personal injury caused by the user's wrong operation or unreasonable modification of this product. Without the prior express permission of our company, it is forbidden for any other individual, legal person or unincorporated organization to copy this manual or part of its content in any form.

What's in the box



Label printer (1 set)
Label (1 roll)
USB data cable

Exterior description



Front
Cover opening part
Power key/Function key
Feeding key/Setting key
Label due
Display
Rear
Root key
USB cable port

How to use it

Attention

Please make sure that the printer is with power before using it for the first time. It needs to be fully charged when using it again after closing for a long time, so that the battery can achieve the best performance.

Charging battery

The charger is connected to the Type-C port of the printer. The charger voltage: 5V/2A.
Please purchase and use the adapter with certification that meets the charging standard if you need to charge with it.

Installation of label

The size of label for this printer is 52mm (max diameter), 20-52mm (width).
Attention

- Please make sure that the label you are using is suitable for this printer.
- Install the label correctly by according to the picture, and put the stop on the right side of the label display area (using the picture as a reference).
- Adjust the adjuster on the left side of the label to the right easily.
- Close the label cover after installing labels.

Basic functions

Turn on

Press and hold power button for 3 seconds to turn on the printer.

Power off

Press and hold power button for 3 seconds to turn a file printer.


Feed label

Press feeding button to set the label in proper position.

Shutdown mode

The printer will automatically shut down when it is in the waiting state for 5 minutes.
Automatic shutdown without connection and operation timeout. The printer with the version of display can modify the shutdown mode by user's need.

Desktop Mode Instructions for Display Version



Bluetooth communication

The sign will show after bluetooth connected successfully.

Out of label

The sign indicates the status of out of label. The sign will show the situation of out of label or wrong installation of label.

External power supply indicator

The sign will show the external power supply started.

Battery level

The sign flashes while charging. Please charge it all battery in time.

Text area

This area shows some text information.

Basic Settings of Display Version

The user's setting interface will show when the printer turns on.

Self-test printing	Self-test printing	Print	to print a self-test page.
Label type	Label type	Print	to set label type.
Automatic calibration	Automatic calibration	Print	to calibrate automatically. (not available when the printer is not connected to a computer.)
Language	Language	Print	to set the language of the printer.
Auto power off	Auto power off	Print	to set timeout time to turn off the printer.
Factory settings	Factory settings	Print	to restore factory settings.
MAC Address	MAC Address	Print	to show the MAC address of the printer.
Printer version	Printer version	Print	to show the printer version of the printer.
Print	Print	Print	to print a self-test page.
Print	Print	Print	to print a self-test page.

Basic Settings for LED Version

LED indicator description

Charging: "Red light" is on.

Fully charged: "Red light" is a flash automatically.

Failure mode: "Red light" flashes (low battery) Label stuck (Label out).

Connecting mode: "Blue light" is on.

Operation mode: "Blue light" is on.

Power on mode: "Purple light" is on.

Upgrade mode: "Red light" and "Blue light" flash alternately.

Timing mode: The printer will be timed to flash automatically after 3min (without connectors or operators) or 10min (without data transfer).

Self-test: Press and hold to print out the self-test page.

Calibrate label: Double press to calibrate label automatically.

Software download

APP download, PC editing software download

Download APP

Download APP from the QR code of the help to download the APP within the mobile phone. For the ease of use, you can use a smartphone equipped with NFC and print out automatically after it is downloaded and installed successfully.

The APP can be operated automatically if smartphone equipped with NFC function close to the NFC-equipped printer.

PC editing software

Please visit www.lsqsoft.com to download PC editing software. Download steps: Service and Support—Download Center—PC Editing software.

Maintenance and repair

Maintenance instruction

1. Cleaning the outside of the printer and the label slot: Please gently wipe the surface of the printer and the inside of the label slot with a non-solvent fabric.

2. Wipe cleaning the print head: Please clean it occasionally which will help keep foreign matter from getting inside the printer.

You can easily clean it using the following methods:

1. Identify the label part of the print head at the rear of the printer.

2. Push the label part of the print head out with a non-solvent fabric.

3. Please turn off the printer and let it dry naturally water is inside the printer.

4. If the printer can't be used for a long time, please charge the battery regularly and store it if the printer can't be used for a long time.

Maintenance and repair

Usage and stor age of printer consumables

1. The printer should be stored at room temperature.

2. Please clean the surface of printed item, when sticking the printer consumables.

Consumable	Replace cause	Replace method
Thermal transfer ribbon	When the printer prints without label, the ribbon is used up.	

| Label | When the printer prints without label, the ribbon is used up. |

| Label | When the printer prints without label, the ribbon is used up. |

Specifications

Printing method	Thermal printing
Input	Label
Output mode	Black and white
Printing resolution	300dpi
Max width	52mm
Max diameter	52mm
Printing speed	30mm/s
Sampling time	100 dots
Connectivity mode	USB, Bluetooth, NFC
Printing resolution	300dpi
Printing accuracy	±0.05mm
Printing format	PDF, JPEG, PNG, BMP, TIF, EPS and other types (not available)
Barcode printing	1D, 2D Barcode
Connection mode	PC, USB, Bluetooth, Android, iOS

Specifications

Battery	Li-ion
Capacity	1000mAh
Voltage	3.7V
Charging time	2 hours
Consumables	Label type: Continuous/Discontinuous/Black mark
Type	Continuous/Discontinuous/Black mark
Form	Max 52mm (52mm width/continuous)
Specification	80g
Thickness	0.05mm~0.15mm

Other preparations

Label printer installation and handling

1. Please read the manual before using the printer.

2. Please read the manual before using the printer.

3. Please read the manual before using the printer.

4. Please read the manual before using the printer.

5. Please read the manual before using the printer.

6. Please read the manual before using the printer.

7. Please read the manual before using the printer.

8. Please read the manual before using the printer.

9. Please read the manual before using the printer.

10. Please read the manual before using the printer.

Warranty Card

Warranty Policy

1. Please read the manual before using the printer.

2. Please read the manual before using the printer.

3. Please read the manual before using the printer.

4. Please read the manual before using the printer.

5. Please read the manual before using the printer.

6. Please read the manual before using the printer.

7. Please read the manual before using the printer.

8. Please read the manual before using the printer.

9. Please read the manual before using the printer.

10. Please read the manual before using the printer.

Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

文件编号				设计文件编号及文件版本 V1.2			
文件名称	物料编号	版本号	日期	文件名称	物料编号	版本号	日期
Q201, Q21&PT26-S中文说明书	4.32.PT26-S-02	V1.5	2024/04/29	Q201, Q21&PT26-S中文说明书	4.32.PT26-S-02	V1.5	2024/04/29
设计	审核	批准	日期	设计	审核	批准	日期
尺寸 成品尺寸:75x75mm 展开尺寸:600x75mm	工艺 风琴折7折页	材质 80克双胶纸	色号	尺寸 成品尺寸:75x75mm 展开尺寸:600x75mm	工艺 风琴折7折页	材质 80克双胶纸	色号
公差范围	彩盒包装±1mm	中包装箱±2mm	外包装箱±3mm, ~0mm	公差范围	彩盒包装±1mm	中包装箱±2mm	外包装箱±3mm, ~0mm