



SENNHEISER


RS 120-W

Model: RS 120-W
TR 120-W
HDR 120-W


EN Quick Guide
DE Kurzanleitung
FR Guide rapide
ES Instrucciones resumidas
PT Guia rápidos
NL Beknopte handleiding
IT Guida rapida
DA Kort vejledning
SV Snabbguide

Sennheiser Consumer Audio GmbH
Am Labor 1, 30900 Wedemark, Germany
www.sennheiser-hearing.com


Publ. 04/22, 595569/A01




Package includes | Lieferumfang | Contenu | Contenido del paquete | O pacote inclui | De levering omvat | Il pacchetto include | Leveringsomfang | Medföljande delar | Toimitussisältö




1 Connecting the transmitter to an audio source | Sender an Audioquelle anschließen | Raccorder l'émetteur à une source audio | Conectar el transmisor a la fuente de audio | Ligar o emissor à fonte áudio | Zender op de geluidsbron aansluiten | Collegare il trasmettitore alla sorgente audio | Tilslutning af sender til lydkilde | Ansluta sändaren till ljudkällan




2 Connecting the transmitter to the power supply system | Sender an das Stromnetz anschließen | Raccorder l'émetteur au secteur | Conectar el transmisor a la red eléctrica | Ligar o emissor à rede elétrica | De zender op de voedingsspanning aansluiten | Collegamento del trasmettitore alla rete elettrica | Tilslutning af senderen til strømnettet | Ansluta sändaren till elnätet




3 Inserting or replacing the rechargeable batteries | Akkus einsetzen oder auswechseln | Insérer ou remplacer les batteries | Colocar o cambiar las pilas recargables | Colocar ou substituir as pilhas recarregáveis | Accu's plaatsen of vervangen | Inserire o sostituire le batterie ricaricabili | Isætning og udskiftning af batterier




4 Charging the headphones | Kopfhörer laden | Charger le casque | Cargar los auriculares | Carregar os auscultadores | Koptelefoons laden | Ricaricare le cuffie | Opladning af hovedtelefoner | Ladda hörlurarna




Switching on/off | Ein-/ausschalten | Allumer/éteindre | Encender/apagar | Ligar/desligar | In-/uitschakelen | Accendere/spegnere | Tænd/sluk | Sätta på/stänga av




Pairing additional headphones with the transmitter | Weitere Kopfhörer mit dem Sender koppeln | Appairer des casques supplémentaire avec l'émetteur | Sincronizar otros auriculares con el transmisor | Emparelhar auscultadores adicionais com o emissor | Verdere hoofdtelefoons met de zender koppelen | Accoppiare ulteriori cuffie al trasmettitore | Parring af andre hovedtelefoner med senderen | Parkoppla ytterligare hörlurar till sändaren




Selecting the sound mode for MUSIC or SPEECH | Klangmodus für MUSIK oder SPRACHE auswählen | Sélectionner le mode sonore pour MUSIQUE ou VOIX | Seleccionar el modo de sonido para MÚSICA o VOZ | Selecionar o modo de som para MÚSICA ou VOZ | Geluidsmodus voor MUZIEK of TAAL selecteren | Selezionare la modalità di suono per MUSICA o PARLATO | Valg af klangmodus for MUSIK eller SPROG | Välja ljudläge för MUSIK eller TAL



Adjusting the volume | Lautstärke einstellen | Régler le volume | Ajustar el volumen | Ajustar o volume | Het volume instellen | Impostare il volume | Indstilling af lydstyrke | Ställa in volymen



Wearing the headphones | Kopfhörer tragen | Porter le casque | Llevar los auriculares | Utilizar os auscultadores | Koptelefoon dragen | Indossare le cuffie | Brug af hovedtelefoner | Bära hörlurarna



Instruction manuals and product support
Bedienungsanleitungen und Produktbetreuung
Manuels d'utilisation et assistance produit
Instrucciones de uso y soporte del producto
Manuais de instruções e assistência ao produto
Bedieningsinstructies en productondersteuning
Manuali d'istruzioni e supporto prodotto
Brugsanvisninger og produkthjælp
Bruksanvisningar och produktsupport

www.sennheiser-hearing.com
www.sennheiser-hearing.com/download