

AIR ONE INSTRUCTION MANUAL

Air one 使用说明书

SOMIC


FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



① 开关机

长按开机或关机, 开机时指示灯白绿灯交替闪烁, 关机时灯熄灭  
单击开关机键: 播放/暂停  
三击开关机键: 唤起语音助手(蓝牙模式下)  
单击开关机键: 接听电话  
双击开关机键: 挂断电话  
三击开关机键: 拒接电话

② 音量调整

短按音量+键, 音量增加, 长按下一曲  
短按音量-键, 音量减小, 长按上一曲

③ 音效开关

ANC模式: 单击ANC键 (正常-降噪-通透) 顺序切换  
空间音频模式: 播放音乐状态长按ANC按键3秒进入, 再按3秒退出 (游戏模式开启状态下可开启空间音频, 同时游戏模式会进行关闭 (优先级: 空间音频 > 游戏模式)  
陀螺仪校准: 在空间音频模式下双击 校准功能, 空间音频模式下可 (正常-通透-降噪) 切换  
游戏模式: 三击ANC键进入, 再次三击关闭回到音乐模式

④ 充电

充电中红灯长亮  
充满后指示灯熄灭  
电池低于10%电量, 耳机会发出低电量提醒, 请及时为耳机充电

⑤ 蓝牙连接

白绿灯交替闪烁, 代表耳机处于待连接中  
连接成功后指示灯熄灭, 提示音 "Connected"

温馨提示: 为维护电池的正常寿命, 请确保本产品2周至少使用一次或以上, 用后请及时补充电量

产品规格


蓝牙版本: V5.4  
蓝牙配对名称: SOMiC Air one  
无线连接范围: ≈10米  
工作频率范围: 20Hz-20kHz  
耳机内置可充电电池容量: 500mAh  
正常充电时间: 6-8h  
耳机工作续航时间: 50h

包装清单

耳机\*1/Type-C充电线\*1/3.5mm音频连接线\*1/说明书\*1

使用声明

1. 充电过程中, 请勿使用耳机
2. 在户外佩戴耳机时, 选择安全的运动场地、道路, 并调整合适的音量, 注意交通安全
3. 请勿在驾驶机动车时使用耳机



① Power On/Off

· Long press the power button. The indicator light will flash white and green alternately when powering on, and turn off when powering off

Playback Control

· Single click on the power button: Play/Pause  
· Triple click on the power button: Activate voice assistant (in Bluetooth mode)

Call Control

· Single press: Answer a call  
· Double press: End a call  
· Triple press: Reject a call

② Volume Adjustment

· Increase Volume: Short press the "+" button, next track: Long press the "+" button  
· Decrease Volume: Short press the "-" button, previous track: Long press the "-" button

③ Sound Modes

· ANC Mode: Single press the ANC button to toggle between Normal, Noise Cancellation, and Transparency modes  
· Spatial Audio Mode: Long press the ANC button for 3 seconds while music is playing to activate Spatial Audio; press again for 3 seconds to exit  
· Note: Enabling Spatial Audio while in Game Mode will deactivate Game Mode (priority: Spatial Audio > Game Mode)  
· Gyroscope Calibration: In Spatial Audio mode, double press the ANC button to calibrate. Switching between Normal, Transparency, and Noise Cancellation modes is supported  
· Game Mode: Triple press the ANC button to enter Game Mode. Triple press again to return to Music Mode

④ Charging Instructions

· The indicator light stays solid red while charging  
· The light turns off when fully charged  
· When the battery level is below 10%, a low battery warning will sound. Please charge the headphone promptly

⑤ Bluetooth Connection

· The headphone enter pairing mode when the indicator light flashes white and green alternately  
· Once connected, the indicator light will turn off, and a voice prompt will announce "Connected."

Warm Tips: If the headphone is not successfully connected or remain in pairing mode for 5 minutes without activity, they will automatically power off

Product Specifications

Bluetooth Version: V5.4  
Bluetooth Pairing Name: SOMiC Air One  
Wireless Connection Range: Approx. 10 meters  
Operating Frequency Range: 20Hz-20kHz  
Built-in Rechargeable Battery Capacity: 500mAh  
Charging Time: 6-8 hours  
Battery Life: Up to 50 hours

Package Contents

Headphone x1/Type C Charging Cable x1/3.5mm Audio Cable x1/Instruction Manual x1

Usage Guidelines

1. Do not use the headphone while charging
2. When wearing headphone outdoors, select safe areas and keep the volume at a level that allows you to hear your surroundings. Pay attention to traffic for safety
3. Do not use headphone while driving a motor vehicle