


说明书材质：105G铜版纸，正反两面单色印刷，Size: 63x73mm

Wireless Speaker User's Manual EBA2-240039A Version 1	CONTROLS  1. Power ON/OFF Button: Press+hold(3s): Power ON/OFF Press once: Pause/Play/Answer phone call, Press+hold 1s to reject phone call, 2x Press to call back the last call. Press once to start automatic search in FM mode. 2. Press once: Increase Volume ; Press+hold (2s): Skip to the next track (or previous radio station in FM mode). 3. LED indicator: the blue light is on when the wireless is working, if the wireless is not connected, it blinks quickly, and if the wireless is connected, it blinks slowly. The red light is on when charging and off when fully charged.	4. Press once: Wireless /FM mode switch, Press+hold(2s) to connect TWS, Press+hold(2s) again to cancel TWS interconnection 5. Press once: Decrease Volume ; Press+hold(2s): Skip to previous track(next Radio station in FM mode) 6. Type C Charging Port 7. Microphone 8. Press once to switch lights, 6-color cycle (Flow - green - red - blue - pink - gradient - light off) SPECIFICATION Input: 5V/1A Power: 3w Battery capacity: 800mAh Playback time: around 4h Charging time: 2-3h Charging port: Type C INCLUDES 1 Wireless Speaker 1 Type C Charging Cable (19.5") 1 Instruction Manual	GETTING STARTED Charging the Wireless speaker Plug the small connector of the included charging cable into the charging port on the wireless speaker. Plug the large connector into the USB port on a computer or a compatible 5V USB adapter (not included) and plug into a wall socket. The LED indicator on the wireless speaker will turn RED while charging and turn off when fully charging. Powering ON/OFF Press and hold the ON/OFF button for 3 seconds to power the wireless speaker ON and OFF. When powered on, the wireless speaker may automatically reconnect to a nearby previously-paired device with wireless enabled. Wireless Pairing 1. Press+hold the wireless speaker ON/OFF Button, "POWER ON" will be heard, now wireless speaker enters the wireless mode, LED indicator blinks quickly 2. Set your mobile device to search for wireless devices. When it appears, select "360 Wireless Speaker" from the list of found devices. 3. After a successful pairing, "Connected"will be heard and the button indicator will blink slowly, and you will be able to play music on the wireless speaker, the blue light is on.	In wireless mode, playback and volume can be adjusted by the controls on a connected device. *Press once the Volume- and Volume+ buttons to Decrease Volume / Increase Volume. *Press+hold 2s the Volume- and Volume+ buttons to skip to previous track / next track(next/previous Radio station in FM mode) ⚠ THIS IS A BATTERY-OPERATED PRODUCT. THIS IS NOT A TOY. INTENDED USE OF THE PRODUCT SHOULD NOT RESULT IN EXPOSURE TO THE INTERIOR BATTERY. In case of abuse, there is risk of rupture, fire, heat, leakage of internal components. Abuses include but are not limited to charging for a long time, short circuit, put into open flame, put into water, whacked with hard object, punctured with acute object, crushed, and broken.	Proper Handling: Do not open, disassemble, crush, or burn battery. Do not puncture, crush, or expose the battery to excessive force.Don't strike, throw or subject the battery to severe physical shock. Do not attempt to disassemble or modify the battery in any way. Do not handle battery in a manner that allows terminal to short circuit. Avoid mechanical damage of the battery. Battery may explode or cause burns, if disassembled, crushed, or exposed to fire or high temperature. Do not short-circuit the battery by connecting wires or other metal objects to the positive(+) and negative(-) terminals. Do not immerse the battery in water or allow it to get wet. Do not use the battery if it gives off an odor, generates heat, becomes discolored or deformed, or appears abnormal in any way. If the battery is in use or being recharged, remove it from the device or charger immediately and discontinue use. Avoid all personal contact, including inhalation. Wear protective clothing when risk of exposure occurs. Proper Storage: Store in a cool, dry, and well-ventilated area. Keep away from heat, fire, and direct sunlight. Keep out of the reach of children. Disposal considerations: Recycle in accordance with government, state and local regulations, to ensure proper disposal.	If exposed to the battery – vapor fumes may be irritating to the eyes and skin. First aid measures: After eye contact: Flush eyes cautiously with plenty of water for at least 15 minutes, occasionally lifting the upper and lower eyelids to assure adequate flushing. Get medical aid. After skin contact: Remove contaminated clothing and rinse skin with plenty of water or shower for 15 minutes. Get medical aid. After inhalation: If inhaled, quickly leave the site to fresh air immediately. Administer artificial respiration if breathing is difficult. Get medical attention. After swallowing: If swallowed, wash out mouth with water provided person is conscious. Get medical attention.	⚠ If exposed to fire, the battery may burst, releasing hazardous chemicals and causing potential combustion. Lithium-ion batteries contain flammable electrolyte that may vent, ignite, and product sparks when subjected to high temperature, when damaged or abused (e.g. mechanical damage or electrical overcharging), may burn rapidly with flare-burning effect, may ignite other batteries in close proximity. Fire-extinguishing measures: Use copious amounts of cold water. May use dry powder, sand, earth. Questions? Comments? Contact contact@culturefly.com FCC Statement - 47 CFR Part 15 - Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Company Name: TopTech International Inc. Company Address: 17870 Castleton St., Ste 215 City of Industry Nevada, CA 91748 United States Telephone Number: (908)930-1042
---	--	--	--	---	--	--	---

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.