



\*Depends on individual use and may be slightly more or less than the time specified.

- The device will turn off automatically if not used for 10 minutes.
- The device will trigger an alarm when the battery is low.
- To charge the device, plug the USB Type-C charging cable into the device and then into a power source.
- The red light will turn on while charging and turn off when fully charged.

CE FCC RoHS  



\*Hängt von jeder individuellen Verwendung ab und kann etwas mehr oder weniger als die angegebene Zeit betragen.

**STROMVERSORGUNG UND AUFLADUNG:**

- Das Gerät schaltet sich automatisch aus, wenn es 10 Minuten lang nicht benutzt wird.
- Das Gerät löst einen Alarm aus, wenn die Batterie leer ist.
- Um das Gerät aufzuladen, stecken Sie das USB-Type-C-Ladekabel in das Gerät und dann in eine Stromquelle.
- Die rote LED leuchtet während des Ladevorgangs auf und erlischt, wenn die Batterie vollständig geladen ist.

CE FCC RoHS  

## **FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

## **RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.