

CHARGING




1. Using a USB Type-C cable (included), insert the jack into the port on back of unit and then plug the USB connector into USB port on the power source.
2. Charge the device until the red LED indicator turns off.
3. Always disconnect the cable when charging is finished.

BLUETOOTH® CONNECTION



- Turn on your device's Bluetooth from the Bluetooth menu and select "MV_SERENITY".



BUTTON FUNCTIONS



Short press: Alarm clock setting mode

When the digits are flashing, confirm the setting value. When the alarm rings, pressing any key other than the alarm key enters snooze mode (**short press** the alarm key to cancel snooze mode).
Long Press: Alarm On/Off



Short press: Clock Setting Mode

When the digits are flashing, confirm the setting value.

Long Press: Sleep Timing Function

Long press to activate 30-60-90 minute timer function. Bluetooth/white noise mode will be shutted down after 30-60-90 minutes.



Long Press: Power On/Off Power On Status:

1. Red light on (Medium mode);
2. 30% volume; 3. Clock display.
Short Press: Play/Pause Music In Bluetooth mode and in white noise mode.



Short Press: Switch Mode

Clock Mode/Bluetooth Mode/White Noise Mode/ FM Radio Mode

(default is Clock Mode when powered on).

Long Press in Bluetooth Mode: Disconnect the bluetooth.

Long Press in FM Radio Mode: Automatic FM channel search.



Long Press: Light On/Off

Short Press: Light Brightness Switch
(low, medium, high)



Short Press: Decrease Volume In music playback mode/ white noise mode/ FM Radio mode.

Decrease digits in clock/alarm setting mode.

Long Press: Previous Track In music playback mode and in white noise mode.

Rapidly decrease digits in clock/alarm setting mode.



Short Press: Increase Volume In music playback mode/ white noise mode/ FM Radio mode .

Increase digits in clock/alarm setting mode.

Long Press: Next Track In music playback mode and in white noise mode.

Rapidly increase digits in clock/alarm setting mode.

TROUBLE SHOOTING



No power

- Recharge your speaker using the USB Type-C cable. If the problem persists, try using another USB Type-C cable.

No response from the unit

- Check if both devices are paired and connected to each other.
- Restart the device and try to reconnect.



MVMT

MVMT and MVMT logo are trademarks of JME & CO, NYC, LLC. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by JME & CO is under license. All other trademarks and trade names are those of their respective owners.

Distributed by JME & CO., New York, NY 10018 USA
©2025 JME & CO, NYC, LLC. All Rights Reserved.
Designed in New York. Made in China. hello@jmeandco.com

FCC ID: 2A3ZO-MA1156



FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1- This device may not cause harmful interference.
- 2- This device must accept any interference received, including Interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or on experienced radio/TV technician for help or assistance.

This device complies with Part 15 of the FCC Rules and Innovation, Science and Economic Development Canada's license-exempt RS5 standard(s). Operation is subject to the following two conditions;

- 1- This device may not cause harmful interference.
- 2- This device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. Under Innovation, Science and Economic Development Canada's regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for

the transmitter by Innovation, Science and Economic Development Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication,

Electronic and electrical devices disposal

This symbol indicates that electrical and electronic device is to be collected separately.



- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- If the device use batteries, they must be removed from the device and disposed in a appropriate collection center.
- If the batteries cannot be removed, do not attempt to do it yourself since it must be done by a qualified professional.
- Separate collection and recycling helps conserve natural resources and prevent negative consequence for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

SPECIFICATIONS

Model No: MA1156

Working Distance: Approx. 33 ft

Playback Time: 8-12 Hours (at 70% volume)

Frequency Range: 20Hz - 20kHz

Output Power: 10 W

Speaker Impedance: 4 Ω / 82dB

Speaker Unit: 50mm / 5W X 2

Lithium Battery: 3.7V/6000mAh

MVMT



RF exposure statement:The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

SERENITY

Red Light & Sleep Support
Alarm Clock / Speaker

IMPORTANT: PLEASE READ BEFORE USING THIS PRODUCT