




T04 Wireless Earbuds User Manual YUWISS DESIGN		WELCOME Thank you for using our T04 Wireless Earbuds. Please allow us to show you how to enjoy them! HEADSET FEATURES • USB charging port • Magnetic charging connector • Charging box battery indicator • Multiple-function button • Answer/Reject/Hang up/Play/Pause • Flash Light Indicator • Microphone	1.HEADSET OVERVIEW Flash Light Indicator Multifunction button Answer/Hang up Play/Pause/Reject Microphone Magnetic charging connector Charging box battery remaining indicator S M L	2.HOW TO WEAR Insert the earbuds into your ears and rotate to fit comfortably. Ensure the microphone is pointing towards your mouth.	2.1 How to change eartips For the optimal audio experience, it is recommended to try each of the different EarGel sizes. The fit should feel tight and secure in your ear. The medium EarGel is premounted on the earbuds. Ensure the EarGel is firmly attached. S M L	3.How to charge How to open charging case: Firmly hold the charging case and lift small tab on the lid while opening the lid. Hold in lift	3.1 How to charge earbuds and charging case To charge earbuds, place the earbuds in the charging case and they will be charged automatically. -If the LED light of earbuds turns to red, which means charging. -If light of earbuds turns to blue, which means full charge. -If light of earbuds isn't on or turns to blue and red flashes alternately, which means they don't charge, please take out and place into charging case again.	4. HOW TO CONNECT LED LIGHT INDICATION: Pairing status - LED indicator flashes blue and red alternately. Connected status - LED indicator flashes blue.
4.1 CONNECT WITH A DEVICE Step1. Take out the earbuds from charging case, and they will flash red and blue lights alternately, which means they are on pairing mode (Ready to pair). And you will hear a sound: "Left channel, right channel", that means two earbuds connect to each other, you can use them on a device. Step2. Enable Bluetooth of the your devices (Such as cell phone, MP3 etc.), scan the earbuds's model name "T04-A", and select to connect with it. After connection, you will hear "connected" Note: If the LED light of earbuds aren't on when you take them out, they probably run out the battery, please go charge them for 15-30 more minutes.(Each light of charging case stands for 25% battery).	4.2 AUTO-RECONNECTED The earbuds can automatically re-connect with the device that had connected last time every time you take the earbuds out from charging case. (Make sure you have turned on the Bluetooth of your device) *Note: If the phone is Android system, please allow the earbuds to access to your phone audio and media audio. 5.HOW TO USE 5.1 POWER ON / OFF Power on Long press (3 sec) the Multiple-function button, LED indicator flashes blue and voice prompt announces "power on" Power off Long press (5 sec) the Multiple-function button, LED indicator flashes red and voice prompt announces "power off"	5.2 VOICE ASSISTANT/SIRI Activate Siri/Google voice commands Press and hold 1 second the Multiple-function button (Simplify "MFB") after pairing and release your finger immediately after hear a sound "Du" or summoning fail. 5.3 MUSIC Play/ Pause music Tap the Multiple-function button Volume up/down Volume +: Quick press touchpad of RIGHT earbud 3 times to turn up the volume. Volume -: Quick press touchpad of LEFT earbud 3 times to turn down the volume. Track control Quick press touchpad of RIGHT earbud 2 times to go to next song, and you will hear a sound "Du".	5.4 CALLS Answer/End a call Tap the Multiple-function button once Reject a call Press and hold (1 second) the Multiple-function and you will hear a sound "Du" then release your finger. 5.5 LANGUAGE Language Switch Under pairing mode(Power on but Not pair with any device), tap the Multiple-function button for 3 times.	6. HOW TO RESET If the earbuds is unable to pair or pair with wrong device that you can't get rid of, please try to reset the earbuds to fix them. Step1. Forget the name of earbuds "T04-A" from device's Bluetooth list, and clean other connection history you don't need. Step2. Power on the earbuds, and keep the earbuds under paring status,DO NOT connect with any devices. Step 3. Quick press one of earbuds 5 times then then you will hear a tone "Du, disconnected" and the LED indicator goes red that means the earbuds have been reset successfully.	7. SUPPORT 7.1 FAQ Q1: Why cannot pair two of earbuds? (1)Please place the two of earbuds back into charging case to charge and then take them out at the same time to connect again. (2)Please follow the above steps to reset them. Q2: What if the earbuds is unable to pair? (1)Please try to reset the earbuds. (2)Contact with us if reset cannot fix it. Q3: What if the earbuds keeps falling out? (1)Please choose the best eartips fit to your ears. (2)Make sure you wear the earbuds correctly. Or just power on them again, but make sure have to power on them at the same time.	Q4: What if the charging case/earbuds cannot be charged? (1)Charge the charging case with stable current, such as laptop USB port. (2)Charge the earbuds 30-60mins before use them again. Q5: I still don't understand how to use? Please do not hesitate to contact with us and we can provide some demo videos regards to your question. Q6: The calling quality / sound quality is not as good as I expected? To provide best product and shopping experience, we have checked every single earbuds before shipment. The item probably damage during shipment, please do not hesitate to contact with us. Q7: The earbuds are bit hot after taking out, is this normal? We suggest you better charge the case when you are using the earbuds avoiding to charge case and earbuds at the same time. High speed charging will make earbuds hot.	8.WARRANTY CARD If any problem occur to the earbuds, please do not hesitate to contact with us before you return it back or leave a review. Our customer supports will always standby for you and offer you best services and solutions that let you feel convenient and satisfied. Official website: www.yuwiss.com Contact us: support@yuwiss.com	BENEFITS TO CONTACT WITH US: 1.Extra 6 months warranty. 2.Over 50% off on every of our new products. 3.Solve your problem quickly. 4.Life-time customer support. 9.Package content: 1 X T04 wireless earbuds 1 X Charging case 1 X Micro USB cable 1 X User manual 3 X Ear tips

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.