

USER MANUAL


Karaoke Speaker




Model No.:CH-006

Dear Customer, Thank you very much for your purchasing, Please read this user manual carefully and keep it for future reference.

Instruction of keys



1. Mode switching key to select mode
2. **▶▶** Pause playback
3. Press **◀◀/V-** for previous song, hold on **◀◀/V-** decreasing the volume
4. Press **▶▶/V+** for next song, hold on **▶▶/V+** for increasing the volume



1. Power ON/OFF : Turn on/off the speaker device
2. Wired microphone jack
3. DC 5V USB charging port
4. TF card insert slot
5. USB insert slot Wired

Operation

1. Turn on the speaker device. Bluetooth mode is enabled by default. Bluetooth Name: CH-006
2. Press “M” mode switching key for choosing FM Radio mode/Bluetooth pairing mode.
3. When speaker in FM radio mode, press **▶||** button, searching the FM channel automatic, then Press **▶||** again, stop to searching the FM radio, in to FM radio station, press **◀◀/V- / ▶▶/V+** to chose the FM channel
4. Insert the USB/TF card, you will hear prompt tone “USB Mode”, “Memory card mode”, press “M” mode switching key for choosing Bluetooth pairing mode/FM radio mode.
5. Connect the wired microphone if you want.
6. Hold on Mode button, can shut off/on LED light

Important Safety Instructions



1. Do not use this device near water.
2. Clean only with a dry cloth.
3. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
4. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Inside Package

Speaker	1pcs
USB charging cable	1pcs
User manual	1pcs
Wired Microphone	1pcs

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

portable device statements

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.