

LED Bubble machine

User Manual



Specifications:

- 1.Voltage : AC90-240V 50-60HZ
- 2.Control : Auto / Sound / Flash / Remote Control
- 3.Remote Distance : 10.9yd/32.8ft
- 4.Package: 1 x Bubble Machine . 1 x Handle
1 x User Manul . 1 x Remote Control
2 x Screw . 1x battery case and DC adapter

Display panel key functions:

Button	Function Description	Functional Description
[MENU]	Feature Selection	Auto/Sound/Flash Manual/Remote Control
[UP]	Select UP	Increase value
[DOWN]	Select DOWN	Reduce value
[ENTER]	OK Button	Save the settings and next reboot will be your last saved interface features

The display panel and display

CL00-CL06	Color selection.By the + and - keys to select different color combinations.
bl01-bl03	Flash.The speed of the + and - keys to change. The larger the value,the faster.
FL01-FL02	Fan. The speed of the + and - keys to change. The larger the value,the faster.
dl01-dl02	Motor. The speed of the + and - keys to change. The larger the value,the faster.
EL01-EL03	Auto. The speed of the + and - keys to change. The larger the value,the faster.
ME	Voice.Changing effects triggered by music.

How To Use

- 1.Powered by Plug-in,used DC adapter plug in not need battery.
- 2.Powered by battery,used battery case plug in.
- 3.When the battery power is exhausted, the DC plug can be used to charge the battery.

With battery case:




3pcs 18650 Batteries
(not include)

Rechargeable battery

Can be used repeatedly

Remote panel Description:



Need 2pcs AAA batteries,not included .

Function Key Description

- ①.Press this button to turn ON or OFF light.
- ②.Press this button to start blowing bubbles,and the lights turn into variable pulse mode.
- ③ .Fan speed adjustment button(2 speeds)

- ④ .Motor off
- ⑤ .Motor on
- ⑥ .Press this button,Color selection.By the R,G,B,RG,RB,GB,RGB,seven colors.
- ⑦ .Strobe mode button,(2 speeds)
- ⑧ .Brightness adjustment button (two brightness)
- ⑨ .Press this button,to turn off the lights.
- ⑩ .Voice,changing effects triggered by music.

Notes:

1. Make sure that the supply voltage meets the stated requirements.
2. Please do not look directly at the light source,or it may damage your eyes.
3. Non-professionals do not dismantle and assemble the product without authorization.
4. The product does not have a waterproof function,pls pay attention to use the product under dry environment.
5. The minors should use the product under the guardian care.
6. The battery case is not waterproof,please do not use in rainy days in outdoor.

FCC Warning Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.