

Instructions

1. Connect the USB cable port to the power adapter and then plug the other side into the type-c port of the charging pad.

NOTES

1. A lower power may result in longer charging time, charging errors or lower efficiency of charging. Charging with QC2.0/QC3.0 adapter is highly recommended.
2. Put the mobile phone on the charger pad, the LED light will turn to green and start charging your phone, as shown below.

Specification

Product Name: Fast Wireless Charger

Input: DC5V/2A 9V/1.67A

Input Port: Type C

Output power: Max 15W

Model: O-07

Color: Black

Caution

1. Please keep the charger away from water or other liquid.
2. If you need to clean the charger, please make sure it is not connected with power supply.
3. Do not place too close to magnetic stripe or clip card (ID card, bank cards, etc) to avoid magnetic failure.
4. Ensure to properly place the center of the phone's back on the position showed of the manual.
5. Remove any metal foreign material between the wireless charger and the phone as they can cause the device not to charge properly.
6. Some kinds of too thick back covers may also halt the wireless charging. Please check the back cover of your phone, or remove the back cover and try to charge again.
7. If your phone has not built-in wireless charge receiver, when installing 3rd party wireless charging cards, be sure that it is installed correctly.

/K1-y3Šā 2N Y2ŘāƧŌ1-ŭā2yā y2ŭ ŠĚLJNŠāāře 1-LJLJN2BŠŘ ōē ūKŠ LJ1-Nŭē NŠāLJ2yāŋŏŦŠ Ƨ2N Ő2Y LJŋ1-yŐŠ Ő2dzŦŘ Ő2Yŋ ūKŠ dzāŠNŭā 1-dzŭK2Nŭāē ū2 2LJŠN1-ŭŠ ūKŠ Š1JdzLJYŠŦŧ ƧKlā Š1JdzLJYŠŦŧ K1-ā ōŠŠY ŭŠāŭŠŘ 1-yŘ Ƨ2dyŘ ū2 Ő2Y LJŋē ōŋŭK ūKŠ Ƨ1-Yŭā Ƨ2N 1- /Ŧ1-āā . Ř1ĀŭŦŦ ŘŠŐŌŠŠ LjdzNādz1-yŦ ū2 t1-Nŭ mp 2Ƨ ūKŠ C// wdzŦŠā ƧKŠāŠ Ƨ1-Yŭā 1-NŠ ŘŠāLJyŠŘ ū2 LJN2BŐŋŘ NŠ1-āzyŦŦŦ LJN2ŭŠŐŭā2y 1-Ė1-ŋyāŭ K1-NYƧdzŦ ŋyŦŠNŦŠNŠyŐŠ ŋY 1- NŠāŋŘŠyŧŦŦ ŋyāŭŦŦŦ1-ŭā2y ƧKlā Š1JdzLJYŠŦŧ 3ŠYŠN1-ŭŠā dzāŠā 1-yŘ Ő1-y N1-Ř1-ŭŠ N1-Ř12 ƧNŠ1JdzŠyŐē ŠYŠNŭē 1-yŘŠ 1Ƨ y2ŭ ŋyāŭŦŦŦŠŘ 1-yŘ dzāŠŘ ŋY1-ŐŐ2NŦ1-yŐŠ ōŋŭK ūKŠ ŋyāŭNdzŐŭā2yāz Y1-ē Ő1-dzāŠ K1-NYƧdzŦ ŋyŦŠNŦŠNŠyŐŠ ū2 N1-Ř12 Ő2YŦy dzYŐ1-ŭā2yā 1 2ŠŠŐŠNŠ ūKŠNŠ lā y2 3dz1-N1-yŦŠŠ ūK1-ŭ ŋyŦŠNŦŠNŠyŐŠ ōŦŦ y2ŭ 2ŐŐdzN ŋY1- LJ1-NŭāŐdzŦŦŦ ŋyāŭŦŦŦ1-ŭā2y 1Ƨ ūKlā Š1JdzLJYŠŦŧ Ř2Šā Ő1-dzāŠ K1-NYƧdzŦ ŋyŦŠNŦŠNŠyŐŠ ū2 N1-Ř12 2N ŭŠŦŠŐŋā2y NŠŐŠLJŭā2y ōKŐK Ő1-y ōŠ ŘŠŭŠNŦŋyŠŘ ōē ūdzNŦŋy ūKŠ Š1JdzLJYŠŦŧ 2ƧŦ 1-yŘ 2yŦ ūKŠ dzāŠN lā ŠyŐ2dzN1-3ŠŘ ū2 ŭŋē ū2 Ő2NŭŠŐŭ ūKŠ ŋyŦŠNŦŠNŠyŐŠ ōē 2yŠ 2N Y2NŠ 2Ƨ ūKŠ Ƨ2ŦŦ2ōŋYŠ YŠ1-ādzNŠāy

- [illegible]

two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter