



Smart Pet Feeder Instructions




PTM - 301

Product introduction




Display function description



- 1.If no operation is performed within 30 seconds, the screen will be locked
2. Hold down the release button for 3 seconds to unlock the feeder

Product assembly

- 1.Rotate the grain drum and the mixing base as shown in the figure
- 2.Rotate the grain drum and install the machine base according to the figure



3. Turn the machine upside down, insert the charging cable into the bottom of the machine, if you need to use the battery, install 4 # 5 batteries as shown
4. Put the machine in position and lift the front side of the machine. Insert the plastic food bowl Install the machine.

Note: Spare batteries are not included in the package



5. Pour in dry pet food, pay attention to the size of 4-12mm, Do not put wet food and dry food that exceeds the size
6. After filling the pet food, rotate and close the lid




Connect APP

The feeder supports 2.4GHz. System requirement iPhone with iOS 10.0 or later, smartphone with Android 5.0 or later.

- Download the app from the IOS or Android APP Store: IPETMON or Tuya Smart or Smart Life Open the APP and make sure your phone is in a WIFI environment. Register according to the guidelines.




Note: Install APP and complete account registration, authorization is required. After entering your mobile number/email address, you will receive a verification code, which must be entered before proceeding with setting your account password.



Timed feeding setting

- 1, click the "feeding plan" option to enter the setting interface. Click the "Add" option to set the feeding schedule.
- 2 Select the number of feedings required during the week, select the feeding time, and specify the portion size for each feeding




3. To activate the feeder, first press and hold the unlock button for 3 seconds. Then, press the RESET icon to the right and hold it for 5 seconds, and you'll notice that the WIFI icon will turn red and start flashing.



Note: If you are using the battery as the sole power source for the feeder, the battery icon will be displayed.


View feeding records

- 1- Click on the "Feeding Record" option to view this week's log, which will show the record after each feeding.



Share the device

1. Enter the modification page and click the pencil icon in the upper right corner of the feeding interface.
2. Click "Share Device" to share this device with your family and friends.




Removal device

- On the Device list screen, press and hold the desired device for 3 seconds to access the Remove Device screen. Select the device you want to remove, and then click the Remove Device button.



Product cleaning

1. Remove the charging cable before cleaning.
2. Open the grain storage bin, take it down, and pour out the remaining cat food.
3. Press the A key as shown, rotate and remove the grain storage bucket



Product parameter

Model	PTM-301
Size	262X182.8 X182.8 mm
Capacity	3L
Weight	6 servings about 55g
Material	ABS+304 stainless steel
Input	5V=1A
Food	Dry food and diameter less than 1.2CM
Adapter	You are advised to use a cable or spare battery

Battery display

- When the battery is fully charged, the battery icon is white.
- If the battery charge is low, the icon blinks.
- If you notice the battery icon blinking, it means the battery needs to be replaced.

Precautions for use

- 1, this feeder is recommended for pets over 6 months old.
- 2, this feeder is designed for indoor use only, to avoid direct sunlight and away from any potential fire or heat source.
- 3, please use the adapter provided with this product to power the feeder. Using any other adapter may result in machine failure or damage.
- 4, do not immerse the host in water or other liquids, it is important to keep the host dry.
- 5, In order to prevent pets from knocking over the feeder, it is recommended to place it against a wall or in a safe location.
- 6, children should use the feeder under adult supervision and guidance to ensure safe operation.
7. If the desiccant bag is found damaged, please stop using it immediately. Contact us for a replacement desiccant bag.
- 8, If you decide to stop using the feeder, remember to unplug the power cord and remove the battery located at the bottom of the feeder.

Warranty

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference.
- (2)This device must accept any interference received, including interference that may cause undesired operation.