

User Manual



1. ON/OFF
2. Status Indicator Light
3. TYPE-C Charging Port
4. Battery Capacity Indicator Light
5. Double click the " ON/OFF" to turn on the music Pulse controller box, and Double click the" ON/OFF" to turn off it.
6. After power on , click the " ON/OFF" three times , the music Pulse controller box will send a 433.92MHz frequency waveform for 40 seconds.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.