

FCC CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

说明书风琴折叠示意图




User Manual

M60 蓝牙音箱
Bluetooth Speaker

01

CHECK ITEM LIST
检查物品清单



音箱*1
Bluetooth audio*1



防滑垫*2
Anti-slip mat*2

充电线*1
Charging cable*1

音频线*1
Audio line*1

02

KEY FUNCTION
按键功能介绍



开机/关机键
POWER ON/OFF



播放/暂停键
PLAY / PAUSE



音量加/下一曲键
VOLUME UP/NEXT




音量减/上一曲键
VOLUME DOWN/PREVIOUS



模式切换键 MODE SWITCH
蓝牙模式——TF插卡模式——FM模式——AUX模式
Bluetooth mode - TF card mode - FM mode - AUX mode

03

REMOVABLE NON-SLIP PAD
可拆卸防滑垫




可将防滑垫置于设备底部，
放置桌面时候起到防滑和保护外观的作用

Anti-slip pads can be placed on the bottom of the device.
When placed on the table,
it can prevent slipping and protect the appearance

04


TURN ON BLUETOOTH
开启手机蓝牙



打开手机蓝牙
Turn on the bluetooth of the mobile phone

05

SEARCH BLUETOOTH
搜索蓝牙设备



找到设备名 “ M60 ” 后点击连接
Find the device name “ M60 ” and click connect

06


CONNECTION SUCCEEDED
蓝牙连接成功



连接 “ M60 ” 后即可自动配对
Automatic pairing after connecting “ M60 ”

07


ANSWER THE PHONE
接听电话



接听/挂断电话，单击功能键
To answer/hang up a call, click the function key

08


MUSIC PLAY/PAUSE
音乐播放/暂停




在音乐播放中，单击多功能按键播放/暂停
During music playback,
the single-machine multi-function button plays/pauses

09

ADJUST THE VOLUME
调整音量




单击+键
Click +
增大音量
Increase volume




单击-键
Click -
降低音量
Lower the volume

10

SWITCH SONG
切换歌曲




长按1s+键
Long press 1S +
切换上一曲
Previous song



长按1s-键
Long press 1S -
切换下一曲
Next song

11

FM MODE
FM 模式




进入FM收音模式，可将电源线插入充电口作为
收音天线，等待音箱读取FM频道，即可收音。

To enter FM radio mode, you can plug the power cord into the charging
port as a radio antenna and wait for the speaker to read the FM channel.

12

CHARGE THE SPEAKER
给音响充电



接入充电线 音响开始充电
指示灯亮表示正在充电
指示灯灭表示充电完成

Plug in the charging cable and start charging
Steady red light means charging
The blue light is always on, indicating that the charging is complete

制造材料认证
MATERIAL CERTIFICATION

为满足中国电子产品有害物质限制相关法律法规和其他要求，
对本产品中有害物质，按部件分类，声明如下：

In order to meet the relevant laws and regulations and other
requirements on the restriction of hazardous substances in electronic
and electrical products in China, hazardous substances in this
product are classified by parts and declared as follows:

产品中有害物质的名称及含量
The name and content of harmful substances in the product

部件名称 Name	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBBs)	多溴二苯醚 (PBDEs)
音箱 Audio	×	○	○	○	○	○
电池 Battery	×	○	○	○	○	○
充电线 Charging cable	○	○	○	○	○	○

本表格依据GB/T 11364的规定编制
This form is prepared according to the provisions of GB/T 11364

合格证书
CERTIFICATE

保修记录表
WARRANTY RECORD FORM

经销商信息 DEALER			
用户信息 USER			
用户名 NAME	联系电话 TEL. NUMBER		
通讯地址 ADDRESS	电子配件 ELECTRONIC PARTS		
保修信息 INFORMATION			
产品型号 NAME	问题描述 QUESTIONS		
保修内容 CONTENT	保修日期 DATE		

注：
(1) 此表应由经销商盖章后确认；
(2) 对于可适用相关“三包”规定的产品，本保修卡等同于三包凭证；
(3) 整机云岭以国家质量监督检验检疫总局、中国海关总署、海关总署公告。请妥善保管。
(4) This form should be stamped and confirmed by the dealer.
(5) For products that are applicable to the relevant "Three Guarantees" regulations, this
warranty card is equivalent to the Three Guarantees certificate.
(6) The maintenance record is subject to the maintenance certificate of the authorized service
organization, other applying for service, please keep it properly.