





LEQISMART

ELECTRIC SCOOTER A6 Pro


USER MANUAL
English



Package Contents



User Manual



Power Adapter




T-shape Allen Key



Screw

Function



Function mode: Cruise mode, Pedestrian mode, Fault prompt, Light, Bluetooth, Lock.

Speedometer: Displays the current speed; displays the remaining mileage within 6 seconds after power-on.

Gear mode: The maximum speed limit is 6 km/h for L gears, 15 km/h for M gears and 25 km/h for H gears.

Battery level: Displays the remaining batterypower; it displays in red and flashing when the power is about 10%.

Switch button: Press it to turn on, press and hold for 3 seconds to shut down; in power-on state, press once to turn on/off the light, and press twice consecutively to switch gears; in power-off state.