

DP01

USER MANUAL


- Digital-Analog Dual Band Channels
- Programmable
- Single Call & Group Call
- Customized Channel Naming
- IP67 Waterproof
- Dialing Contacts
- Message
- GPS Positioning
- 2000mAh Battery Capacity
- High/ Low Power Mode
- Bluetooth



Catalogue

1. Product Layout	1
2. Annotation of The Radio Home Page Icon	3
3. Accessories List	4
4. General Operation	5
5. Battery Removal/Installation	6
6. Headset Installation	7
7. Charging Method	8
8. DP01 Function and Operation Manual	9
A. Contacts Function	9
B. Message Function	11
C. Call Log Function	12
D. Scan Function	13
E. GROUP Function	13
F. Settings Function	14
G. Positioning Function	15
H. Bluetooth Function	16
9. Product Default Parameter Settings	17
10. Extension of Battery Life	18
11. User Security Information	19

1. Product Layout




NO.	Part Name	NO.	Part Name
1	Push-to-Talk(PTT)key	10	GROUP Key
2	Side Key 1 (SK1)	11	LED Indicator
3	Side Key 2 (SK2)	12	Antenna
4	EmergencyAlarmKey	13	USB-C Jack
5	On-Off/Volume Control Knob	14	Battery
6	MenuKey	15	LCD Display
7	UpKey	16	BatteryLatch
8	Back/Keyboard Lock Key	17	Microphone
9	DownKey	18	Speaker

Notes:

- The SK1 and the SK2 are programmable keys. Their functions can be modified through the programming software.
- By default, the SK1 is for monitoring function, and short press is for switching between high and low power.
- Long press of the SK2 is for scanning function, and short press is for turning on/off the prompt tone.


2. Annotation of The Radio Home Page Icon




Notes:

Regarding the display of the ⑤ icon, the display HIGH/LOW icons will be based on the corresponding power selection within the radio.

3. Accessories List



Earphone




Charging base

Notes:


To avoid risk of fire or shock, use only original DP01 power supply inside the package.

4. General Operation

① Turn on/off operating




Power on



Power off

② Volume Adjustment Operation




5. Battery Removal/Installation

① Battery Removal


STEP 1

Locate the battery latch at the bottom of the device and place your hand on the latch.



STEP 2

Hold the latch and pull it outward in the direction shown in the diagram to remove the battery.




② Battery Installation

To install the battery, align it with the slot in the same direction as removal and press it back in until you hear a "click" sound, indicating successful installation.

6. Headset Installation


STEP 1

Locate the silicone cover on the side of the radio with a microphone icon.




STEP 2

Open the silicone cover and insert the Type-C headset cable into the port to complete the headset installation.




7. Charging Method

Charging with a Dock Charger



Charging with a Type-C Cable



8. DP01 Function and Operation Manual

The menu lists differ between Digital Mode and Simulation Mode, with certain menu items omitted in Simulation Mode.

Nevertheless, the functionalities available in Simulation Mode remain consistent in content and definition with those in Digital Mode, ensuring a uniform user experience.

A. Contacts Function Operation Instructions

1. Contacts (Menu → Contacts)

1.1 Default Contacts 4/200:

At the factory, four contacts are preset by default. These include the All-Call contact, contact 1, Contact 2 and Emer-contact.

1.2 All-Call Contact:

The All-Call contact is the default transmitting contact. You can enter the All-Call contact to view its name ("All-Call"), along with your own radio number and its category, which is "All-Call."

1.3 Modifying the Tx Contact:

You may change the Tx contact to a specifically designated Contact. In this case, PTT communication will be limited to a two-party conversation, and no one else will be able to listen or participate.

1.4 Deleting Unused Contacts:

You may also delete any specific contacts that are no longer needed.

1.5 Emer-contact:

1.5.1 The emergency alarm contact ID is preset at the factory to 999999 (compatible with radios of the same model).

Notes: If changes are required, the ID must be modified using the programming software.

1.5.2 Emergency Alarm Operation

- Press the orange emergency alarm key (short press) on the top of the radio to trigger the digital emergency alarm system when operating on a digital channel.
- By default, the radio will transmit an emergency alarm signal and sound an alert tone. Once the pop-up confirms successful transmission, the radio automatically transmits the emergency signal for 10 seconds, then stops for 10 seconds in standby mode. This cycle repeats up to 5 times.
- After 5 automatic transmissions, the radio remains in Emergency Standby Mode with a "Emergency Call" pop-up notification.
- The emergency alarm state will not exit automatically. To exit, press and hold the orange emergency alarm key.

2. Manual Dialing

2.1 Direct Calling:

Enter Manual Dialing mode to input a contact's extension number for a direct call.

2.2 Extension Number Format:

The maximum length of the radio ID is to 8 digits, but it should not exceed 16777215.

2.3 Editing the Number:

A cursor appears beneath the digits. Use the ▲ and ▼ arrow keys to move the "-" cursor to the digit you wish to modify. When the "-" cursor is positioned under the desired digit, press the MENU key. The "-" cursor will start blinking, indicating that the digit is in edit mode.

Each press of the adjustment key will cycle the digit sequentially from 0 to 9.

Once you have selected the desired digit, press the MENU key again. The "-" cursor will stop blinking, confirming that the digit has been set.

Finally, just press the PTT button to call out.

3. Creating a New Contact

3.1 Editing the Number

3.1.1 You can set an 8-digit extension number.

3.1.2 A "-" cursor appears beneath the digits. Use the ▲ and ▼ arrow keys to move the cursor to the digit you want to modify. When the "-" is positioned under the desired digit, press the MENU key. The cursor will start blinking, and each press of the adjustment key will cycle the digit sequentially from 0 to 9. Once you have selected the correct digit, press the MENU key again; the "-" will stop blinking, indicating that the digit is set. Then, press the Return key to go back to the Contacts menu.

Notes: The first digit can only be “0” or “1”.

3.2 Editing the Name

3.2.1 When you see the “.” cursor, press the MENU key. The cursor will begin blinking, and each press of the adjustment key will cycle through the letters A, B, C, ... up to Z. Once you have chosen the desired letter, press the MENU key to confirm; the cursor will stop blinking, indicating that the letter is set.

3.2.2 Press the and key again to move the cursor to the next letter position. Repeat the process: press MENU, cycle through the letters until you find the one you want, then press MENU to lock it in. Continue until you have entered the full name.

3.3 Saving the Contact

Once you have finished setting up the new contact, press the Save key. A “Save Successful” message will be displayed, and the contact’s name and number will be added to the Contact list.

4. Deleting a Contact

4.1 In the Contacts list, select the contact you want to delete.

4.2 Once selected, you will see the option “Delete Contact” in the list. Select this option to delete the contact.

B. Message Function Operation Instructions

1. Message (Menu → Message)

All messages can only receive and send preset content from the quick file. To customize SMS content, you must preset it using the configuration software.

1.1 Inbox

1.1.1 Inbox List (0/60):

A maximum of 60 messages can be stored. Older messages will be overwritten by the latest ones. Press the MENU button once to view a message; messages are displayed from the most recent to the oldest.

1.1.2 Viewing or Deleting Messages:

Press the Return key, then use the Up/Down keys to choose whether to view the SMS content or delete it.

1.1.3 Delete All Messages:

You can also delete all messages in the Inbox.

1.2 Quick Text

1.2.1 Viewing Quick Text

Press the MENU button to view all preset quick text messages.

1.2.2 Sending Quick Text

Use the Up/Down keys to select the content you wish to send, then press the MENU button to choose the recipient. After selecting the recipient, press the MENU button again to send the message successfully.

C. Call Log Function Operation Instructions

1. Dialed Calls (Menu → Call Log)

1.1 Dialed Call Log (0/60):

The Dialed Call List and the Received Call List share a total capacity of 60 records. The factory default display is 0/60.

Older entries will be overwritten by newer records. Press the MENU key to view the contact's name, number, and time of call.

Notes: Only calls from contacts in the call list will be recorded.

1.2 Delete All Records:

You can also delete all dialed call records.

2. Received Calls

2.1 Received Call Log (0/60):

The Dialed Call List and the Received Call List share a total capacity of 60 records. The factory default display is 0/60.

Older entries will be overwritten by newer records. Press the MENU key to view the contact's name, number, and time of call.

Notes: Only calls from contacts in the call list will be recorded.

2.2 Delete All Records:

You can also delete all received call records.

D. Scan Function Operation Instructions

(Menu → Scan)

1. Scan Switch:

Select to enable or disable the scanning function.

2. Scan List:

Choose a scan list to specify the channel range for scanning.

Further Explanation: Custom SCAN Frequency Range

If you have modified the scan list using the programming software, select the desired scan range from the scan list.

The frequency range supported by the radio is UHF 406.1MHz-470MHz.

Notes: The default factory setting scans all channels, with 10 analog channels and 10 digital channels preset.

You can download our programming software through the website:
www.DP01-radios.com.

Please don't hesitate to reach out to DP01 Team:

sanconmarketing2@outlook.com if you need any tech supports.



Technical Support

E. GROUP Function Operation Instructions

(Menu → GROUP)

1. Dual-Channel Monitoring:

This function enables the radio to monitor two channels simultaneously. One channel is used for PTT (Push-To-Talk) communications, and the other is accessed via the "GROUP" button. These channels are referred to as the PTT channel and the Group channel.

2. Emergency Communications:

When the GROUP channel is set to the same frequency as the PTT channel, it can be used for emergency communications. In this configuration, even if the primary channel is on a different frequency, the GROUP channel remains available for emergency use.

3. Simultaneous Dual-Channel Operation:

When the GROUP channel is set to a different frequency, the radio can quickly operate on two channels simultaneously, enhancing communication flexibility.

4. Disabling the GROUP Function:

When the GROUP channel is set to "None," this function is disabled. In this state, pressing the GROUP button will neither transmit nor receive any calls.

F. Settings Function Operation Instructions

(Menu → Settings → Radio Settings)

1. Radio Settings

1.1 Transmission(Tx) Power Level:

Switch between high power and low power transmission modes.

1.2 Backlight:

Choose the backlight duration: options include 15, 30, 45, or 60 seconds.

1.3 Brightness:

Adjust the backlight brightness across 9 levels by press ▲ and ▼ key.

1.4 Prompt Tone:

Enable or disable audio cues for receiving, transmitting, and key presses.

1.5 Squelch Level:

Adjust the level of noise suppression. The higher the level, the better the noise suppression effect.

1.6 Language:

Switch the device language. Currently, the available options are Chinese and English.

1.7 Voice Operated Transmitter(VOX):

Adjust the IVOX sensitivity across 5 levels, or disable the IVOX function entirely.

1.8 Time Zone:

Select the correct UTC time based on your country or region.

1.9 Date&Time:

Modify date and time.

Notes: The date and time can only be modified when GPS is turned off. If GPS is enabled, the current date and time will automatically be set according to the GPS location.

1.10 Lone Worker:

This feature is designed to prevent a person from losing contact when working alone.

Once activated, if the radio is not operated (such as pressing a button or transmitting) within the set time(The default time is 10 minutes and can be modified through the programming software), it will first emit a prompt tone to alert the user.

If no operation is performed after the prompt tone ends, the walkie-talkie will automatically trigger the emergency alarm function and send out an emergency alarm signal to Emer-contact.

2. Device Information (Menu → Settings → Device Information)

View relevant details about your device, including:

Notes

ID: Extension Number

Name: User Name

Freq: Frequency

DMR: DMR Version

HW: Hardware Version

SW: Software Version

D: Programming Date

G. Positioning Function Operation Instructions

(Menu → Positioning)

1. Location Share

This radio is equipped with a GPS positioning chip and antenna, allowing it to send GPS location data during communication.

1.1 Follow TX Operation:

Each time a transmission is made, the current location information will be shared with the designated contact.

1.2 Periodically:

You can set the radio to automatically send the current location to the designated contact every 30 minutes..

1.3 Distance Exceeded:

You can set the radio to automatically send the current location to the designated contact each time the distance from the contact increases by 1,000 meters.

Notes: The transmit contact can be set under the “Contacts” menu. By default, the unit is configured to send to all contacts.

2. Location Display

Displays the device's current time, longitude, latitude, altitude, and heading angle.

Notes: Ensure that the correct UTC time zone is set in the radio settings; otherwise, the displayed time may be inaccurate.

3. Azimuth Map Display

This feature provides a visual representation of the device's orientation relative to the North and South Poles, functioning as a compass.

4. Azimuth Calibration

To calibrate the position coordinates, slowly rotate the device horizontally twice. The system will automatically adjust the positioning.

H. Bluetooth Function Operation Instructions

(Menu → Bluetooth)

This feature allows the radio to connect wirelessly to compatible Bluetooth audio devices, such as headsets or earpieces, for hands-free communication. Before use, please ensure your Bluetooth device is set to pairing mode.

1. On/Off

Select this option to enable or disable the radio's Bluetooth functionality. When enabled, a Bluetooth icon will typically appear on the display, and the radio can

connect to other devices. To conserve battery, it is recommended to turn Bluetooth off when not in use.

2. Saved Device

This menu displays a list of Bluetooth devices that have been previously paired with the radio.

Connecting: Use the Up/Down keys to navigate the list and highlight a saved device. Press the MENU key to initiate a connection.

Managing: Within this menu, you may also have an option to delete a device you no longer wish to connect to automatically.

3. Search

This option scans for new, discoverable Bluetooth devices nearby.

Select "Search" to begin scanning. A list of available devices will appear on the screen.

Use the Up/Down keys to select the device you wish to connect to from the list.

Press the MENU key to start the pairing process. You may need to confirm a prompt on both the radio and your Bluetooth device to complete the pairing. Once paired, the device will be added to your "Saved Devices" list for future connections.

4. Bluetooth PTT

This setting enables the Push-to-Talk function of the radio DP01 through a connected Bluetooth accessory such as Bluetooth buds

ON: When the setting is turned on, to have the radio start or stop the transmitting operation, besides pressing the buttons on the radio, you also can touch or press the designated button on the connected Bluetooth device.

OFF: When the setting is turned off, to have the radio start or stop the transmitting operation, only can you press the buttons on the radio.

Note: The Bluetooth PTT feature requires a compatible accessory that supports this specific function. Not all Bluetooth audio devices have a PTT button or the required profile.

9. Product Default Parameter Settings

CH. No.	Frequency /MHz	Mode	Sub - Code or CC	Channel Spacing /KHz	CH. No.	Frequency /MHz	Mode	Sub-Code or CC	Channel Spacing /KHz
1	464.5000	Digital	1	125	11	464.5000	Analog	67Hz	125
2	464.5500	Digital	1	125	12	464.5500	Analog	67Hz	125
3	467.9250	Digital	1	125	13	467.9250	Analog	67Hz	125
4	461.0375	Digital	1	125	14	461.0375	Analog	67Hz	125
5	461.3625	Digital	1	125	15	461.3625	Analog	67Hz	125
6	466.0375	Digital	1	125	16	466.0375	Analog	67Hz	125
7	451.1875	Digital	1	125	17	451.1875	Analog	67Hz	125
8	452.3125	Digital	1	125	18	452.3125	Analog	67Hz	125
9	456.1875	Digital	1	125	19	456.1875	Analog	67Hz	125
10	457.3125	Digital	1	125	20	457.3125	Analog	67Hz	125

In the factory default settings, 20 channels are preconfigured.
The first 10 channels are digital channels, and the remaining 10 channels are analog channels.

10. Extension of Battery Life

The performance of the battery will be reduced when the temperature drops below 0°C. In cold weather, it is advised to spare another battery for emergency. Please do not dispose the cold batteries that can not work at low temperature but may be usable at room temperature

It may affect the normal use or charge of the battery, if it is covered with dust. Please clean the battery with dry cloth before loading or charging it

Knowledge about Battery Storage

Since the battery will self-discharge, please do charge it fully before putting it aside so as to prevent damages caused by over discharge.

Please take out the battery after storage for some time to fill it, in order to avoid the reduction of the battery capacity resulting from over discharge. It is proposed for lithiumion /lithium-polymer batteries to be filed in every 6 months of storage.

Please pay attention to the humidity of the battery storage environment. Batteries are supposed to be stored in the environment of room tempera- ture, cool and dry air, to reduce the self-discharge.

11. User Security Information

Handheld transceiver product safety and RF radiation

Warning:

Please read the manual carefully before using. It contains the important safety using operation instruction, and RF energy and control information contributing to meet the RF radiation limitation requirement of national and international standards. information provided in this manual may replace the general safety information of the editions before.

Handheld Transceiver Safety Guidelines and Instruction

To control the transceiver radiation, ensure to meet the general or non-controlled environment radiation limitation standard please operate following below procedures. Press PTT key when talking; and release PTT key when receiving.

Because measured RF energy radiation will be generated when transmitting, so transmitting time should not exceed 50% of the using time.

Place the transceiver vertically on the front, make sure the microphone (and other parts including the antenna) is no less than 1 to 2 inches (i.e. 2.5 to 5cm) away from your lips when transmitting signals. It is very important to keep the correct distance from the transceiver, since the farther away the less radiation.

If you carry the portable transceiver around your body, please put into DP01 specially designed fixture, leather, box or other annex. Only use the certified and provision antenna, battery and accessories or other alternatives by DP01. If not, the body by radiation will be out of range of general or non-controlled environment RF radiation limitation that required by Radio Authority. Ministry of Information industry.

If you do not use any accessories, not place the transceiver on the front specified location, please make sure that it is no less than.

1 inch (about 2.5cm) away from your body when transmitting signals. It is very important to keep the correct distance from the transceiver, since the farther the less radiation.

Attention:

This radio complies with IEEE and ICNIRP exposure limits for Occupational / Controlled RF exposure environment at operating duty factors of up to 50% and is authorized by the FCC for Occupational / Controlled use only. An appropriate warning label is affixed to all units. In order to comply with RF exposure requirements, a minimum distance of 2.5 cm must be maintained when held-to-face, and body-worn operations are restricted to the approved original accessories (belt clip), a minimum distance of 0 cm. Do not use this device when antenna shows obvious damages.

This product is compliance to FCC RF Exposure requirements and refers to FCC website <https://apps.fcc.gov/oetcf/eas/reports/GenericSearch.cfm> search for FCC ID: 2A4CJ-DP01 to gain further information include SAR Values.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.