

FRONT COVER



BACK COVER



40 mm

103 mm

FRONT COVER BACK SIDE

REAR COVER BACK SIDE



PCP PN:291-00002-00MSF

尺寸:103X40mm

Material: 100G双胶纸

规格: (双面印刷)


订装方式: 侧面书订 2个钉

Description: Zwift BC2 Quick Start Guide


印刷内容见附页

ZWIFT:CLICK



Quick Start Guide / Guide de démarrage rapide / Kurzanleitung
/ Guía de inicio rápido




CONTENTS/CONTENU/INHALT/CONTENIDO




BAR LOCATIONS/BAR LOCATIONS/BAR LOCATIONS/BAR LOCATIONS





2 STRAP ASSEMBLY/2 STRAP ASSEMBLY/2 STRAP ASSEMBLY/2 STRAP ASSEMBLY




1 STRAP ASSEMBLY/1 STRAP ASSEMBLY/1 STRAP ASSEMBLY/1 STRAP ASSEMBLY




ORIENTATION/ORIENTATION/ORIENTATION/ORIENTATION



**POWER ON/POWER ON/
POWER ON/POWER ON**




**POWER OFF/POWER OFF/
POWER OFF/POWER OFF**



Navigation Pad
Navigation Pad
Navigation Pad
Navigation Pad

Shift Down
Shift Down
Shift Down
Shift Down



Status Led
Status Led
Status Led
Status Led



Action Buttons
Action Buttons
Action Buttons
Action Buttons

Shift Up
Shift Up
Shift Up
Shift Up



Blue pulsing - Ready to connect

Pulsations bleues - Prêt pour la connexion

Blau blinkend - Kopplungsbereit

Azul pulsante – Listo para la conexión



Blue - Connected

Bleu - Connecté

Blau - Gekoppelt

Azul – Conectado



Yellow - Updating

Jaune - Mise à jour en cours

Gelb - Wird aktualisiert

Amarillo – Actualización en curso



Orange Flashing - Low Battery

Pulsations orange - Pile faible



Orange blinkend - Schwache Batterie

Naranja parpadeante – Pila agotada




Red Flashing - Error
Pulsations rouges - Erreur
Rot blinkend -Fehler
Rojo parpadeante – Error



UPDATE/MISE À JOUR/AKTUALISIEREN/ACTUALIZACIÓN



CONNECT/CONNEXION/KOPPELN/CONEXIÓN



BATTERY/PILE/BATTERIE/PILA





[ZWIFT.COM/CLICK/SETUP](https://zwift.com/click/setup)