

80克书纸

PREACE

Dear customers, please read this manual carefully before using the product and keep it properly.

PACKAGE CONTENT

- 1*Men mart I Main device
- 1* Type-C cable
- 1* 3.5mm Aux in cable
- 1* User Manual

KEY FUNCTION DEFINITION

① Power: Long press Turn on/off Short press Play/Pause	⑤ BASS: Long press turn on/off lights Short press to turn off BASS sound on / off
② Bluetooth/Phone: Long press force to disconnect Bluetooth connection Short press switch Bluetooth/Aux in mode	⑥ TWS pairing: Short press on/cancel TWS connection Long press to clear away TWS pairing
③ Answer/Hang off phone call	⑦ Type-C interface
④ Minus: Short press to decrease volume Long press to previous track	⑧ AUX interface
⑥ Plus: Short press to increase volume Long press to next track	⑨ TF card slot
	⑩ Work light / Bluetooth indicator
	⑪ bass sound light
	⑫ TWS light

OPERATION INSTRUCTION

(1) BLUETOOTH MODE

- Turn on speaker enter into bluetooth mode,the bluetooth light starts to flash. Open the bluetooth on your device search for "Men mart I" and connect to your speaker. When the connection is successful, the electronic sound will be activated. The bluetooth light is always on, now you can play music on your device by bluetooth.
- When the bluetooth is connected successfully and you make calls with phone, the voice will automatically enter into the bluetooth hands-free mode.Short press "Ⓜ" key to answer incoming call,Long press to reject call.

(2) AUX IN MODE

Please connect 3.5mm audio cable to the headphone of the phone/computer output interface, short press "Ⓜ" key switch to AUX in mode.After the sound electronic prompt sound "beep", the music can be played.

※ Due to the lower power supply capability,most computer's USB interface can not meet speaker's operational requirements.It is not recommended to use the computer's USB for charging synchronously when you play music in the AUX in mode while connecting computer.

(3) TF CARD PLAY

Please insert TF card in speaker,The audio will automatically switch to the TF card mode and voice prompt "Ding Ding" twice, and then automatically play the music in the card. TF card memory maximum is 32G.
(This mode is only apply to some models, please consult local dealer for details.)

OPERATION INSTRUCTION

(4) TWS STEREO SOUND PLAY

Turn on two Men mart I speakers enter into bluetooth mode. Short press "Ⓜ" bottom of one speaker. TWS light starts to flash, the speaker will automatically search the other for TWS connection,If they connected successfully, two speakers will switch into left and right channels automatically. Repeat the bluetooth connection operation and connect to phone. If they connected successfully, music will play on the speaker shows dual stereo sound effect.

Note:
This function requires two Men mart I speakers,make sure both are turned on and in the bluetooth mode.
No bluetooth connection to any other devices before TWS pairing.
When TWS is connected, short press "Ⓜ" key of one speaker to cancel the interconnection.

Left channel
(Main Speaker)

+

Right channel
(Auxiliary Speaker)

(5) COOL PARTY LIGHTS

Long press "Ⓜ" key to turn on/off lights.Short press to switch to BASS sound.

(6) TYPE-C QUICK CHARGE

※ Do not use power adapter that has not been certificated by safety certification.
※ Power adapter with output 5V-1.5A is recommended for charging.

- When the audio power is low, two electronic prompts will be broadcast,Please charge speaker as quickly as possible.
- This speaker supports self-adaptation charging. It's able to choose charging current automatically according to the external rated power of the adapter. When charging by USB interface on computer, the current is smaller and it takes longer time to complete charging.
- The light is breathing when charging, and the white light is always on when fully charged.

Kindly tips:

OPERATION INSTRUCTION

TROUBLE SHOOTING

- Can not connect to bluetooth or no sound when playing music?
Please make sure the speaker is in bluetooth mode,and also make sure your device supports bluetooth function and bluetooth has already been turned on searching for devices. Check if there are too many bluetooth devices around ,which might bring difficulties of the searching process. Please turn off other bluetooth device.
- What if TF card doesn't respond ?
Please make sure TF card is in good quality,and check whether the audio file is MP3 playing format,If all problems above are excluded ,it might be TF card compatibility issue, you can consider of formatting TF card to FAT32 or change a different TF card.

TECHNICAL PARAMETERS

input voltage	5V/1.5A
Bluetooth version	5.0
frequency response	50HZ~20KHZ
Rated power	20W
Product weight	520g
Battery capacity	4000mA
Product size	L:207*W:78*H:78 mm

V.2.0.3

WWW.WISEPNT.COM
全国服务电话: 400-018-9358
制造商: 深圳市智祺科技有限公司
地址: 中国广东省深圳市龙岗区六约社区勤富路38号
保成泰智汇广场B902
National Service Tel: 400-018-9358
Manufacture: Shen zhen ZhiQi Technology Co., Ltd.
Address: B902 Baohengtai Square, No.38 Qinfu road, Liuyue Community, Henggang Street,Longgang District,Shenzhen. China

Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.