




Remote Control Outlet

[Instruction Manual]




Please pay attention to the warning signs
Read the instructions with caution before operating
and keep it properly

Warning:

To reduce the risk of fire, electric shock, or personal injury, please strictly follow the instructions.

1. Indoor use only. Avoid high humidity, high temperature, and areas with a high magnetic field.
2. Always be sure to cut off the power before installing the receiver.
3. Don't connect any device that may exceed the performance limits of the receiver.
4. Don't install or repair the product Only authorized service personnel should undertake such installation and repairs.
5. If the remote is not in use for an extended period time, remove batteries.
6. Used batteries should be disposed of safely and properly.
7. To prevent a choking hazard, keep packing materials away from children.
8. Do not use the battery again if it is dropped or knocked out of shape.

Product Illustration



Programming the Outlets

Note: The transmitter and receiver have been pre-programmed for immediate use, but the configuration can be customized to meet your needs.

To program a remote transmitter and receiver:

1. Plug the receiver into the socket.
2. Press and hold the program button on the receiver until the indicator

light starts to blink slowly.

3. Release the program button, then press the “ON” or “OFF” button corresponding to the number on the transmitter.

4. When the indicator light stops flashing, the program is paired successfully.

Repeat Step 1-4 to pair multiple transmitters and receivers.

Cancel All Programming:

Cancel all the programs so that no remote transmitter can control it.

1. Press and hold the program button on the receiver until the indicator light starts to blink rapidly.

Note: The indicator light blinks from slow to fast.

2. Release the program button, then press it again, the indicator light will go

off, which means cancel the program successfully.

No Interference

Remote control outlets adopt variable learning codes technology. The codes will be changed each time after re-programming. If this remote control outlet happens to be in the same channels with other RF remote devices, just re-program it and the interference will be eliminated.

Battery Replacement

If you find the receiver works abnormally or the indicator on the remote transmitter becomes dim, please replace the remote battery with a new DC 12V (type 23A) battery, making sure the polarity +/- of the battery is correct.

- Low battery power may decrease readable wireless remote range.

- Remove batteries if the remote is not in use for an extended period of time.

Troubleshooting

In the case that one receiver is unresponsive to the remote control, please follow the steps below to resolve the issue:

1. If the wire switch receiver is unresponsive to the remote control, please refer to the “Canceling Programming” and “Programming the Receiver” sections in the manual to reprogram the receiver.

2. Make sure the receiver and appliance are properly connected and powered on.

3. Replace the remote battery with a new DC 12V (type 23A) battery.

4. The remote transmitter may be too far away to control the receiver.

5. Make sure not to exceed the maximum load.

6. "Canceling Program" is always prior to "Programming the Receiver" when you would like to make changes.

Specifications

- Input Voltage: 125VAC, 60Hz
- Max Power Rating: 15A /1875W (Resistive), 10A /1250W (Tungsten)
- Transmission Frequency: 433.92MHz
- Remote Control Distance: 100 Feet (Free Area)
- Remote Battery: 23A, 12V

Safety Information

Federal Communications Commission Interference Statement. This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Redirect or relocate the receiving antenna.
- Increase distance between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

ISED Warning:

This device complies with Innovation, Science, and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil n' doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain

Canadian information on RF exposure and compliance.

Le présent appareil est conforme

Après examen de ce matériel aux conformité ou aux limites d'intensité de

champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la

conformité and compliance d'acquérir les informations correspondantes.

One Year Limited Warranty

Supported by our professional R&D team and QC team, we provide One Year Warranty for materials and workmanship from the purchase date. Please note that the warranty does not cover damage caused by personal misuse or improper installation.

Please attach your Order ID and Name so that our dedicated customer service team can help you better.

