

JELLYFISH MOOD LAMP SPEAKER

USER MANUAL



Specifications

- Bluetooth version: 5.3
- Wireless range: 10 M
- Speaker size: 50 mm (4W)
- Power input: 5V 2A
- Material: ABS + PC
- LED modes: 12 color options
- Auto shut-off: After 4 hours of use
- Includes remote control
- FM tuner-Signal dependent


Contents

- 1pc Jellyfish Speaker 2.0
- 2pcs decorative jellyfish
- 1pc decorative fish
- 1pc remote control
- USB power adapter




Instructions

1. Remove the rubber cap from the top of the container.
2. Fill the aquarium with water. Do not overfill; leave about .25" of space at the top.
3. Add 1-2 drops of liquid dish detergent. Gently stir with a straw or stick (not included).
4. Carefully place the jellyfish upside down into the water; push to bottom. Use a straw or stick to remove any air bubbles.
5. Put the rubber cap back on securely.
6. Connect the USB cord to the product and wall adaptor (doesn't come with adaptor).
7. Press the Power button once to turn on the speaker in Bluetooth mode.
8. Press the Power button twice quickly to switch to white noise mode (6 soothing soundscapes available).
9. Press the LED button once to turn on the lights.
10. Press and hold the LED button to turn the lights off.
11. Use the remote control to adjust lighting modes and volume as desired.
12. The unit will automatically shut off after 4 hours of continuous use. Wait 1 hour before restarting.





Remove rubber cap.




Fill aquarium to the top with water.


Connect **A** end to the product and plug **B** end of the USB-C cord in a charger



Turn on the switch.



Add 1-2 drops of liquid dish washing detergent (not included).




Turn on the power at least 30 seconds before adding the jellyfish into the aquarium.

Try to avoid air bubbles forming on the jellyfish. If necessary you can use a straw or stick to help to remove the air bubbles.

Put the jellyfish UPSIDE DOWN and push to bottom of tank.




Put on rubber cap.




ON/OFF:

1. Press the button to activate the lamp in "automatic light color changing" mode.
2. Press again to turn off.

SELECT: Press to change colors.



Dry the surface of the aquarium.



Please change water occasionally when dirty.

Warning

1. Do not place objects or fingers inside the aquarium while operating.
2. Always keep the device on a flat surface to prevent tipping or spilling.
3. Avoid direct sunlight and do not expose the product to extreme temperatures.
4. Change water occasionally when it becomes dirty.
5. Do not attempt to replace the LED components.
6. Avoid physical or water damage; warranty does not cover misuse.
7. Keep out of reach of small children and pets.
8. For best performance and durability of the unit, it will switch off automatically after 4 hours of operation.
9. Leave for 1 hour before pressing the button to re-activate the unit.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warranty & Support

1-Year Limited Warranty
Register your product at:
www.trendtechbrands.com

Warranty excludes physical or water damage.



FCC ID: 2A4HD-JFSPK1

Wireless Express™
137-1 Express Street, Plainview, NY 11803
Made in China