

封2

内页

内页 内页

封底

Q: Some of keys on my Samsers keyboard do not work.

1. Changing the keyboard for 3-4 hours, remove the Bluetooth connection record "Samsers K08S" and then reconnect it;
2. Turn off / restart the sensitive touch feature in your device.
Open "Settings" → "Accessibility" → "Touch" → "AssistiveTouch" → "OFF"

Sleep Mode

1. When the keyboard is not used for more than 10 minutes, it will automatically enter the sleep mode and the indicator light will be off;
2. When you use the keyboard again, you only need to press any key, and the keyboard will wake up within 3 seconds. The indicator will light up again and start to work.

Contact Us

If you have any use problems with your keyboard / mouse, please do not hesitate to contact us! Please rest assured that we will definitely help you solve them!

Please contact us for a 24-month worry-free warranty:

support@samsers.com

EC	REP	eVatmaster Consulting GmbH Bertelsplatz 30 60323 Frankfurt am Main, Germany contact@evatmaster.com
----	-----	---

UK	REP	KOVA ASSOCIATES LTD 72a Kingston Road, Portsmouth, Hampshire, PO2 7PA, United Kingdom KOVA.Compliance@outlook.com
----	-----	--

Made in China

CCC Statement

Certification of modifications not expressly approved by the party responsible for compliance could void the user's ability to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to another electronic device which can be determined by turning the equipment off and on, the user is encouraged to take one or more of the following measures:

- Reorient or relocate the receiving antenna;
- Increase the separation between the equipment and receiver;
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected;
- Consult the dealer or an experienced radio/television technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause intermittent operation.

www.samsers.com

 — support@samsers.com —