

128克铜版纸
成品尺寸: 85 *125 mm

双面印刷 折页

User Manual



PN-W51A
20000mAh Solar Power Bank

Thank you for choosing our product. To ensure a smooth experience, this manual provides detailed instructions, including product introduction, usage guide, and other relevant information. Please read this manual carefully before use to ensure correct operation.

Product Parameters

USB-C Input	DC5V/3A 9V/2A 12V/1.5A
USB-C Output	DC5V/3A 9V/2.22A 12V/1.67A
USB-A Output	DC5V/3A 9V/2A 12V/1.5A
USB-C Cable Input	DC5V/2A 9V/2A 12V/1.5A
USB-C Cable Output	DC5V/2.4A 9V/2.22A 12V/1.67A
Wireless Output	5W 7.5W 10W 15W
Battery Capacity	20000mAh/3.7V (74Wh)
Solar Charging	DC5.5V/0.23A (Light Intensity>25000Lux)
Flashlight Power	1W
Camping Light Power	2W

Product Details



Product Features

- Unique Exterior Design: Fashionable and exclusive.
- High-quality Lithium-polymer Battery Cells: Ensuring safety and stability.
- Built-in USB-C 27.5 inch Retractable Cable: Charging both phones and the power bank itself.
- Strong Magnetic Wireless Charging: Precise alignment and secure attachment to phones.
- Integrated Solar Panel for Charging: Allowing you to charge your digital devices anytime, anywhere.
- Built-in LED Flashlight and Camping light: Making it more convenient for outdoor use.

Instructions

1. Turn on/Turn off:

Press the power button lightly to turn on the device. The LED indicators will display the current power level. If no charging device is connected, the device will automatically power off after 30 seconds.

2. Charging the Power Bank

Connect one end of a cable to the power bank's USB-C port and the other end to a charger's USB port. When fully charged, all battery level indicators will remain on. Alternatively, use the built-in retractable USB-C cable: plug it directly into a charger's USB-C port to charge the power bank.

3. Charging Other Devices

Press the power button lightly to turn on the device. Connect your device charging cable to the appropriate port on the power bank, and plug the other end into the device you wish to charge.

4. Using the Built-in Cable:

Press the power button lightly to turn on the device. The battery level indicators show the remaining capacity. Pull the built-in retractable USB-C cable from its storage slot and connect it to your phone or other device to begin charging.

5. Wireless Charging

Supports automatic induction for wireless charging. Align the phone with the product's wireless charging area. An orange indicator light will stay on during charging. If the orange light flashes, check if the phone is properly aligned or if the phone case contains metal objects.

6. LED Flashlight and Camping light

Long press the power button for 3 seconds to turn on flashlight, then short press to switch to SOS/strobe/off. Double-press the power button to turn on the camping light, short press to to adjust brightness (3 levels), double press again to turn off.

Package Contents

Solar Power Bank x1 User Manual x1
Charging Cable x1 Carabiner x1

Product Maintenance

To ensure optimal performance and longevity of the product, please note the following:

- Keep away from moisture and corrosive substances.
- Do not clean the product with chemicals.
- If the product will not be used for an extended period, recharge it fully at least once every three months.

Other Important Notes

- Do not disassemble or modify this product.
- Keep the product away from fire and moisture to prevent malfunctions.
- Do not use the product in high-temperature environments ($\geq 45^{\circ}\text{C}$ / 113°F).
- Only connect devices that comply with this product's output specifications.
- Immediately stop using the product if the battery bulges, leaks, or emits an unusual odor.

Frequently Asked Questions & Troubleshooting

The battery indicator flashes when the power button is pressed.

- The battery level is critically low. Please charge the power bank immediately.

Unable to charge the power bank.

- Try using a different charger and charging cable.

The power bank does not reach full charge even after an extended charging time.

- Please use the included cable or a charger supporting an output of 5V/2A or higher.
- Check if the charging indicator works normally during charging.
- Check if there are any unusual sounds or odors
- Do not attempt to disassemble the product or repair yourself, as this will void the warranty.
- If the issue persists after following the steps above, please contact our After-Sales Service Department.

Other Important Notes

- 12 months of warranty and lifelong technical support
- Support full refund or returned without product/package damage in 30 days
- Free exchange for quality problems in 12 months
- We take great concerns about customer's opinions, if you have any questions about our product, please contact us with Amazon message and we will respond in 24 hours.

How to Contact Us

If you have any questions or need our support for warranty service, please contact us via email support@browey.com. Our customer service team will provide technical support within 48 hours. (Please send your order number instead of the warranty card if your purchase is from Amazon)

FCC Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The device has evaluated to meet general RF exposure requirement. The device can be used be in portable exposure without restriction.