

Superbcco MK221

Wireless Keyboard and Mouse

User's Manual

*Thank you for purchasing **Superbcco 2.4Ghz Wireless Keyboard and Mouse Combo**. Each unit has been manufactured to ensure safety and reliability with life-time warranty. Before using for the first time, please read the instructions carefully and keep them for further reference.*

PACKAGE CONTENTS

- 1 * Wireless Keyboard and Mouse
- 1 * USB Receiver (stored inside the mouse not in the keyboard)
- 2 * AAA-Type Batteries for the Keyboard (included)
- 1 * AA-Type Battery for the Mouse (included).
- 1 * User Manual


Note: MacBook, iPad, iPhone, Android Phone, Tablet, etc.

Please use a USB dongle/OTG to make it work.

SETTING UP YOUR WIRELESS KEYBOARD AND MOUSE

1. Install 2 AAA batteries in your keyboard and 1 AA battery in your mouse (Note: batteries+/-ends should follow those indicated on the battery compartment label).



❶



2. Connect the 2.4 GHz USB receiver to the computer (Please note that this combo only needs one USB receiver for both keyboard and mouse; and the USB receiver is inserted in the back of the mouse below the on/off power icon and please pull it out of the mouse). Warning: plug the USB receiver into USB 2.0 port (usually the black one) not USB 3.0 the blue one; this is due to USB 3.0 radio frequency interfere with 2.4GHz wireless device, and not properly plug-in may lead to mouse lagging or freezing

problems. Sometimes the black one can also be USB 3.0.

2



3

3. Flip the power switch on (Power on/off placed on the back of the mouse. There is no power switch on the keyboard. Additionally, the "POWER" indicator light on keyboard doesn't turn on when connecting to computer; and the keyboard and mouse have already been successfully paired before delivery. The light on keyboard "A" turns on when you press CAPS LOCK (capital letters).

FUNCTION KEYS

When  is locked, press to activate F1~F12 functions keys;

Hold down FN+  to unlock FN key and press the desired function key.

Key Icon	Windows	Key Icon	Windows
Esc	Home		Decrease Brightness
	Mute		Increase Brightness
	Decrease Volume		Calculator
	Increase Volume		Search
	Previous Track		Setup
	Play/Pause		Device Sharing
	Next Track		FN-key Lock

DELETE Key: Please select the object first and then press delete to make the DELETE key work;

BACKSPACE Key works as direct delete as well.

4 FUNCTION KEYS



Under Chinese Input Mode+Shift



Under English Input Mode+Shift



Under Chinese Input Mode (No Need Other Operation)



Under English Input Mode (No Need Other Operation)

3 FUNCTION KEYS



Under Chinese Input Mode+Shift



Under English Input Mode+Shift



Directly Input



Directly Input

TROUBLE SHOOTING

Common Symptoms	What You Experience	Possible Solutions
Unable to use the keyboard mouse	No response when operating your keyboard or mouse	1. Check if the batteries are inserted correctly (Batteries + and – ends should follow those indicated on the battery compartment label)
		2. Check if the mouse's power switch is set to On .
		3. Remove and reinstall the batteries.
		4. Remove and reconnect the USB receiver on your computer.
		5. Restart your computer
Mouse lagging or no response	Mouse lagging or no response	6. Battery is out of power and please change the battery;
		7. Clean the surface of the mouse's sensor;
		8. Try it on another computer;
		9. Contact us for replacing

		another USB receiver. Sometimes lagging due to wifi speed or specific computer.
--	--	--

TECHNICAL SPECIFICATIONS

Item Name	Wireless Keyboard and Mouse Combo HW221	Battery	2 AAA & 1 AA Batteries (included)
Material	Environment-Friendly ABS	Optical Resolution	1600 DPI
Interface	USB	Number of Keys	96
Transmission Distance	10m/33ft	Hotkeys	12
Operation Voltage	5V	Features	Wireless, Cute, Plug and Play
Operation Current	<20mA	Mouse Size	6.1cm x 10.7cm x 3.8cm/2.4" x 4.3" x 1.5" (Approx.)
Service Time	≥10 Million Strikes	Keyboard Size	38.4cm x 14.3 cm x 2.3cm/13.7" x 5.6" x 0.7" (Approx.)
Colors	Seafoam Green/Lemon Yellow		
Supported Operating Systems	Microsoft Windows 10/8/7/XP/Vista/Server 2003/Server 2008/Server 2012, Linux 6.x, Ubuntu, Neoklyin, Free DOS, Chrome and Android.		

LIFE TIME WARRANTY

Superbcco warrants this product to be free from manufacturing defects for life-time warranty from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit.

COMPANY ADDRESS

Shaanxi Depin Trading Co., Ltd:

Room 705, Building No. 2, Internet Industry Land, Weibing South Road No. 1, Garden Road Zone, Qiaonan Street Work Station, Weibing District, Baoji City, Shaanxi Province, 721000

CONTACT US

Official Website: www.de-pin.com

Tel: +01 (415) 326-9924

Email: info@de-pin.com

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.