




Wireless headset instructions	Specification of Earbuds Wireless version : 5.4 Protocol: Supports HFP 1.7, HSP 1.2, AVRCP 1.6,SPP 1.2 and PBAP 1.0 Speaker Diameter : 6mm Working distance: 10m Call Time: 5-6H (1 time full charged) Play Music Time: 5-6H (1 time full charged) Battery type: 3.7V Charging Time: 1-2H Working Temperature: -10°-55° Specification of charger case: Input current: 5V—0.4A Battery type: 3.7V Charging time:1-2H Serious warning: Do not use this product while charging. Please use the acadapter specified by the manufacturer to charge the product. Do notdi sassemble the built-in lithium battery. Do not let the metalcont act ar short the electrode.Do not touch or squeeze thebattery to avoid Place in a humid or hot (>60 C) environment.	Fitting  Instructions: 1. Ensure that the charging cabin is charged. If the charging cabin is out of power, please fully charge the charging cabin. (Pick up the two earphones and put them back on the cover. If the indicator light of the charging bay is on, it means there is electricity, and if it is not on, it means there is no electricity.) 2.Take the two earphones out of the charging cabin and putthem on the left and right ears respectively. The earphones will be powered on automatically and paired automatically. (Voice prompt: power on, left channel, right channel, waiting for connection) ③ Mobile phone connection operation: open bluetooth search of mobile phone, and click the link in the device name that is found to have the model of the machine (S880). The left and right channel earphones voice prompt "Connection successful" and the mobile phone display: connected, ready to use.	Warming remain For the first time to use the earbuds or for a long time to no use, please charge the charging case and earphones before,Please keep it in an unobstructed and effective environment within 10meters. Otherwise, it may be stuck and disconnected. Up and down operation: double click to touch the multi-function button next or previous song Hold for 3 seconds to turn on/off Click Pause/Play   Double click/Next or previous  Increase or decrease (+/-) Volume operation: Tap and touch the volume "+*" or volume "*" of the multi-function button three times in a row, or directly adjust the volume by using the volume key on the mobile phone	Three strikes/volume "+*" or volume "*" "  Single Earbud Mode: When the main earbud (L) and the secondary earbud (R) are not connected, taking out one of any of the earbuds separately from the charging case.The earbud prompts "turn on" . then for 3 seconds, the blue light flashes—the red and blue lights flash alternately, open the mobile phone Bluetooth function, search for the Bluetooth device and Click Connect, the "Bluetooth Connected " will be displayed in the upper right corner of the phone screen, and the earbud will prompt "Connected", or the manual operation of a single earbud will repeat the above operation. Dual mode operation: continuously tap the headset to touch the position for 4 times to switch the game mode	Operation for more than two times: Connect with the used mobile phone - turn on the bluetooth of the mobile phone and take out the earphone in the charging bin at the same time. It will automatically connect with the mobile phone without any operation. If you use a different mobile phone for more than two times, follow the instructions before using it. Safety guidance: 1.please use the standard 5V charger (4.9-5.5V) 2.Do not place the charging case and the Bluetooth earbudsnext to the flammable explosives. 3.Do not disassemble the charging case and Bluetooth earbuds,or insert other items into the product to avoid damage to thep roduct or even cause harm to you. 4. Please do not give the headset to children to play, so as to avoid accidental eating by children!
--	---	--	--	---	--

无线耳机 —— 使用说明书 ——	产品描述 耳机功能参数: ①无线版本: 5.4 ②支持协议:Supports HFP 1.7 HSP 1.2, A2DP 1AVRCP1.6 SPP 1.2 and PBAP 1.0 ③喇叭直径:6mm ④工作距离:10m ⑤通话时间:4-5H(满电单次使用) ⑥音乐播放时间:4-5H(满电单次使用) ⑦电池类型:3.7V, ⑧耳机充电时间:1-2H ⑨工作温度:-10°C-55°C 移动充电仓参数: ①输入电流:5V—0.4A ②充电仓充电时间:1-2H 双模式操作: 连续敲击耳机触控位置4次可切换游戏模式	佩戴示意图  使用说明: ①确保充电仓有电, 如果充电仓没电请给充电仓充满电,(把两只耳机拿起来再放回盖好盖子, (充电仓显示屏亮表示有电,不亮表示没电) ②把两只耳机从充电舱取出分别戴在左右耳朵上, 耳机将自动开机, 自动配对:(语音提示:开机" 咚 " 等待连接) ③手机连接操作:打开手机蓝牙搜索,在搜索到的设备中有 蓝牙名称 (S880)点击链接。左右声道耳机语音提示 "连接成功" 同时手机显示:已连接,即可使用。 温馨提示: 首次使用或长时间不用, 请务必给充电舱和耳机充电后再使用, 请保持在10米内无阻碍的有效环境使用, 否则可能出现卡顿和断连。	指示灯说明: ①给耳机充电:把耳机放入充电舱, 盖好盖子即可充电。耳机指示灯: 充电时亮灯, 充满后 灯灭。 严重警告: 内置锂电池切勿拆开放置火中, 不可让金属品接触或短路电极, 不可撞击或挤压电池, 避免放置于潮湿腐蚀性或过热(>60℃)环境中。 长按3秒开/关机 单击暂停/播放  上、下曲操作:双击 触摸多功能按键下一曲或上一曲  加减 (+/-) 音量操作:连续3击 触摸多功能按键音 量 "+" 或 音量 "-", 也可以直接操作手机上的音量键调节音量大小	三击/音量 "+" 或 音量 "-"  单耳单独使用: 主耳机与副耳机无连接时, 从充电仓单独取出其中一个, 耳机提示 "开机" 灯光 闪烁, 点击打开蓝牙, 搜索蓝牙设备并点击连接, 手机屏幕右上角 会显示 "蓝牙已连接图标" 同时耳机提示 "连接成功", 或者 单个耳机手动开机重复以上操作。 二次以上使用操作: 和已经连接使用过的手机—打开手机蓝牙, 同时拿出充电仓内的耳机, 不需要任何操作, 即会和手机自动连接上了。如果二次以上使用不同的手机, 需要按照使用说明中操作步骤操作后方可使用。 安全指导: ①充电仓请使用标准5V充电器 ((4.9-5.5V) ②充电仓与蓝牙耳机充电时请勿将放在易燃易爆物品旁边。 ③请勿拆卸充电仓与蓝牙耳机, 或将其它物品插入产品内, 以避免产品损坏甚至给你带来伤害。 ④请勿将耳机给儿童玩耍, 避免儿童放入口中误食!	护理及保养: ①将蓝牙耳机放入口袋前, 请将蓝牙耳机放回充电仓, 避免碰撞所导致的误操作。 ②请勿使用具有腐蚀性的清洁剂清理蓝牙耳机。 ③请勿将蓝牙耳机暴露在高温过高的地方。 ④请勿将蓝牙耳机长时间暴晒。 ⑤请勿让蓝牙耳机靠近火源。 ⑥请勿将蓝牙耳机掉落、撞击、刮擦、扭曲、敲打、碾压、投入水中等。 ⑦使用蓝牙耳机时请将远离磁体、电器和扬声器附近。 ⑧请勿将蓝牙耳机放置于极端温度中 (使用环境温度范围 -10°C-55°C) ⑨请勿将蓝牙耳机暴露潮湿的环境中 ⑩若长时间不使用蓝牙耳机, 请充满电并隔一个星期冲一次电, 延长蓝牙耳机使用寿命。
---------------------------------	---	--	--	--	--

型号	S800-S880-S808(说明书)
尺寸	60*46mm
工艺材质	80克书写纸

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.