

FCC WARNING:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received, which may cause undesired operation.

When using this device, the following instructions should be followed: (1) This device must not be used near a medical device, (2) This device must not be used near a fire alarm, (3) This device must not be used near a telephone, (4) This device must not be used near a television, (5) This device must not be used near a radio, (6) This device must not be used near a microwave oven, (7) This device must not be used near a power line, (8) This device must not be used near a power cord, (9) This device must not be used near a power switch, (10) This device must not be used near a power outlet.

WHEN USING A KEYBOARD:

1. Before using the keyboard, please read the user manual carefully. 2. Please do not use the keyboard in a wet environment. 3. Please do not use the keyboard near a fire or heat source. 4. Please do not use the keyboard near a power line or power cord. 5. Please do not use the keyboard near a power switch or power outlet.



GUARANTEE

No-shipment damage 12-month warranty

PRODUCT BASIC / ОСНОВНЫЕ СВЕДЕНИЯ

Manual Руководство пользователя	Switch and Keycap Pull Съемник переключателя и клавиш	Keyboard Клавиатура	USB Type-C cable Кабель USB Type-C	2.4 G Dongle Датчик 2.4 Г
Size Размер	Backlight Подсветка	Language Язык	Layout Раскладка	Switch Переключатель
302 (202mm) x 140 (42.7mm) x 40 (10.2mm)	RGB	English / Russian	QWERTY / Cyrillic	Blue / Brown / Red

INDICATOR LIGHT / СВЕТОВЫЕ ИНДИКАТОРЫ

Caps Lock Win Lock

Charging indication: The red light shows lights on when charging, goes off when fully charged, and the red indicator light flashes when the power is low.


KNOB FUNCTION / ФУНКЦИИ РУЧКИ

	Clickback Volume + Поворот ручки вправо для увеличения громкости +
	Clickback Volume - Поворот ручки влево для уменьшения громкости -
	Press to mute Нажатие ручки для отключения звука


WIRED CONNECTION / ПРОВОДНОЕ ПОДКЛЮЧЕНИЕ




BT CONNECTION / BLUETOOTH ПОДКЛЮЧЕНИЕ




BATTERY LEVEL REMINDER / НАПОМИНАНИЕ ОБ УРОВНЕ ЗАРЯДА БАТАРЕИ



2.4 G MODE / БЕСПРОВОДНОЕ ПОДКЛЮЧЕНИЕ 2.4 ГЦ



TOUCH FUNCTION / ФУНКЦИИ СЕНСОРНОГО ЛОГОТИПА



FCC WARNING:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received, which may cause undesired operation.

When using this device, the following instructions should be followed: (1) This device must not be used near a medical device, (2) This device must not be used near a fire alarm, (3) This device must not be used near a telephone, (4) This device must not be used near a television, (5) This device must not be used near a radio, (6) This device must not be used near a microwave oven, (7) This device must not be used near a power line, (8) This device must not be used near a power cord, (9) This device must not be used near a power switch, (10) This device must not be used near a power outlet.

BATTERIES:


This device is powered by two AA batteries. Please insert the batteries correctly. Do not use the device if the batteries are low or if the device is not working properly. Please replace the batteries when the device is not working properly.




GUARANTEE

No-shipment damage 12-month warranty

CUSTOM BACKLIGHT SET / НАСТРОЙКА ПОДСВЕТКИ



SECONDARY COMBINATION FUNCTION KEYS / СПЕЦИАЛЬНЫЕ ФУНКЦИОНАЛЬНЫЕ КЛАВИШИ



BACKLIGHT CONTROL / УПРАВЛЕНИЕ ПОДСВЕТКОЙ



MULTIMEDIA KEYS / МУЛЬТИМЕДИЙНЫЕ КЛАВИШИ

