


HK607 中性英文说明书

尺寸:80*100mm 风琴折

材质 :128g铜板纸 黑白正反印刷

折后此面朝上

Waterproof wireless speaker with light show




Please charge before use

Model number:HK607

HK607 is a Floating lightshow speaker with IP68 waterproof. It can be widely used for swimming pool, hot tub, bicycling, hiking, camping, party, indoors,etc.with colorful light show, it is also a wonderful night ambient Light, making life colorful.

1. Introduction to Parameters




Light Mode Button (short press) /TWS Button (double press)

volume down(Long press) /previous track(Short press)

ON/OFF button (long press) /Play/Pause button (short press)

Volume up(Long press) /Next track(Short press)

Charging port



5.9"

5.7"

5.9"

4.7"

BT version	V5.0
Battery capacity	2000mAH lithium battery 3.7V
Working hours	5-7 hours
Freequency	2400MHz-2480MHz
Protocol	A2DP\AVCTP\AVDTP\AVRCP\HFP\SPP\SMP
Communication distance	15-25 meters
Speaker	5W 2Ω
Dimension	4.24"x4.24"x4"
RGB light type	Yellow,Green,Red,Blue
Light mode	8 modes
Waterproof	IP68

It takes about 3 minutes to pair for the first time. After the pairing is successful, it will automatically pair in the future, which only takes 8 seconds.

2.After power on, if without any pairing, it will enter the sleep state after 20 minutes, and then shut down after another 40 minutes.

2. Button Function Description

A. Multifunction Button: 

1.Long press 3 seconds to power on, and long press again 3 seconds to power off.

2.When in playing music, short press this button to pause music, press again to play music.

3. When the call is coming, short press the button to answer the phone, and double press the button to refuse the call.

4. Double tap to dial the last coming call number.

B. “volume-and previous”Button: 

Short press the button to play the previous track, long press the button to reduce the volume.

C. “volume+and next”Button: 

Short press the button to play the next track, long press the button to increase the volume.

D. Light mode Button: 

I Short press to switch the different LED modes.

1. Slow flashing when there is no music: red green blue yellow turns brighter every 20 seconds.

when there is music: the LED lights flashes with the music.

2. Keep red light

3. keep green light

4. keep Blue light

5. RGB light color change automatically(slow and fast flashing are mixed)

6.RGB light color automatically switches slowly

7.RGB light color automatically switches quickly

8. The light power off.

II: Long press the light button for 8 seconds to restore factory settings

3. BT Pairing Settings

Long press on the multifunction button for 3 seconds to power on. Wait the blue light flash, open the BT mode on your smartphone and select “HK607” to pair the device. It’s now paired. You can broadcast your music ! If not, start again or relaunch the HK607.

4. TWS function operation

TWS function means two BT speakers can connect with each other, playing music at the same time.

1.Turn on two BT speakers into Bluetooth pairing

2.Double press the Light Mode Button of one speaker to start TWS connection, after two speakers are connected with each other successfully, there is beep sound prompt.

2. Turn on the Bluetooth function of your phone to search and pair the speaker pairing name,"HK607".

3. After paired successfully, the phone's music will be played out by two speakers at the same time.

4.Double press the Light Mode Button of one speaker to disconnect TWS function.

5.Double press the Light Mode Button of one speaker to restart TWS function.

5. Charging

Please take the charging cable included to charge the speaker. During the charging, the Led Indicator will keep red. after fully charged, the LED indicator is Blue.

Note: Use the included cable and respect the voltage!

6. Accessories

1*HK607

1*User manual

1*Charging cable

1*Gift box

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.



Made in China