


Digital Media Player

User Manual



Preface

- Thank you for purchasing this digital media player. Please read this manual thoroughly before use.
- This manual is based on the latest product information available at the time of production. Any product modifications are subject to change without prior notice.
- The power interface of this product is designed specifically for charging the built-in battery. Please charge the device using a USB port from a computer or a 5VDC/1A power adapter that complies with national standards and is CCC certified. Please do not connect to other power supply equipment, otherwise it may cause irreversible consequences such as failure to charge or data and hardware damage, for which we do not assume any responsibility.
- Do not attempt to repair or disassemble the product yourself. Unauthorized repairs will void any warranty or after-sales service.

Precautions

1. Keep the device away from electromagnetic environments, excessive humidity, and dusty conditions.
2. Do not submerge the device in water. Do not use corrosive or abrasive cleaners.
3. Avoid applying excessive pressure to the device.
4. Please do not vibrate or hit the product violently.
5. It is recommended to lower the volume before using headphones and gradually increase it to a comfortable level. To protect your hearing, avoid high volume (Prolonged use of high volume listening can damage the listener's hearing.If you experience tinnitus, reduce the volume or stop use) .
6. Keep the device out of reach of children to prevent accidents or falls.
7. Unplug the device after charging to avoid prolonged power connection.
8. Do not use headphones while driving, cycling, operating machinery, or when awareness of surrounding sounds is required.
9. Battery Charging Notes :


- 1) This device uses a rechargeable polymer lithium battery.
 - 2) The battery must be replaced by professionals only. Improper battery replacement may result in explosion. Use only the same or equivalent battery type. Dispose of used batteries properly via professional recycling services.
 - 3) Battery lifespan may vary based on usage and manufacturing date.
 - 4) Do not expose the battery to direct sunlight, fire, or overheating environments.
10. Due to possible software updates, actual usage may differ slightly from this manual. Please refer to the actual product.

Main Features

- ◆ 4.0 inch full-view IPS display
- ◆ Full-screen touch control
- ◆ Supports multiple audio formats, synchronized lyrics display, multiple sound effects for high-quality audio
- ◆ Supports video playback with 1080P HD decoding
- ◆ Equipped with latest Bluetooth 5.0 module: low power consumption, high stability, long transmission distance (supports bidirectional Bluetooth)
- ◆ Supports Wi-Fi connectivity
- ◆ Clock and alarm functions
- ◆ Supports various image formats and slideshow playback
- ◆ Supports TF cards up to 128GB
- ◆ Multi-language support

- ◆ Built-in speaker

Button Descriptions



No.	Description	No.	Description
1	Volume Up	2	Volume Down
3	Reset Button	4	Power/Screen On-Off
5	Speaker Jack	6	USB Port
7	TF Card Slot	8	Recording Holes
9	Headphone Jack		

Quick Guide

Power On: In the power off state, press and hold the power button to turn on.

Power Off: In the power on state, press and hold the power button to turn off.

Main Interface

Status Bar: Shows time, battery level, Bluetooth, and Wi-Fi status at the top.

Function Icons: Swipe left or right to browse features. Tap an icon to enter the corresponding function.

System Reset

If the device freezes, press the “RESET” button to force shutdown. Then press the power button to restart.

Navigation

- Tap the ◀ icon at the bottom to go back.
- Tap the “○” icon to return to the home screen.
- Tap the “□” icon to view and close running

applications.

- Tap the “▽” icon to hide part of the menu.

Volume Adjustment

- **Buttons:** Press the “Volume +” or “Volume -” to adjust volume level.
- **Touchscreen:** Drag the slider on the volume bar to adjust the sound.

Charging

- **Adapter Charging:** Connect the adapter to power and the USB cable to the adapter and device. Charging takes about 3 hours. Use only CCC-certified 5V/1A adapters.
- **Computer USB Charging:** Connect the supplied USB cable to your computer's USB port, then insert the other end into the player's USB Type-C port to charge. The player can also be used as a removable disk. Charging via a computer's USB port is slower

than using a power adapter.

Note:



When charging via a PC USB port, the charging time may vary slightly due to differences in current output capacity across USB ports on different PCs. For faster charging, it is recommended to charge the device while the PC is powered off.



Slight heating during charging is normal.

Accessories List

- Device x1
- Type-C USB Cable x1
- User Manual/Warranty Card x1
- Product Certificate x1

(*Actual contents may vary based on package.)

Function Descriptions

Gallery

Tap the “Gallery” icon to view saved photos, screenshots, and media on the TF card.

FM Radio

Tap the “Radio” icon to access FM features. Tap “ < ” “ > ” to manually fine-tune the radio band to select a station. Tap “ ⏮ ” “ ⏭ ” to select the saved radio station quickly. “ ★ ” is the saved radio band. The upper right corner “ ≡ ” is the automatic search for radio bands. “ 🎧 ” can select headphones or speakers. “ ⋮ ” can record the sound of the radio band. Tap “ ● ” “ ● ” to play or pause the radio.

Recording

Tap the “Record” icon to access:

1. Start Recording: Tap “ ● ”

2.Pause/Resume: Tap“||” to pause the recording and click “●” again to resume recording

3.Save Recording: Tap “■”

4.File List: Tap the folder icon “≡” to view saved files

【Note】Recording format: WAV

Calendar

In the main interface, Tap the“calendar” icon to enter.The upper left corner“▼”can choose: day/week/month/schedule corresponding to the format of the interface.Tap a date to add notes.“⋮” The menu offers: Create Event, Refresh, Search, Display Settings, Clear Events, Jump To Date, Settings.

File Manager

Browse internal or TF card files. Tap to open files or media, and switch to appropriate function. Long press to

Copy, Cut, Share, Delete, Rename, View Info. New folders and search supported.

Bluetooth

Tap “Bluetooth” to toggle on. Tap to search and connect to available devices. Paired devices will auto-reconnect.

The icon will change when connected. 

Settings:

Tap “Settings” to configure:

1.WLAN: Connect to Wi-Fi

2.Bluetooth: Connect to phones, headphones, speakers etc.

3.Memory: View internal storage status.

4.Apps & Notifications: View recent apps and permissions etc.

5.Battery: Check battery info and power saving options etc.

6.Display:Adjust brightness ,wallpaper,sleep

time,font,screen rotation etc.

7.Sound: Adjust media,alarm, and notification volume

8.Storage : Manage internal and TF card storage

9.Security :Set screen lock, data encryption

10.Auto Shutdown: Set timer (5/10/15/20 min ,or Never)

11.Schedule Power on/off : can set the automatic on/off time

12.Google:

13.System:a.Language & input; b.Date & Time;c.

System updates; d. Reset options; e.About device

Charging and Battery Management

1. Connect one end of the USB cable to a PC, the other to the device to charge.
2. Charging is complete when the battery icon stops flashing.

Notes:

- New batteries require several cycles for optimal performance.
- If unused for a long time, recharge monthly to prevent over-

discharge damage.

- Battery damage due to over-discharge or non-original chargers is not covered under warranty.

Using TF Card

- Insert the card properly until you hear a “click.”
- To remove, press the card inward and release to eject.

Cautions:

- Insert card correctly into the slot.
- Do not remove the card during operations to avoid data loss.
- Avoid high temperatures or humidity.
- Keep away from liquids and corrosive materials.

Product Specifications

Product Name	Digital Media Player
--------------	----------------------

Model	
Dimensions	106*59*10.8mm
Display	4.0 inch 640×1136
Battery	2000mAh
Charging Spec	5V/1A input
Charging Time	Approx. 4 hours
Bluetooth	V4.1/ V5.0
SNR	≥85dB
TF Card Support	Up to 128GB
Audio Formats	MP3、WAV、APE、FLAC、AAC
Video Formats	AVI、MKV、RMVB、MP4、MPG、MOV
Recording Format	WAV
Image Formats	JPG、BMP、GIF、PNG
Interface	Type-C
OS	Android 9.0 / 13 / 14
Languages	Simplified Chinese, Traditional Chinese, English (Multilingual)

Working Temp	0°C~45°C
--------------	----------

Note: Audio specs are for reference only. Slight variation may occur due to electronic component differences. Please refer to the actual product.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction

Specific Absorption Rate (SAR) information:

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue.

Device types: This device has also been tested against this SAR limit

This device was tested for typical body-worn operations with the back of the This device kept 5mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 5mm separation distance between the user's body and the back of the This device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.