


SUPPER BASS
MINI BLUETOOTH SPEAKER
USER MANUAL

V7

PRODUCT DISPLAY CHART



Thank you for choosing the V7 Super Bass Mini Bluetooth Speaker. Please read this manual carefully before use and keep it for future reference.

IMPORTANT SAFETY & NOTICE INSTRUCTIONS

Do not disassemble the device by yourself, if disassemble, not in the warranty.

Please use good quality charger to recharge the device, or it may reduce the lifetime of the device.

Make sure it is out of the kids.

Make sure it is far from fire and the object whose surface temperature is over 60°C, to avoid severe damage or burning.

Make sure it is stored in no corrosive gas environment.

Make sure it is stored in the environment between 15°C and 60°C, then the device will be originally good for 6 months.

We are not responsible for any loss or damage incurred during shipment or as a result of a majeure.

We are not liable for any incidental or consequential damages arising from the misuse or intended abuse of the product.

All warranty claims are limited to repair or replacement of the defective product and at the sole discretion of us.

OVERVIEWS

1. Volume +
2. SD Card Slot
3. Volume -
4. Charging Interface (Micro USB)
5. ON/OFF Button



FEATURE DESCRIPTION

Super Bass Mini Speaker

TWS Bluetooth 5.0 Wireless Connection

Built-in SD Card Slot

Hands Free phone call is available

SPECIFICATION

Li-Polymer battery : 500mAh

Dimensions: Φ 53(L)*48(H)mm

Net Weight : 91g

Sound output: 5W

Operation distance:>10m

Frequency response:120HZ-20KHZ

Charging Time: 2- 3 Hrs

Working Time: up to 4Hrs (60 - 90 minutes in max volume)

PACKAGE CONTENTS

V7 Bluetooth Speaker x 1

Charging Cable x 1

User Manual x 1

Lanyard x 1

INSTRUCTION

- 1- Long press ON/OFF button for 3 seconds to turn on the speaker
- 2- Long press ON/OFF button for 3 seconds to Turn off the speaker
- 3- Quick click ON/OFF button to display or pause
- 4- Long press ON/OFF button to reset
- 5- In the status of connecting between speaker and mobile phone, enter camera mode of mobile phone, quick click ON/OFF button to take photos.
- 6- Quick click ON/OFF button to pick up / ring off phone call.
- 7- Long press Volume + to increase volumes, quick click for next song.
- 8- Long press Volume - to decrease volumes, quick click for previous song.

LED INSTRUCTION

Standby Status: Blue Light is flashing quickly.

Connected Status : Blue Light stays on.

Charging Status: Red Light stays on.

Full charged Status: light's off.

Music Displaying Status : blue light is flashing slowly.

USAGE TIPS

1. Make sure your devices are charged-enabled.
2. Make sure the V7 is fully charged before using it for the first time.
3. Turn off the speaker when it is not used, as well as before storing it.
4. In order to protect the circuitry of the speaker and ensure the long-term performance of the built-in battery, do not turn on the speaker while it is charging. Also, V7 does not support this function.
5. To protect the long-term performance of the built-in battery, do not use or keep V7 in a hot environment (above 60° C/140° F), such as in a hot vehicle or under direct sunlight.
6. Do not expose the V7 or any of its accessories to liquids.

WARRANTY

We offers a 12-month warranty defective from the date of

purchase.

Any damage or malfunction resulting from improper use or unauthorized disassembly or repair will not be covered by our warranty.

We also take no responsibility for products purchased from unauthorized retailers.

For detailed information, please contact our customer service.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID: 2A4UJ-V7