

训狗器折页说明书 2022 09 23
成品尺寸:90x140mm


PEACHAR

Dog Training Collar Model: X100




User Manual
Please read this instruction carefully before using this product.

PACKAGE LIST




Contents: 1 Receiver, 1 Remote, 1 Test Light, 1 Long Contact Points, 2 Silicone Caps, 1 User Manual, 1 Charging Cable

OVERVIEW



Handheld Remote
ON/OFF Switch (Leveling Button)
LED Indicator
Adjusted
Digital Display
Vibration button
Shock button
Shock Level
Digital display
Shock Level (00-99)
Battery Status Remote
Battery Status (Receiver)

OVERVIEW




Receiver
LED Status Light
Charge Status Light
ON/OFF Switch
Magnetic Charging Port
Contact Points
Important Safety Information
WARNING: Indicates a hazardous situation which, if not avoided, could result in serious injury. Do not use with aggressive dogs. Do not use the product if your dog is prone to aggressive behavior. Aggressive dogs can cause severe injury to their owners and others. If you are not sure that the product is right for your dog, please ask your veterinarian or a certified trainer.

CAUTION


CAUTION: Use with the safety alert symbol indicates a hazardous situation which, if not avoided, could result in minor or moderate injury. Risk of skin damage. Please read and follow the instructions in this manual. Proper fit of the collar is important. A collar worn too loosely or made too tight on the pet's neck may cause skin damage. Always use correct pressure when adjusting the collar. This condition is commonly known as bed sores. Avoid leaving the collar on the dog for more than 12 hours per day. Provide separation of the collar on the pet's neck every 1 to 3 hours. Check the fit to prevent excessive pressure. Follow the instructions in this manual. Never connect directly to the electronic device. It will cause excessive pressure on the contact points. When using a remote collar for a leash, don't put pressure on the electronic collar. Wash the dog's neck area and the contacts of the collar weekly with a damp cloth. Check the contact area daily for signs of a rash or sore. If a rash or sore is found, discontinue use of the collar until the skin has healed. If the condition persists beyond 48 hours, see your veterinarian.

Fit the Receiver Collar



Note: The Contact Points must be in direct contact with the skin under the dog's neck. Check the tightness of the Collar by inserting one finger snugly between the collar and neck.

To turn the Remote and Receiver on




Rotating the regulator A to turn the Remote on. Press the button to turn the Receiver on. When not using the collar, turn off to increase the battery life. Long press the button to Sleep to turn the Receiver off.

Keypad Lock




Security keypad lock or unlock.

Beep Tone command




Delivers a beep tone with non-adjustable volume to the collar.

Vibration command



Delivers vibration to the collar. Vibration frequency adjustment. Press the vibration Level button B, then rotating the band A of the remote.

Shock Stimulation command




Shock button (Delivers current selected level Shock stimulation to the collar. Shock + button That is 10% higher than the currently selected level). Some consumers would like to instant access to a higher setting while the dog may not respond to lower level. Shock + button. Press the status level button C, then rotating the level regulator A of the remote. Some consumers would like to instant access to a higher setting while the dog may not respond to lower level. Shock + button. Press the status level button C, then rotating the level regulator A of the remote.

How to find the Best shock Level for Your Dog?

Very Important: Always start at the lowest level and choose the level that is best for your dog. Have 1 to 99 different Stimulation Levels. Follow the steps below to find the best level:
1. Start at Level 10 on the Digital Display, press the shock button to see dog reaction.
2. If your dog continues to show no response at Level 10, check the fit of the Receiver Collar.
3. If your dog keeps barking or tries to bark, change to a longer set of Contact Points, or a 600V Test Light will need to be inserted around the Contact Points. If all these steps have been taken and dog continues to show resistance, see the "How to Use Test Light Tool" function.

Main Features




How to Use Test Light Tool
A: Status function test
1. Make sure the Remote and Receiver Collar on.
2. Hold the Test Light red contacts to the Contact Points.
3. Press A button on the Remote Transmitter. The Test Light will be lit.

Training Tips


If you want to eliminating unwanted behavior - For examples, barking, Please follow these training steps:
1. Put a separate non-metallic collar on your dog's neck above the Receiver Collar, and attach a 6-10 foot leash. (Note: Be sure the extra collar does not put pressure on the Contact Points).
2. Hold the leash and the Remote Transmitter.
3. Choose your pet's Recognition Level.
4. As soon as your pet is barking, press the Stimulation button and give the command "No" or "No barking."
5. Release the Stimulation button immediately once your dog stop barking, and verbally praise him.
6. If your pet ignores the stimulation, increase the Intensity level by 3 to 5.
7. Practice this exercise in several different areas.

Pairing



Notes: 1. You may skip this step because the set is already paired by factory setting. 2. Make sure the Receiver is turned off. 3. Press and hold Switch for 5 seconds and the receiver beep and the green light flash fast. 4. Press and hold Switch for 5 seconds and the receiver beep and the green light flash fast. 5. Press the button of the remote to select the Dog, then press the button 3 seconds and the green light is flashing fast. 6. Pairing successful, the receiver will beep and the green light flash fast.

TWO , Three , Four Receiver system



Notes: (Note: Please skip this step if you only use one receiver. This setting only for multiple receiver with one remote.) Part I: Pairing 2nd, 3rd, or 4th Receiver. 1. Receiver: 1. Make sure the Receiver is turned off. 2. Press and hold Switch for 5 seconds and the receiver beep and the green light flash fast. 3. Press and hold button C to select the dog (in the example Dog 2, the dog will not light). 4. Long press the remote Magnetic Charging Port button C for 5 seconds and the green light is flashing fast. Part II: Receiver Switching: 1. All 4 collars do it at the same time. 2. Press covered button C to select the dog to link.

After-Sales Customer Service



Customer Service: support@peachar.cn Website: www.peachar.cn

Compliance

FCC Statement
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device. Radiation Exposure: This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This device and its accessories must not be co-located or operation in conjunction with any other antenna or transmitter.

IC warning:
This device contains license exempt transmit(receive)/or that comply with Innovation Science and Economic Development Canada's license-exempt (ICES). Operation is subject to the following two conditions: 1) this device may not cause interference and 2) this device must accept any interference, including interference that may cause undesired operation of the device. Radiation Exposure: Cet équipement est conforme aux radiations du Canada limites d'exposition pour un environnement non contrôlé. Cet appareil et ses accessoires ne doivent pas être co-localisés ou en opération en conjonction avec toute autre antenne ou émetteur.

DECLARATION OF FIMED CANADA:
Cet appareil contient des transmetteurs (récepteurs) qui sont conformes à l'innovation Science et Économie Développement Canada's licence-exempt (ICES). L'opération est soumise aux deux conditions suivantes: 1) cet appareil ne peut pas causer d'interférences et 2) ce dispositif doit accepter toute interférence, y compris tout provoquer le fonctionnement indésirable de l'appareil. Exposition aux rayonnements: Cet équipement est conforme aux radiations du Canada limites d'exposition pour un environnement non contrôlé. Cet appareil et ses accessoires ne doivent pas être co-localisés ou en opération en conjonction avec toute autre antenne ou émetteur.

EC REP TANMATEE INT'L BUSINESS LTD
25-100 Yonge Street, Toronto, ON M5T 1G5, Canada
CE ROHS MADE IN CHINA