

成品尺寸：70*100mm
展开尺寸：280*100mm

正面

Smart gamepad

Introduction Manuel



■ Product introductions:


- This is a smart gaming console with Classic appearance design. It uses 2.4Ghz wireless transmission technology. It is a best game-pad controller for Android smart phone/ Tablet/TV Box/ Smart TV.

■ Product Specifications:

- Exclusive game Store.
- Fit for Android smart phone/ Tablet/TV Box/ Smart TV.
- Use 2.4Ghz RF wireless transmission technology, distance ≥8M.
- Support android standard menu key including MODE.
- Use 2 x AA batteries (Notincluded).
- Service life of buttons: 500000 times.
- Service life of rocker: 500000 times.
- Surface finishes:anti sweat and oil.
- Low power consumption.
- 1xWireless Gamepad
- 1xNano Receiver.
- Gift Box. Packed Safely in blister

■ Fast start

1. The receiver received intelligence android TV or TV box ofa USB interface;
2. The gamepad is equipped with batteries, open the power switch to "ON" position, the handles and receiving head automatic connection, the connection is successful after the red LED normally ON, without success, please press MODE button twice quickly and receiver forced the attachment.
3. Product Overview



■ Gamepad operation in detail

● Power On/Off

1. Open the power switch to "ON" position, the handle wil be automatically connected to the recaiver, indicates a red LED normally ON after the connection is successful, if is not successful, please switch gamepad power or Insert the receiver again.
2. the power switch in the "off" position place, the gamepad is in completely turned off, power consumption is 0mA

The Gamepad according to the prompt after the connection is successful, the game please keep proper distance with the television:

● Gamepad sleep Model

1. (Boot attachment) when there is no connect receiver, after 10 seconds Into sleep mode;
2. If there is no any operation of shaft and buttons, 5 minutes after go into sleep mode;
3. When Into Sleep mode need to press the HOME key wake up after a red LED light, can begin to play games.

● The gamepad code

When the gamepad can't operation or to increase a new gamepad, we need the gamepad with the receiver in the code;

The receiver is powered on for 15 seconds after treatment of code state;

- a) The receiver to the SmartTV or TV box USB port, turn on the TV orTV box power;

- b) The gamepad is equipped with battery, the power switch to "ON" position (to code the distance of not more than 2 meters), express press HOME button, LED flashing rapidly, marks the state of the code;
- c) When the red LED normally on state, the code is successful, if the horse did not succeed, please turn off the controller power supply wait 3 seconds and then open the power supply or the receiver.
- d) If you need two gamepad into the game, with the same like before way.
- e) The normal default mode of Android, if it for computer operation required need by 5 seconds then open for PC mode;

■ Frequently asked Questions

1. Why open the gamepad switch LED does not flash, also can not connect to the device?

A: please confirm whether the battery is installed or whether the battery is properly installed.

2. Why the LED flashing used in the process?

A: If is low battery consumption need to replace the battery!

3. Why the red LED is not bright in the process of using?

A: Maybe is broken nee to re connect to the code.

4. Why sometimes appear LED flashing or button delay in the use of the process?

A: Maybe there are too far away from the TV and the receiver is too far ,Can be used to extend USB line for receiver;

5. Why the gamepad can not be used in the computer game?

A: Please select the OPTION in the game handle device operations, and set a good button mapping relationship, if the game OPTION are not found in the game equiprent, the game only supports the keyboard and mouse ,it does not support the gamepad;

6. Why can not be play the game on the phone?

A: First ,please confirm whether the phone is Android's mobile phone system, if it is support the OTG function. Please turned on the function.

■ Attentions:

1. When the gamepad unexpected disconnection, it is have voltage protection and other conditions, can't be connected making the gamepad, and the connection without the function and other crash loading state, then need to turn off the power switch 3 seconds after re open;
2. if you have any other questions, please contact the vendor!
3. Don't take this product placed in extremely hot and huld place, put it in a dry place;
4. Children should be used under the supervision of adults!
5. Don't use alcohol to wipe any part of the product, please use a soft cloth and a small amount of water to clean the product!
6. Can be compatible with PCIP3

Product warranty card

The purchase of the product, please fill in this card, and be ready to save

User profile	
customer name	
Sex	
postal addre	
zip code	
contact number	
Where to buy	
Date of pur chase	
Name and specifications	
Sale No	
Serial No	
Dcaler signature	
User signature	

背面

产品规格说明书



产品概述

安卓智能电视无线游戏手柄，经典外观，人性化设计，采用2.4CHz无线传输技术设计智能省电模式，为您专心打造一款适配安卓电视游戏手柄，同时也支持电脑、手机平板的通用型游戏手柄，让您玩任何游戏更加得心应手。

一、产品规格

连接方式: 采用24GH2 RF无线传输技术

产品重量: 156G

接收距离: 8米 1

使用电池: 2节 AA 电池 (7号)

表面处理: 防汗油

按键寿命: 50, 0000次

摇杆寿命: 50, 0000次

按键支持: 支持安卓标准菜单键 Home键功能

待机电流: 小于 60Ua


工作电流: 小于 15mA

适用安卓系统智能、平板、电视盒、智能电视、机顶盒及微软WIN7以上系统的电脑、

(支持 OTG 功能的安卓手机)

一、快速开始

1. 请将手柄接收器插入到智能安卓电视机或机顶盒的USB接口(安卓智能手机需要 OTG转换)
2. 请把手柄装上电池，打开电源开关到ON位置，手柄与接收头自动连接，连接成功后红色LED常亮，若没有成功，请快速按2次 HOME 键与接收器强制连。
3. 支持局域网厅等游戏平台，简需游戏厅下载游戏后连接接收器信号即可直接使用(部分游戏支持夜战)
4. 手柄功能键如下图



二、手柄详细操作

1.开启手柄

打开电源开关到"ON"位置，手柄会自动与接收器连接，连接成功后指示红色LED常亮，设有成功，请重新开关手柄电源或拔插接收器。

2. 手柄使用

手柄连接成功后即可根据提示使用，游戏中请与电视机保持适当的距离；

3. 手柄关机

将电源开关置于 "off"位置，手柄就处在完全关机状态，耗电为 0mA；

4. 手柄睡眠

1. 开机连接时，当没有手柄接收器时，10秒钟之后进入睡眠模式；
2. 在连接状态下，如果没有任何轴和按键的操作，5分钟之后进入睡眠模式；
- 3睡眠模式下需按 HOME键唤醒，唤醒后红色LED亮，就可以正常玩游戏。

5.模式切换

按照默认安卓模式，如在电脑上操作需长按 5秒 MODE 键切换 PC模式；

五、常见问题

1. 为什么打开手柄开关 LED 不闪，也连接不上设备？

答: 请确认是否安装好电池，或电池安装是否正确。

2. 为什么使用过程中 LED 会闪烁？

答: 电池电量低，需要更换电池。

3. 为什么在使用过程中红色 LED 不亮了？

答: 可以断线，需要重新对码连线。

4. 在使用过程中有时出现LED 闪烁或按键后？

答: 有可能手柄与电视距离太远或接收器被遮挡太厉害，可用 USB 延伸线把接收器引出；

5. 为什么在电脑游戏中游戏手柄无法使用？

答: 请先在前戏 OPTION 选项中选择手设备操作，并设置好按键映射关系，若在游戏 OPTION 选项中找不到游戏设备，则该游戏仅支持键盘鼠标不支持手柄游戏。

6. 为什么手柄在手机无法使用？

答: 首先请确认一下手机是否是安卓系统的手机，是否支持 OTG 功能，如果支持是否已开启该功。

温馨提示:

1. 当手柄出现意外断线、电压保护等状况时，使得手柄出现不能连线，及连线无反应等死机状态时，需关闭电源开关3 秒后再重新开启；
2. 如有其他疑问请与厂商联系。
3. 不要把此产品置放在极度高温和潮湿的地方，放于干燥的地方
4. 儿童要在成年人的监护下使用。
5. 不要用酒精液体擦拭本产品的任何部分，请用软布和少量水对本产品进行清洁！

保修案例

根据三包规定，整机保修期为一年(自购买日期计算)

。在保修期内，因产品本身质量问题引起的故障，请顾客持保修卡正本和购机发票在指定的地点享受免费保修服务；

，不接受由于改装或加装其他功能，及自行拆卸后出现故障的机器，

此证不得涂改，否则作废每次维修时，由维修中心人员填写维修记录

此证书请顾客妥善保管，遗失不补！

游戏厅介绍

推荐使用智慧游戏厅、小鸡模拟器、小修模拟器、KO 等游戏模拟器，强烈建议在游戏平台下载游戏(网上直接下载的游戏会不兼容)，电脑电脑手机上同样需要下相对应的游戏模拟器以兼容游戏厅使用为例：

已经在网上下载游戏需要进行卸载，仅需在游戏平台内找相同游戏重新下载即可，只要你网游账号不变，您的装备、等级等是完全相同的。

产品保修卡

购买产品时，请认真填写此卡，并予以妥善保管。

用户档案	
用户姓名	
姓 别	
通讯地址	
邮 编	
联系电话	
购买地点	
购买日期	
品名及规格	
销售单号	
机身编号	
经销商签名	
用户签名	

经销商盖章处

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.