

正面

背面

Wireless Controller Instruction Manual

ENGLISH

About the Controller

The vibration function can be turned on or off from the menu that is displayed by pressing the PS button of the wireless controller.

Battery life and duration

- The battery has a limited life span. Battery duration will gradually decrease with repeated usage and age. Battery life also varies depending on the storage method, conditions of use and environmental factors.
- Charge in an environment where the temperature range is between 10°C – 30°C (50°F – 86°F). Charging may not be as effective when performed in other environments.
- When the wireless controller is not used for an extended period of time, it is recommended that you fully charge it at least once a year to help maintain battery functionality.

Use and handling precautions

- Avoid prolonged use of this product. Take a break at about 30 minute intervals.
- Stop using this unit immediately if you begin to feel tired or if you experience discomfort or pain in your hands or arms during use. If the condition persists, consult a doctor.
- This product is intended for use with the hands only.
- The vibration function of this product may aggravate injuries. Do not use the vibration function if you have any ailment or injury to the bones, joints, or muscles of your hands or arms.
- Do not expose the product to high temperatures, high humidity or direct sunlight.
- Do not allow the product to come into contact with liquids.
- Do not put heavy objects on the product.
- Do not throw or drop the product or subject it to strong physical shock.
- When using the motion sensor function, be cautious of the following points. If the controller hits a person or object, this may cause accidental injury or damage.
 - Before using, check that there is plenty of space around you.
 - When using the controller, grip it firmly to make sure it cannot slip out of your hand.
 - If using a controller that is connected to the PS3rm system with a USB cable, make sure there is enough space for the cable so that the cable will not hit a person or object. Also, take care to avoid pulling the cable out of the PS3T system while using the controller.

Exterior protection

Follow the instructions below to help prevent the product exterior from deteriorating or becoming discolored.

- Do not place any rubber or vinyl materials on the product exterior for an extended period of time.
- Use a soft, dry cloth to clean the product. Do not use solvents or other chemicals. Do not wipe with a chemically-treated cleaning cloth.

Specifications

Input power rating:	DC 5V, 500mA
Battery type:	Built-in rechargeable Lithium-Ion battery
Voltage:	DC 3.7V
Battery capacity:	610 mAh
Operating temperature:	5°C – 35°C (41°F – 95°F)
Mass:	Approx. 180 g (6.3 oz)


Design and specifications are subject to change without notice.

PS3 Mode

If the controller has not been connected to the current PS3 host or has been connected to other hosts, and you need to connect to the current host, you need to use a USB data cable to communicate with the PS3 host. In the process of communication, the program automatically carries out code, and then you can use Bluetooth for wireless communication. The gamepad connects to the PS3 host through USB data cable, and the gamepad connects to the PS3 host through cable. After the data cable is removed, the gamepad will automatically connect back to the PS3 host through Bluetooth.

Windows (PC) Mode

The handle can be connected to Windows (PC) through USB data cable when the device is off. After the connection is successful, the LED2 channel light in XINPUT mode will blink by default.



⚠ Precautions

1. Please do not store this product in humid or high temperature places;
2. Do not knock, beat, stick, puncture, or try to decompose this product, so as not to cause unnecessary damage to this product;
3. The built-in battery of this product, please do not throw it away with trash;
4. Avoid water or other liquids from entering the inside of the controller, which may affect the function of the controller;
5. Do not charge the controller near fire or other heat sources;
6. Non-professionals should not disassemble this product, otherwise it will not be covered by the after-sales warranty service;
7. Children should use this product under the supervision of adults.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.