


18-KEY RF REMOTE CONTROLLER(The Battery: 12V 23A)

Pull The Antenna As Long As Possible Before Using



New Upgraded Brightness Mode: Adjustable 5-level brightness (100%-25%), Not only adjust color brightness, but also can adjust lighting mode brightness.

New Upgraded Memory Function: Will stay at your lasting setting, while turn on again. Also can remember the dim level(Limited to turn on/off with remote, if power off more 5 minutes, turn on the light again, the light will keep 100% brightness).

10 Lighting Mode: M①: 7-Color Fade(no pink); M②:7-Color Slow Flash(no pink); M③:7-Color Breathe(no pink); M④:R G B W Fade; M⑤: R G B W Jump; M⑥:R G B Fade; M⑦:8-color Jump; M⑧:Red Fade+Jump; M⑨: Green Fade+Jump; M⑩:Blue Fade+Jump.

Auto Lighting Mode: 10 Lighting mode automatic cycle.

Timer Mode: Pre-setting the 2 hours turn on or make it turn off 4 hour or 6 hours automatically.

► **Note:** Press the time switch button, the green light will flash 3 times, which means the timer function is turned on, then setting the corresponding time to turn on or off,if the green light flashes 3 times again, which means the time setting successfully.

► What You Get

- 1* 3.2ft Wall Washer LED Light Bar; ●1* User Guide; ●1* 1.5m 3-prong plug extension cord;
- 1*Installation Tool Kit; ●1* 18-key RF Remote Controller;

► Gift Installation Tool Kit

- 1* 8mm Open-Ended Wrench; ●1*16mm Open-Ended Wrench; ●1*2.5*18*53 mm Allen Wrench;
- 1*4*21*57 mm Allen Wrench; ●1* Waterproof 3 Core Male Female Plug.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.