



USB
Battery level
Speaker icon



Power



Volume



Play/Pause



Power Input



Power Switch

WARNING: Do not use a power source that is not rated for use with this device. Do not use a power source that is not rated for use with this device. Do not use a power source that is not rated for use with this device.



Power Input



Speaker

DC 110-200V
50-60Hz