

Location: Stick it on the back of the device
SIZE: L50*H40mm

40mm

50mm

40mm

ALTEC
LANSING



800562
US

ITEM NO.: IMT7100
PRODUCT DESCRIPTION: Shockwave 200 Wireless Party Speaker
DC INPUT: 19V  1.5A
MID#3580420 TECH SUPPORT #: 1.855.292.4087
MADE IN CHINA
FCC ID: 2A623S225

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.
OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE .
AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE
RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE
UNDESIRABLE OPERATION.

DATE CODE: 04/2022

The diagram illustrates the rear panel of the Shockwave 200 Wireless Party Speaker. It features a vertical arrangement of controls and ports. At the top is a circular 'MIC LEVEL' control with a vertical slider and '+' and '-' volume indicators. Below this is a 'MIC' input jack. Further down is a '5V=1A' USB Type-A port. Below the USB port is a 'LINE IN' jack. At the bottom of the control section are a 'DC IN' jack, a battery status indicator (a battery icon with a lightning bolt), and a 'RESET' button. The bottom half of the device is dominated by a large, solid black rectangular area, which represents the speaker grille. The entire device is framed by a double-line border with rounded corners and four circular mounting points at the corners.