


产品说明书


按键位置



按键操作

- ▢ 长按减低音量/单击调至上一曲。
- ⊕ 长按增加音量/单击调至下一曲。
- ⏸ 单击暂停/单击播放
蓝牙模式:长按进入TWS串联
FM模式:三击自动收台（插上充电线可做辅助天线）
来电时单击接听来电/挂断来电；
- Ⓜ 功能切换:蓝牙/MP3模式/收音模式。
- ⏻ 长按开机和关机;双击:LED灯开关

插口功能



插口功能

- ① TF卡槽，可以直接插TF卡播放音乐。
- ② 音频接口，可以连接电脑或者手机进行播放。
- ③ U盘插口，可以直接插上U盘播放音乐;插上USB线可以做充电宝充电
- ④ 充电接口，配置数据线可以进行充电。

配对步骤

连接蓝牙设备

- 1、单个连接: 开机蓝灯闪烁进入配对状态，打开手机搜索音箱型号,点击连接即可。
- 2、双个连接: 两个音箱同时开机，长按任意一个音箱播放键，听到语音提示即为串联成功，然后手机搜索音箱型号（只显示一台设备），点击连接即可。

连接手机/电脑


- 1、长按开机，断开所有手机蓝牙功能，直接插上AUX音频线，听到语音提示后即可播放音乐。

产品参数

产品名称	蓝牙音箱	TWS串联	支持双个连接
蓝牙版本	5.0	接 口	3.5mm接口
输出功率	8W*2	喇 叭	52mm
防 水	IPX7防水	电池容量	3000毫安
失 真 率	<1%	支持格式	MP3/WAV
蓝牙范围	10-30米	产品尺寸	20.5*6.7*8.5cm

Product Manual


KEYS



FEATURES

- ▢ Press and hold to decrease the volume / click to tune to the previous song.
- ⊕ Press and hold to increase volume / click to go to the next song.
- ⏸ Click pause / click play
Bluetooth mode: long press to enter TWS series connection
FM mode: three strike automatic station closing (plug in the charging line can be used as auxiliary antenna)
When calling, click answer / end call;
- Ⓜ Function switch: Bluetooth / MP3 mode / radio mode.
- ⏻ long press power on and turn off.Double click: LED light switch

SOCKET



FEATURES

- 1. TF card slot, you can directly insert TF card to play music.
- 2. Audio interface, can be connected to the computer or mobile phone to play.
- 3. U disk plug, you can directly plug in the U disk to play music; plug in the USB cable can be used to charge the power bank
- 4. Charging interface and data cable can be configured for charging.

PAIRING STEP

Connect a Bluetooth device

- 1. Single connection: turn on the phone and the blue light flashes to enter the pairing state. Open the mobile phone to search for the speaker model, and click Connect.
- 2. Double connection: when two speakers are turned on at the same time, press and hold any speaker play key. If you hear the voice prompt, the series connection is successful. Then the phone searches for the speaker model (only one device is displayed), and then click Connect.

Connect phone/computer

- 1. Press and hold the phone to turn off the Bluetooth function of all mobile phones, plug in the AUX audio cable directly, and play the music after hearing the voice prompt.

PARAMETER

Product	Bluetooth Speaker	TWS	Two connections
Bluetooth version	5.0	Interface	3.5mm
Output Power	8W*2	Lamb	52mm
Water protection	IPX7 waterproof	Battery	3000 mAh
Distortion	<1%	Support format	MP3/WAV
Bluetooth range	10-30meters	Product Size	20.5*6.7*8.5cm

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.