

I152 SMART WATCH USER MANUAL

PLEASE READ THE USER MANUAL BEFORE USE

English—1	Français—9	Deutsch—18	Italiano—27	Español—35	Nederlands—43	日本語—52							
Product Overview  Long press 5 seconds turn on/off, short press back. Return button APP download ①Scan "FitCloudPro" in the APP store (Apple store/Google store). ②Scan QR code to download.  User tips When install the app, it will be prompted to access the phone permissions. Please allow all permission: ① Bluetooth ② Notification (including alerts /sounds/ icon badges) ③ Local network in the "FitCloudPro" app. 1 2. On the watch face page, you can go to the following page by touching the finger from top to bottom. Do not disturb: you can turn on or off do not disturb function. Brightness: you can adjust the brightness. Settings: you can set stopwatch, alarm clock, timer, brightness, phone switch, call settings, vibration, speaker mode, factory reset, shutdown, about APP download. Vibration setting/Brightness adjustment/Bracelet reset Down slide screen will display the interface.(As in the first picture) 1. Click brightness adjustment, you can adjust the screen brightness you need according to the usage. 2. If you need to use the watch with another phone, you need to reset the watch. 3. Click Restore factory settings, the watch will be restored to the initial state and restart automatically, at this time all data on the wristband is cleared. 3. Click the "SYSTEM" icon, you can check the version information, Bluetooth MAC address, battery percentage display and Bluetooth connection status.	1. Switch watch on: long press the side button for 3-5 seconds 2. Please turn on the phone's Bluetooth and location service and make sure the watch is not binded to other devices. Open the FitCloudPro APP on your mobile phone. Set your personal information enter the device interface. Click on "Bind Device" Right-side on the main dial interface of watch to view MAC address. You can use the MAC address from the device list to determine your device. The device name and the corresponding MAC address are paired. Device is successfully connected. Step 1: Open "FitCloudPro APP" -- "OK, Allow" -- "Add A DEVICE" -- Find I152 and choose -- "Pair" -- "Allow" -- Done  Bluetooth MY DEVICES I152 Connected 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212 213 214 215 216 217 218 219 220 221 222 223 224 225 226 227 228 229 230 231 232 233 234 235 236 237 238 239 240 241 242 243 244 245 246 247 248 249 250 251 252 253 254 255 256 257 258 259 260 261 262 263 264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279 280 281 282 283 284 285 286 287 288 289 290 291 292 293 294 295 296 297 298 299 300 301 302 303 304 305 306 307 308 309 310 311 312 313 314 315 316 317 318 319 320 321 322 323 324 325 326 327 328 329 330 331 332 333 334 335 336 337 338 339 340 341 342 343 344 345 346 347 348 349 350 351 352 353 354 355 356 357 358 359 360 361 362 363 364 365 366 367 368 369 370 371 372 373 374 375 376 377 378 379 380 381 382 383 384 385 386 387 388 389 390 391 392 393 394 395 396 397 398 399 400 401 402 403 404 405 406 407 408 409 410 411 412 413 414 415 416 417 418 419 420 421 422 423 424 425 426 427 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462 463 464 465 466 467 468 469 470 471 472 473 474 475 476 477 478 479 480 481 482 483 484 485 486 487 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503 504 505 506 507 508 509 510 511 512 513 514 515 516 517 518 519 520 521 522 523 524 525 526 527 528 529 530 531 532 533 534 535 536 537 538 539 540 541 542 543 544 545 546 547 548 549 550 551 552 553 554 555 556 557 558 559 560 561 562 563 564 565 566 567 568 569 570 571 572 573 574 575 576 577 578 579 580 581 582 583 584 585 586 587 588 589 590 591 592 593 594 595 596 597 598 599 600 601 602 603 604 605 606 607 608 609 610 611 612 613 614 615 616 617 618 619 620 621 622 623 624 625 626 627 628 629 630 631 632 633 634 635 636 637 638 639 640 641 642 643 644 645 646 647 648 649 650 651 652 653 654 655 656 657 658 659 660 661 662 663 664 665 666 667 668 669 670 671 672 673 674 675 676 677 678 679 680 681 682 683 684 685 686 687 688 689 690 691 692 693 694 695 696 697 698 699 700 701 702 703 704 705 706 707 708 709 710 711 712 713 714 715 716 717 718 719 720 721 722 723 724 725 726 727 728 729 730 731 732 733 734 735 736 737 738 739 740 741 742 743 744 745 746 747 748 749 750 751 752 753 754 755 756 757 758 759 760 761 762 763 764 765 766 767 768 769 770 771 772 773 774 775 776 777 778 779 780 781 782 783 784 785 786 787 788 789 790 791 792 793 794 795 796 797 798 799 800 801 802 803 804 805 806 807 808 809 810 811 812 813 814 815 816 817 818 819 820 821 822 823 824 825 826 827 828 829 830 831 832 833 834 835 836 837 838 839 840 841 842 843 844 845 846 847 848 849 850 851 852 853 854 855 856 857 858 859 860 861 862 863 864 865 866 867 868 869 870 871 872 873 874 875 876 877 878 879 880 881 882 883 884 885 886 887 888 889 890 891 892 893 894 895 896 897 898 899 900 901 902 903 904 905 906 907 908 909 910 911 912 913 914 915 916 917 918 919 920 921 922 923 924 925 926 927 928 929 930 931 932 933 934 935 936 937 938 939 940 941 942 943 944 945 946 947 948 949 950 951 952 953 954 955 956 957 958 959 960 961 962 963 964 965 966 967 968 969 970 971 972 973 974 975 976 977 978 979 980 981 982 983 984 985 986 987 988 989 990 991 992 993 994 995 996 997 998 999 1000	Personal Profile Set personal information when you login. My date-personal date. Gender - height - weight - age. Call reminder Keep connected, if the call alert function is enabled, the wristband will vibrate and display the name or number of the caller when the call Notifications Keep connected, if this function is enabled, the bracelet will vibrate when there are messages such as Wechat, Facebook, Twitter and so on. (Give the APP access to system permission). Alarms: set the alarms. Shutter: this function will control your mobile phone to take photos from watch. Favorite Contacts: you can add your mobile phone contacts to your watch. Others: you can set Find a bracelet, Time format, Sedentary reminder, Raise your wrist to brighten the screen, drink water reminder. Upgrade: upgrade the watch software when necessary. Note: 1: When using GPS under sports mode, please turn on location services for phone and device, the watch does not have GPS function, you can open the GPS function in the app. 2: Each time you open the App, the watch will automatically connect to the phone. After right-slide of the main interface of watch to enter the MAC address interface, the Bluetooth icon will appear, indicating that Bluetooth is connected. If there is no Bluetooth icon, Bluetooth is not connected. Watch function interface 1. Watch face: long press the watch face button, it can be changed to 4 different watch faces, showed Dates, Time etc. More default watch faces: go to App "FitCloudPro" -- Watch faces -- Discover more faces -- Choose dial -- Download immediately -- Done. Then, you can see the dial will be showed in your watch. 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	Apps Functions and Settings Main interface / dial Switch the customized dial through the APP Discover more dials through APP APP device page dial selection find more dials click on your favorite dial picture click to download new dialface do not leave the download page during download. 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	Présentation du produit Appuyez longuement pendant 5 secondes pour allumer/éteindre, appuyez brièvement pour revenir. Bouton de retour  Téléchargement de l'APP ① Recherchez le "FitCloudPro" dans l'App Store (Apple store/Google store). ② Scannez le code QR pour télécharger.  Conseils utilisateur Lors de l'installation de l'application, il vous sera demandé d'accéder aux autorisations du téléphone. Veuillez autoriser toutes les autorisations : ① Bluetooth ② Notifications (y compris alertes / sons / badges d'icône) ③ Réseau local dans l'application "FitCloudPro". 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	1. Allumer la montre : appuyez longuement sur le bouton latéral pendant 3 à 5 secondes. 2. Veuillez activer le Bluetooth et le service de localisation de votre téléphone : assurez-vous que la montre n'est pas associée à un autre appareil. Ouvrez l'application FitCloudPro sur votre téléphone mobile : réinitialisez vos informations personnelles, entrez dans l'interface de l'appareil. Cliquez sur "Lier l'appareil". Faites glisser vers la droite sur l'interface principale du cadran de la montre pour voir l'adresse MAC. Vous pouvez utiliser l'adresse MAC de la liste des appareils pour identifier votre appareil. Le nom de l'appareil et l'adresse MAC correspondante sont apparus. L'appareil est connecté avec succès. Étape 1 : Ouvrez l'application "FitCloudPro" -- OK, Autoriser -- Ajuster un appareil : Trouvez I152 et choisissez -- Associer -- Associer -- Terminé. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	Paramètres de vibration / Ajustement de la luminosité / Réinitialisation du bracelet 1. Cliquez sur l'ajustement de la luminosité, vous pouvez ajuster la luminosité de l'écran selon vos besoins. 2. Si vous avez besoin d'utiliser la montre avec un autre téléphone, vous devez réinitialiser la montre. Cliquez sur "Restaurer les paramètres d'usine", la montre sera réinitialisée à son état initial et redémarrera automatiquement. À ce moment, toutes les données sur le bracelet seront effacées. 3. Cliquez sur l'icône "SYSTEME", vous pouvez vérifier les informations de la version, l'adresse MAC Bluetooth, l'affichage du pourcentage de batterie et l'état de la connexion Bluetooth. Pourquoi la montre ne peut-elle pas recevoir la notification de message ? Étant donné que les téléphones Android ferment automatiquement les applications qui ne sont pas utilisées fréquemment, cela peut entraîner la perte de connexion de la montre et empêcher la notification de message. 1. Assurez-vous d'activer les notifications de message dans les paramètres de FitCloudPro. 2. Assurez-vous que les notifications de message peuvent être 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	Produktübersicht 5 Sekunden langes Drücken schaltet ein/aus, kurzes Drücken zurück. Zurück-Taste  App-Download ① Suchen Sie "FitCloudPro" im App Store (Apple store/Google store). ② Scannen Sie den QR-Code zum Herunterladen.  Nutzerhinweise Bei der Installation der App wird um Zugriff auf die Telefonberechtigungen gebeten. Bitte erlauben Sie alle Berechtigungen: ① Bluetooth ② Benachrichtigungen (einschließlich Alarme / Töne / App-Symbole) 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	Benachrichtigungen Bleiben Sie verbunden, wenn diese Funktion aktiviert ist, wird das Armband vibrieren, wenn Nachrichten wie WeChat, Facebook, Twitter usw. empfangen. (Erlauben Sie der Uhr Zugriff auf Systemberechtigungen). Favoritenkontakte: Sie können Ihre Mobiltelefonkontakte zu Ihrer Uhr hinzufügen. Andere: Sie können Armband finden*, Zeitformat, Stille-Zeichen, Handgelenk anheben, um den Bildschirm auszuheilen, Erinnerung an Trinken von Wasser einstellen, Upgrade: Aktualisieren Sie die Uhr-Software, wenn nötig. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	heifen Quellen oder in der Sauna tragen? Die Wassertemperatur im Bad ist relativ hoch, was zu einer großen Menge an Wasserdampf führt. Wasserdampf ist ein Gas und seine Moleküle sind klein, sodass er leicht durch die Spalten des Gehäuses in die Uhr eindringen kann. Wenn die Temperatur sinkt, kondensiert der Dampf wieder in flüssige Form. Wassertropfen können leicht einen Kurzschluss im Inneren der Uhr verursachen, die Schaltkreise beschädigen und die Uhr selbst zerstören. Besondere Beachtung: Für weitere Fragen zur Nutzung der Uhr können detaillierte Antworten im Vorschlags-Feedback der App gefunden werden. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	Panoramica del prodotto Premere a lungo per 5 secondi per accendere/spegnere, brevemente per tornare indietro. Pulsante di ritorno  Download dell'APP ① Cercare "FitCloudPro" nell'App Store (Apple store/Google store). ② Scansionare il codice QR per scaricare.  Consigli per l'utente Quando installi l'app, verrà chiesto di accedere alle autorizzazioni del telefono. Si prega di consentire tutte le autorizzazioni: ① Bluetooth ② Notifiche (inclusi avvisi /suoni /icone) ③ Rete locale nell'app "FitCloudPro". 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	Conseils pour une première utilisation : La première fois que vous utilisez la montre, veuillez vous assurer que la batterie est complètement chargée. ① Ouvrez la boîte, utilisez le câble de charge I152, puis insérez le USB dans votre ordinateur portable ou tout port USB avec 5V pour charger la montre avant de l'utiliser, afin de garantir que la montre est entièrement chargée. Le temps, il will cause the watch connection to drop and no longer push the message. 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	Local network in the "FitCloudPro" app. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100	Local network in the "FitCloudPro" app. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48

