


# USER MANUAL

For more details,  
please consult online  
customer service.



## Notice

Please read this user manual carefully before use.



## Warranty Card

Client Name: \_\_\_\_\_ Client ID: \_\_\_\_\_

Client Phone Number: \_\_\_\_\_

Purchase shop: \_\_\_\_\_

Return Address: \_\_\_\_\_

Fault description:  
(For quick repair, please describe the problem in details.)

FC CE RoHS  

封面

封底

## Safety Tips

For the best viewing effect, please use the projector in dark room.

- Do not install this projector in the area which directly blown by the air conditioner, to prevent projector failed caused by water vapor condensation or excessive temperature.
- Ensure that the environment is ventilated to prevent overheating caused by heats build-up.
- Prevent foreign objects from falling into the machine. Never insert any metal objects into the machine. If foreign objects fall into the machine accidentally, please power off immediately and seek professional assistance.
- Do not place any liquid on the machine to avoid leakage.
- Avoid violent vibrations when transporting. Please protect the lens from wear.
- Do not touch the vents when using the projector to avoid burns due to excessive temperature.
- Do not look directly at the lens while the projector is running to prevent eye injury.
- Please clean the filter regularly to prevent malfunction caused by clogging.

|                                                                                                                                                         |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Notice</b> ⚠</p> <p>Do not open the case of projector to prevent electric shock. Please seek professional assistance for maintenance matters.</p> |
| <p><b>Warn</b> ⚠</p> <p>Do not touch! The inside of the projector contains uninsulated voltage.</p>                                                     |
| <p><b>Warn</b> ⚠</p> <p>Do not install the projector around flammable objects to prevent fire.</p>                                                      |

1

o ensure the performance and stability of the projector, please place it horizontally and leave a space of about 0cm from the projector and the wall.

Do not install in places with poor ventilation.

Do not install in high temperature or humid places.

Do not block the vents.

Do not install in dust or smoky places.

| Item                  |          | Specification          |
|-----------------------|----------|------------------------|
| Product               |          | X3 MAX                 |
| Resolution            |          | 1280*720               |
| Projection Technology |          | LCD Display            |
| Lamp Type             |          | LED Lamp               |
| Battery Type          |          | Lithium-ion battery    |
| Capacity              |          | 15Ah                   |
| Charging Time         |          | 4-5H                   |
| Interface             | HD       | HD IN*1                |
|                       | USB      | USB 2.0*1              |
|                       | Earphone | 3.5mm audio port       |
|                       | LAN      | LAN IN*1               |
|                       | Type-C   | USB-C port             |
| Environment           |          |                        |
| Power Input           |          | DC 12V-6A              |
| Operating Temperature |          | 0 ~ 30°C               |
| Storage Temperature   |          | -20 ~ 65°C             |
| Operating Humidity    |          | 0 ~ 90% Non-condensing |

1

Package Contents



Projector



Adapter



Remote control



HD cable



User manual

1. IR Remote Sensor  
2. Projection Lens  
3. Dust Filter  
4. LAN Port  
5. IR Remote Sensor  
6. 3.5mm Audio Port  
7. USB Port  
8. HD Port  
9. Type C Port  
10. DC Port  
11. Vent  
12. battery

1. Power On  
2. Signal Source  
3. Ok(Enter)  
4. Down  
5. Left  
6. Right  
7. Up  
8. Menu  
9. Return  
10. Projector Foot Pad  
11. Projector Mounting Hole  
12. Name Tag Label

**Power Supply Modes:**

- 1.Rechargeable Battery Power Supply
- 2.Adapter Power Cord Power Supply
- 3.AC Power Cord Power Supply

**Note:**  
If the product is not used for a long time , it is recommended to put the projector separately from the battery.

Diagram illustrating the layout of the remote control buttons and their functions:

- Power ON/OFF
- Navigation key
- Return
- Home
- VOL -
- Focus+
- Voice Key
- Input Source
- Menu
- Mouse Mode
- VOL +
- Focus+
- Mute

**Power Connection**

**Way1**  
Battery-powered

**Way2**  
Adapter power supply

**Power On/Power Off**

Press the power button to boot up projector.

Aim the remote control at the remote sensor part of the projector.

**Way1:**  
Power on/off by the button on projector.

**Way2:**  
Power on/off by remote control.

- 1 Language Select**

Click [Settings]>[Device Preferences]>[Language], then choose the language you want.
- 2 Date & Time**

Click [Settings]>[Device Preferences]>[Date & Time], then you can select automatic date & time, or turn off automation and use manual adjustments.
- 3 Network & Internet**

Click [Settings]>[Network & Internet], then choose the wifi option and enter passwords to connect.
- 4 FOTA Update**

Click [FOTA Update], follow the on – screen instructions to upgrade the software version.
- 5 Bluetooth Connection**

Click [Settings]>[Bluetooth] and search for the corresponding Bluetooth device in the projector, and then click on pair.

## 1 For iOS Devices:

1. Make sure the iOS device and the projector are connected to the same network.
2. Open the [iOS Cast] option on the projector's interface.
3. On the iOS device, open the Control Center and enable the screen mirroring function.
4. Search for the corresponding device model.
5. Connect to the corresponding model, and start screen mirroring.

## 2 For Android Devices:

1. Connect your mobile device to a wireless Wi-Fi network.
2. To open [Android Miracast] on the projector interface.
3. On your phone, tap [Setting], select [Connection & Sharing], and finally enable the [Cast] function. Connect to the corresponding device model to enable screen mirroring functionality.

Notes:

- Due to variations in smartphone models, the setup steps may differ. Please follow the mirroring screen instructions that apply to your specific settings.

- 1 Connect your device to a network.
- 2 To open [Android Miracast] on the projector interface.
- 3 Press the [Windows] key and the [P] key simultaneously on the keyboard. Then, go to [More Display Settings], select [Multiple Displays] in the scale and layout section, and finally choose connect to a [Wireless Display] to connect to the corresponding device model to enable screen mirroring functionality.

If the **Connect to a wireless display** option is not listed, this means your device or video card does not support Miracast.

---

✦ Certain content may be unavailable to be casted due to copyright restrictions. In this case, you can stream those content via the same app installed in your projector.

- 1 Unable to Boot Up**
  - \* Check if the power cord is connected properly, and if the power light is on. Try to unplug and plug the power if the projector still can not boot up.
  - \* Check if the battery is low on power.
- 2 Remote Control is Inensitive or Unresponsive**
  - Do not cover IR receiver.
  - In the infrared mode, make sure remote points at IR receiver directly. There is an obstacle between the remote control and the projector.
  - The batteries are out of power or the battery is not installed correctly. Paste the Bluetooth remote control and make sure is working within 5 meters.
- 3 Why is there no display when I connect HD port?**
  - \* Check if the interface is securely connected.
  - The devices may be incompatible.
- 4 Blurry Display**
  - \* The lens is not clean.
  - \* The projection lens is not correctly focused.
  - \* The environment is too bright.
- 5 Screen Freeze**
  - \* Please remove the projector to test again. If the screen still freeze, please turn off for 10 minutes and turn on again.

**If you have any other problems or suggestions, please contact our online services to help you immediately.**

Open filter from here

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications; however, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment complies with FCC radiation exposure limits set forth for uncontrolled environments. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.