


尺寸：70X100mm
材质：105g双铜纸
工艺：风琴折页 单黑印刷

USER
MANUAL

For more details,
please consult online
customer service.



Notice

Please read this user manual carefully before use.

Safety Tips

For the best viewing effect, please use the projector in dark room.

1. Do not install this projector in the area which directly blown by the air conditioner, to prevent projector failed caused by water vapor condensation or excessive temperature.

2. Ensure that the environment is ventilated to prevent overheat caused by heats build-up.

3. Prevent foreign objects from falling into the machine. Never insert any metal objects into the machine. If foreign objects fall into the machine accidentally, please power off immediately and seek professional assistance.

4. Do not place any liquid on the machine to avoid leakage.

5. Avoid violent vibrations when transporting. Please protect the lens from wear.

6. Do not touch the vents when using the projector to avoid burns due to excessive temperature.

7. Do not look directly at the lens while the projector is running to prevent eye injury.

8. Please clean the filter regularly to prevent malfunction caused by clogging.

Notice

Do not open the case of projector to prevent electric shock. Please seek professional assistance for maintenance matters.

Warn

Do not touch! The inside of the projector contains uninsulated voltage.

Warn

Do not install the projector around flammable objects to prevent fire.

Safety Tips

To ensure the performance and stability of the projector, please place it horizontally and leave a space of about 30cm between the projector and the wall.

Do not install in places with poor ventilation.

Do not install in high temperature or humid places.

Do not block the vents.

Do not install in dust or smoky places.

Specifications

Item	Specification	
Product	X6	
Native Resolution	1920X1080	
Projection Technology	LCD Display	
Lamp Type	LED Lamp	
Interface	HD	HD IN*1
	USB	USB 2.0 * 2
	Earphone	3.5mm audio port
Environment		
Power Input	AC 110~240V 50-60HZ	
Operating Temperature	0 ~ 30℃	
Storage Temperature	-20 ~ 65℃	
Operating Humidity	0 ~ 90% Non-condensing	

1 Package Contents

Projector

Power cord

Remote control

HD cable

Heightening screw

User manual

Bracket

Projector Introduction

1.Projection Lens

2.IR Remote Sensor

3.Dust Filter

4.3.5mm Audio Port

5.USB Port

6.USB Port

7.HD Port

8.Bracket

9.AC Port

10.Vent

1.Power On

2.Return

3.Signal Source

4.Down

5.Right

6.Up

7.Left

8.Ok(Enter)

9.Projector Foot Pad

10.Dust Removal Hole

Remote Control Introduction

Power ON/OFF

Navigation key

Return

Home

VOL -

Focus-

Voice Key

Input Source

Menu

Mouse Mode

VOL +

Focus+

Mute

Electric Focus

Press Focus+/- to adjust the image sharpness.

F-

F+

Q&A

1 Unable to Boot Up

* Check if the power cord is connected properly, and if the power light is on.Try to unplug and plug the power if the projector still can not boot up.

2 Remote Controller is Insensitive or Unresponsive

* Do not cover IR receiver.

* In the infrared mode, make sure remote points at IR receiver directly.

* There is an obstacle between the remote control and the projector.

* The batteries are out of power or the battery is not installed correctly

3 Why is there no display when I connect HD port?

*Check if the interface is securely connected.

*The devices may be incompatible.

4 Blurry Display

* The lens is not clean.

* The projection lens is not correctly focused.

* The environment is too bright.

5 Screen Freeze

* Please reboot the projector to test again. If the screen still freeze, please turn off for 10 minutes and turn on again.

✎ If you have any questions or suggestions, please contact our online customer service.

Maintenance Suggestion

Open filter from here

Notice

To make this projector work longer, we recommend you to follow the suggestions.

1.Before cleaning the projector, turn off the projector, then turn off the main power and unplug it from the outlet.

2.Clean the filter regularly every month to prevent clogging.

3. Make sure to close the projector off once you finished using it.

4.Make sure not to use it continuously for more than 6 hours.

Warranty Card

Client Name: _____ Client ID: _____

Client Phone Number: _____

Purchase shop: _____

Return Address: _____

Fault description:
(For quick repair, please describe the problem in details.)

FC CE RoHS

6

7

8

Electric Focus

Press Focus+/- to adjust the image sharpness.

F-

F+

Q&A

1 Unable to Boot Up

* Check if the power cord is connected properly, and if the power light is on.Try to unplug and plug the power if the projector still can not boot up.

2 Remote Controller is Insensitive or Unresponsive

* Do not cover IR receiver.

* In the infrared mode, make sure remote points at IR receiver directly.

* There is an obstacle between the remote control and the projector.

* The batteries are out of power or the battery is not installed correctly

3 Why is there no display when I connect HD port?

*Check if the interface is securely connected.

*The devices may be incompatible.

4 Blurry Display

* The lens is not clean.

* The projection lens is not correctly focused.

* The environment is too bright.

5 Screen Freeze

* Please reboot the projector to test again. If the screen still freeze, please turn off for 10 minutes and turn on again.

✎ If you have any questions or suggestions, please contact our online customer service.

Maintenance Suggestion

Open filter from here

Notice

To make this projector work longer, we recommend you to follow the suggestions.

1.Before cleaning the projector, turn off the projector, then turn off the main power and unplug it from the outlet.

2.Clean the filter regularly every month to prevent clogging.

3. Make sure to close the projector off once you finished using it.

4.Make sure not to use it continuously for more than 6 hours.

Warranty Card

Client Name: _____ Client ID: _____

Client Phone Number: _____

Purchase shop: _____

Return Address: _____

Fault description:
(For quick repair, please describe the problem in details.)

FC CE RoHS

6

7

8

System Initial Setup

1 Language Select

Click [Settings]>[Device Preferences]>[Language], then choose the language you want.

2 Date & Time

Click [Settings]>[Device Preferences]>[Date & Time], then you can select automatic date & time, or turn off automation and use manual adjustments.

3 Network & Internet

Click [Settings]>[Network & Internet], then choose the wifi option and enter passwords to connect.

4 FOTA Update

Click [FOTA Update], follow the on – screen instructions to upgrade the software version.

5 Bluetooth Connection

Click [Settings]>[Bluetooth] and search for the corresponding Bluetooth device in the projector, and then click on pair.

Screen Mirroring

You can mirror the screen of your smartphone/tablet/computer onto the projector screen.

1 For iOS Devices:

①Make sure the iOS device and the projector are connected to the same network.

②Open the [iOS Cast] option on the projector’s interface.

③On the iOS device, open the Control Center and enable the screen mirroring function.

④Search for the corresponding device model.

⑤Connect to the corresponding model. and start screen mirroring.

2 For Android Devices:

①Connect your mobile device to a wireless Wi-Fi network.

②To open [Android Miracast] on the projector interface.

③On your phone, tap [Setting], select [Connection & Sharing], and finally enable the [Cast] function. Connect to the corresponding device model to enable screen mirroring functionality.

Note:

Due to variations in smartphone models, the setup steps may differ. Please follow the mirroring screen instructions that apply to your specific settings.

Screen Mirroring

3 For Windows Laptop/PC (Win 8.1/10/11)

①Connect your device to a network.

②To open [Android Miracast] on the projector interface.

③Press the [Windows] key and the [P] key simultaneously on the keyboard. Then, go to [More Display Settings], select [Multiple Displays] in the scale and layout section, and finally choose connect to a [Wireless Display] to connect to the corresponding device model to enable screen mirroring functionality.

⚠If the Connect to a wireless display option is not listed, this means your device or video card does not support Miracast.

⚡ Certain content may be unavailable to be casted due to copyright restrictions. In this case, you can stream those content via the same app installed in your projector.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.