


Instructions

Model name:BL-RGB500

Operate on cable:

- 1.Long press: power off
- 2.Short press: on/mode switch



Bluetooth version:

Please scan the QR code to download the app



Warning:

- 1.The light belt should not be bent or twisted too much
- 2.Once installed, light up red, green, blue, and white. Check whether it is normal.if there is color abnormality, or flashing, please discard immediately, contactcustomer service to replace the new product.
- 3.After instaling the light belt, after lighting up the white light for 1 minute, touchthe whole lamp belt to check if there is abnormal fever (hot touch) . If abnormalfever is found, discard it and do not use it.
- 4.Please stop using and contact customer service for replacement if abnormalighting is found during daily use.

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.


This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- **Reorient or relocate the receiving antenna.**
- **Increase the separation between the equipment and receiver.**
- **Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- **Consult the dealer or an experienced radio/TV technician for help.**

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body



Model name:BL-RC01
Remote Control Description:



Attention to use:
1.Please remove the insulating plastic sheet of the battery before use
2.If the battery fails, please replace it as shown in the picture

