

INSTRUCTION MANUAL OF DRIFT RACING

Thank you for using our products. In order to get a better understanding of this product, Please read the following instructions carefully before using them, which will bring you a different sense of operatina experience.

Attention

- Electric control product: This product is suitable for 6 years old and above. It is assembled / charged by adults and then played by children.
- Please use the product under the supervision of adults. Please do not dismantle or modify the product without authorization. Any modification may cause the product to be unable to be used normally.


Precautions for Use

1. 1X3.7V chargeable lithium battery is required in this R/C car, 2X1.5V "AA" non-chargeable batteries are required in the transmitter.
2. The removal and loading of batteries should be carried out correctly as the +/- polarity and voltage shown inside the battery compartment of this toy.
3. Non-chargeable batteries are not to be charged.
4. Chargeable batteries are to be charged under the supervision of the adult.
5. Chargeable batteries are to be removed from this toy before charging.
6. Different types of batteries or old and new batteries can not be mixed.
7. Batteries used in the car body requires only the ones made from the original factory and original usb line included should be used to charge the car body.
8. The exhausted battery should be removed from this toy. If not used for a long time, please remove the battery from the toy.
9. The power terminals are not to be short-circuited.
10. Use a screwdriver to unscrew the screw on the battery cover of the transmitter. Load the battery as per the correct "+/-" polarity. Use a screwdriver to unscrew the screw on the battery cover of the chassis and connect the plug wire of the battery to the power line of the car body as per the correct "+/-" polarity.
11. Maintenance: This product is composed of plastic, hardware and electronic components. Regularly inspect the wires, plugs, casing and other components for defects. If any defects are found, please stop using until they are fully repaired.

Description of 2.4G Auto Decoding


1. Load the batteries into the transmitter, and turn the switch to the "ON" position, the indicator will be flashing, switch on the power of the transmitter and enter into the connected state. When it is successfully connected , the indicator on the transmitter will be OFF and the indicator of the R/C car will appear eternal bright "ON". Note: If it can not be connected successfully, please repeat the above operation.
2. Each transmitter can only be connected to one R/C car. Once it is successfully connected, each car will not interfere with each other. Note: When more cars are used in the same time, you can open the connection one by one.
3. When the transmitter fails to make decoding, it will enter into sleep after 45 seconds.
4. When needs to make decoding with other transmitters or R/C cars of the same models, it requires to remove the batteries in the transmitter and switch off the power of the R/C car before re-decoding.

Description to the Functions of Remote Control




How to Recharge

1. This is a new 3.7V battery and it needs to be charged before using.
2. First of all, please connect the wire of the battery to the plug of the charger as per the correct "+/-" polarity and then plug the charger into the socket. (Note: Do not use a fast charger for charging so as to avoid getting burnt the USB charging cable and battery.)
3. It takes about 2 to 3 hours to charge the battery full. The charging plug is equipped with a charging indicator. When it is under charging, the red indicator will be eternally bright "ON". When it is fully charged, the indicator will be "OFF". Please do not overcharge it as excessive charging will not increase the battery volume.
4. Check regularly the toys and batteries as well as the wires and plugs of the charging wires. In case these parts are damaged, these parts should be stopped using immediately until they are repaired or replaced.



How to Install Batteries


1. Remote controller
 - (1) Open the battery cover of the transmitter and load 2X1.5V "AA" battery as the "+/-" polarity shown in the battery compartment of the transmitter.
 - (2) Close the battery cover and well lock the screws.
2. Remote control car
 - (1) Open the battery cover of the chassis, please connect the chargeable battery with the power socket and load it into the battery compartment of the chassis.
 - (2) Close the battery cover and well lock the screws.



Operations of Remote Control and Cars

Operate the "Forward / Backward" trigger, the R/C car Forward / Backward.

Operate the "Turn left / Turn right" knob, the R/C car Turn left / Turn right.



Press "Light switch" key to control the light switch.

Press "Low speed mode" key, low speed is defaulted when switched on, shortly press to switch into low speed mode.

Press "High speed mode" key, shortly press to switch into high speed mode.



Instructions

The toy battery charger should be checked before use to prevent damage to wires and other components. If there is damage, it must be repaired before use.

General Fault Handling

Symptoms	Fault cause	Treatment method
The vehicle cannot be operated	1. The remote control is not connected or the R/C car switch is not on. 2. The battery is not properly installed. 3. The rechargeable battery is weak.	1. Reopen the R/C car and remote control switch, and reconnect the remote control. 2. Properly load the battery into the remote control and the R/C car. 3. The car battery is charged.
The vehicle is not controlled and the distance is close by remote control	1. Remote control or car battery, lack of electricity. 2. There may be a source of disturbance near the site.	1. Replace the battery in your remote control or recharge your car battery. 2. Replace the site.
Abnormal protection	When the function of the R/C car is hindered by external forces or the power is insufficient, circuit battery short circuit.	Re-turn on the power switch or take out the battery and reload it after it is powered off.

To consumers

1. When playing this R/C car indoor, please be careful not to damage the furniture or glass.
2. Please play outdoor in a safe place. Do not play this R/C car on the road or in crowds to avoid danger.
3. When playing this R/C car outdoor and hearing thunder, you should immediately stop playing.
4. When the wheels are rotating, please do not reach your hands close to avoid injury and do not get the hairs or clothes caught into the wheel.
5. Do not drive the R/C car towards people.
6. Do not litter or collide the R/C car.
7. When placing the R/C car, please stay away from fire source and high temperature.
8. Complex electronic circuits and a large number of components are applied on this R/C car. Please do not disassemble or re-equip the circuit board at will.
9. When the R/C car is covered with soil and dust after playing, it should be gently wiped with a damp cloth.
10. Don't put the R/C car in water, it will damage the electronic components.

WARNING: The contained widgets are at risk of suffocation and are not suitable for children aged 3 and under to play with. Adults must be present when using them for supervision and guidance. This manual contains important information, which cannot be discarded for inquiry.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.