


Functions


● Connect to 4G network

To use 4G internet, please refer to following steps:

1. Turn the machine off.
2. The the SIM card slot may differ due to different models. Please refer to below pictures:



A: Find the SIM cable, push right to open the lid > push the clip up to open > insert the SIM card in the correct direction > close and push the clip down to lock > close the lid and push left to lock.




B: Find the SIM cable, push up to open the lid > push down and lift the clip to open > insert the SIM card in the correct direction > close and push the clip up to lock > close the lid and press to lock.

Functions

3. Check signal mark in the upper right corner of the display, if normal, then you are free to surf the internet. You can browse the web, download apps via Google Play, play online games, etc. The possibilities are endless with the Internet in your car.

SIM card is not included and accept Micro-SIM card (15mm * 12mm) ONLY.



SIM card is not included and accept Micro-SIM card(15mm*12mm) ONLY.

※ 4G frequency supports :

LTE-FDD: B5/B7/B5/B7/B8/B20/B28

LTE-TDD: B38/B40/B41

WCDMA: B1/B2/B5/B8

The 4G frequency bands used in different countries are different, a few frequency bands may not be supported.

※ Do not plug or unplug the SIM card while the machine is running as it may result in burning the SIM card or taking a long time to receive the 4G signal.

※ When inserting the SIM card, please pay attention to the direction of the card, the wrong direction will lead to no signal or burn the SIM card.

Functions


Multimedia

● Always Drive Safely

Video Playback while driving is prohibited by law. It may cause distractions that lead to an accident. The factory settings on this units do not allow for video play while driving. You can change these settings in:
Settings --> Car Setting --> Base Setting --> Brake

● Music Audio

You can play audio files from USB/SD. Insert a USB drive/SD card containing music files, and tap music icon to open music player.



Playback



DSP




Previous



Pause/Play



Next



Favorite



Content list




Lyrics

Functions

● Video


You can play video files from USB/SD. Insert a USB drive/SD card containing video files and tap video icon to open video player (The file format may affect the sound quality).




Tap the icon to change the screen ratio: Center/Best Fit/Fit Horizontal/Fit Vertical/Full Screen/16:9/4:3




Switch playback modes. Each time you tap this button, playback model will switch in the following sequence: Random, File Repeat, Repeat All.



Previous



Next



Play/Pause




Content list

Functions

DSP

Tap the Audio Setting icon to open DSP settings menu.


● EQ



There are six factory preset settings for the EQ that included: Flat, Pop, Standard, Rock, Classic, Jazz.

Functions


- **Curve**



32-Bands Equaliser with Frequency from 30Hz to 17K Hz.

Functions

● Sound Field



You can adjust the sound field in the car according to your request.