



Smart Vibrator Ball



ZOR-0106

Features

Product introduction

MEXITOP vibrator balls use the whole package liquid silicone integral molding technology, small shape, strong seismic force. Connect with mobile APP for remote interaction and expand

Specifications

Material: Liquid Silicone、ABS

Product size: about 220*40mm

Battery capacity: 400mAh

Charging time: 2 hours

Working time: 2 hour

Waterproof: Yes

Product picture

Recharging hole

Power button



Power ON/OFF

Press and hold the power button for 2 seconds, The motor vibrates once, the product is started. It is allowed to connect with the mobile App. after power on, press and hold the power button for 2 seconds, the motor stops shaking, the product shuts down, and the Bluetooth function is turned off.

Mode switching

Press the power button, the product will vibrate in the next mode, a total of 8 modes. 1-2-3-4-5-6-7-8-1, cyclic switching

- 1.Low frequency vibration
- 2.Medium frequency vibration
- 3.High frequency vibration
- 4.Low pulse vibration
- 5.Medium pulse vibration
- 6.High pulse vibration
- 7.Frequency conversion 1 (Short vibration interval)
- 8.Frequency conversion 2 (longer vibration interval)

Method of recharging

- 1.Plug the cable into USB port or any USB power adapter, plug another pin into the recharging hole.
- 2.When the LED blinks, means charging now.
- 3.A full charge takes about 2 hours. When fully charged, the LED will stop blinking and will be kept turned on.
- 4.The light blinks when the battery is low.



Cleaning & Maintaining

The lifespan of your vibrator ball will be greatly increased with proper maintenance and care.

Choice of the Lubricant

Please don't use it with silicone-based lubricants. For product safety, please use water-soluble lubricants.

Cleaning and Disinfection

1. Always remember to clean and disinfect your vibrator ball completely before and after your use each time.
2. It could be washed with boiled water but less than 10 seconds.
3. Clean with a mild neutral detergent.
4. No cleaning with cleaning solute contained with gasoline or acetone but could be wiped with ethyl alcohol.

Storage and Safety

Store vibrator ball under the air-cool place and avoid leaving in direct under the sunlight. Keep away from the scope of your children that could reach.

Download WETOY App

1. Download the mobile App client program by visiting:
<http://app.cst2002.com>
2. Download the app by scanning the QR code below from your phone. (Note: "WETOY" app is suitable for Android or IOS smart devices that support Bluetooth 4.0 technology)



MADE IN CHINA

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

製品説明

本製品は一体成形技術を応用しており、形が小さく、振動力が強いです。無線設備を内蔵しています。アプリによるリモート操作可能。体験の臨場感を一層高めます。

製品仕様：

材質：液体シリカゲル、ABS

製品サイズ：約220*40mm

バッテリー容量：150 mAh 400 mah

充電時間：2時間

使用時間：2時間

防水機能：あり

使用方法

①充電挿入口

②電源ボタン



電源ON / OFF

電源ボタン②を2秒間長押しすると、製品が1回振動して電源が入ります。スマートフォンと接続してすぐにプレイすることができます。電源ボタンを2秒間押し続けると、電源をOFFすることができます。

モード切り替え

電源ボタン②を押して、バイブレーションも変更できます。8つのモード切り替え可能です。1-2-3-4-5-6-7-8-1サイクル切り替え。

- 1.低周波振動
- 2.中周波振動
- 3.高周波振動
- 4.インパルス振動低い
- 5.インパルス振動中
- 6.インパルス振動が高い
- 7.周波数変換1(短い振動間隔)
- 8.周波数変換2(長い振動間隔)

充電方法

- 1.製品の充電ポートに付属の充電用USBケーブルを差し込み
- 2.充電ランプが点滅し、充電中であることを示します。
- 3.100%までの充電に約2時間。充電が完了するとLEDランプが常に点灯します。
- 4.バッテリー残量が少なくなると、インジケータライトが点滅します。



クリーニングとメンテナンス

正しくお手入れを行うことで、効果的に製品の寿命を延ばすことができます。

潤滑剤の選択

シリコーン系潤滑剤との併用はご遠慮ください。製品の安全のため、水溶性潤滑剤を使用してください。

洗浄・消毒

- 1.本品はお湯で洗い流すことができますが、10秒を超えてはいけません。
- 2.毎回使用前後は洗浄消毒を行います。
- 3.中性洗剤を使って洗浄します。
- 4.専用の消毒液を使って消毒してください。
- 5.ガソリンやアセトンを含む洗浄剤を使用しない、アルコールを拭き取ります。

保存と収納

直射日光や高温を避け、風通しの良い場所に保存してください。
子供の手の届かないところに保管して下さい。

ダウンロード

ウェブサイト<http://app.cst2002.com>からモバイル用のセットアッププログラムをダウンロードします。

以下のQRコードをスキャンして、アプリをダウンロードできます
(Bluetooth 4.0 以降を搭載している Android またはIOSシステムのスマートフォン対応)



MADE IN CHINA