

GAMING HEADSET



User Manual

Customize Your Style, Decorate the Side Covers

CONTENTS

QUICK START GUIDE	1
PRODUCT LAYOUT	3
SPECIFICATION	4
PRODUCT STORAGE & BATTERY SAFETY	4
FCC CAUTION	5

QUICK START GUIDE

1. Power On/Off



Long-press the Power Button for 3 seconds.

2. Button Functions



Microphone Switch

Power Button

Volume Button

Microphone Button	● Click: Mic on/off ● Double click: Switch sound effect mode ● Triple click: Switch connection mode ● Hold 3s: Clear BT pairing
Power Button	● Hold 3s: Power on/off ● Click: Play/Pause/Answer/Hang up ● Hold 2s: Reject call ● Double click: Previous track ● Triple click: Next track
Volume Wheel	● Scroll up: Volume up ● Scroll down: Volume down

3. Connect Your Device


Wired Mode	● Turn off the headset. ● Plug in the cable. ● Wired mode starts automatically.  3.5mm to Type-C cable
2.4G Mode	● Turn on the headset. ● Plug in the USB dongle. (Name: SS202) ● Pairing starts automatically. LED: Blue on receiver / White on headset 
BT Mode	● Turn on the headset. ● Triple-press the Microphone Button. ● Search for "SS202" in your device's Bluetooth settings and tap to pair. 

4. Charging

Connect the USB Type-C cable, and the LED turns red during charging. The LED turns off when fully charged.

Note: The headset can still be used while charging in 2.4G/BT mode.

PRODUCT LAYOUT



① Headband

② Microphone Switch

③ Power Button

④ Volume Button

⑤ Headband Pad

⑥ Ear Cup

⑦ Ear Pad

⑧ Microphone

SPECIFICATION

Rated Input Power	30 mW
Maximum Input Power	100 mW
Speaker Diameter	50 mm
Speaker Impedance	32±10%Ω
Headphone Sensitivity	100±3 dB
Frequency Response	20 Hz-20 KHz
Microphone Sensitivity	-40±3 dB
Microphone Frequency Response	100~10 KHz
Battery Capacity	1000 mAh
Headphone Lighting Effect	RGB
Product Dimensions	187*92*193 mm

PRODUCT STORAGE & BATTERY SAFETY

Storage

- Store in a clean, dry place (–5°C to 35°C).
- For long-term storage, charge the headset every 3 months to protect battery life.

Battery Safety

- Do not expose to fire, extreme heat, or liquids.
- Never disassemble, crush, or modify the battery.

Custom Cover Care

- The decorative cover features a printed design.
- Clean only with a dry or slightly damp soft cloth.
- Do not use alcohol, solvents, or abrasive cleaners—they may damage the print.

FCC CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

