


Step 1 Scan the QR code to download the app




Step 2 Scan the QR code on the lamp and add the lamp



Step 3 Set the WIFI of the lamp for distribution network

- 1. Connect your phone to the WIFI at home
- 2. Open the distribution network interface on the app



Step 4 Enter the WIFI password at home

SSID	a
BSSID	82:ec:71:e7:35:4b
WIFI PW	Enter your home WIFI password

Setup

Step 5 Press the power button of the lamp and wait for the light to flash red



Step 6 Press the Setup button on the App interface to enter the intelligent distribution network process


SSID	a
BSSID	82:ec:71:e7:35:4b
WIFI PW	12345678

Setup

This process requires patience. Once the network is successfully connected, the lights will automatically connect to WIFI and flash white three times.

If the network configuration is unsuccessful multiple times, please modify the WIFI router at home to 2.4G network mode

Step 6 Operating instructions for the lamp




Press to turn on the power, press again to turn off the power



Charging interface. Charging requires turning on the power source of the lamp



Insert the lamp post into the wine bottle



Touch for 3 seconds or more to turn on or off the lights. Note that it is only a light switch, not a power on or off switch

Touch once to change the color. Your friend's light also changes color synchronously

Step 7 Particular attention

Every time the lamp is turned on, it automatically connects to the WIFI network and flashes white three times upon successful connection. The networking time ranges from 10 to 90 seconds, depending on the frequency band of the router.

If you encounter multiple unsuccessful connections for a long time, please restart the WIFI router.

If your WIFI router at home is in the 5G frequency band, the light networking will be slow. Please set it to 2.4G frequency band or be compatible with 2.4G frequency band.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.