


封面


JL

NC8i Wireless Earbuds



User Manual

Product Diagram



1



Choose the ear cap that suits you.


2




3



4



Functional Operation Instructions



ON

1.Earbuds auto-power on when removed from case
2.Or hold MFB for 3s (when outside case & powered off)

OFF

1.Auto-off when placed in case (with power)
2.Or hold MFB for 6s (when unconnected)
3.Auto-shutdown after 5min inactivity

1x Accept L / R Earbud

2s Hang up L / R Earbud

2s Reject L / R Earbud

2x Play / Pause L / R Earbud

3x Previous track L Earbud

3x Next track R Earbud

1x Volume- L Earbud

1x Volume+ R Earbud

4x Voice assistant L / R Earbud

2s ANC Switch L / R Earbud

Warm Notice:

Single earbud mode doesn't support previous track/volume -.

ANC Active Noise Reduction

TWS State

Boot default settings. Long press 2s MFB button to switch between the following modes.

Transparency Mode

ANC On

First time using



1.Tear off the insulating film.

2. Put the two earbuds back in the charging case to charge (the red light will on after activating the earphones).

3. Take out the two earbuds, they will automatically power on;

Tips: If the earbuds don't turn on or in silent state, please put the earbuds back in the charging case again and make sure to use them after charging (red/white lights flashing alternately)

4. After pairing, one light will go out, and the other one will flash red and white alternately.

5. Turn on the Bluetooth function on your phone and search for ' NC8i 'and connect it.

Warm Notice:

If the earbuds are not paired or one has no sound: Turn off your phone's Bluetooth. With both earbuds on and unconnected, double-tap either earbud to enter TWS pairing mode. Once paired, the primary earbud will flash red/white, and the secondary earbud's light will turn off.

Reconnection:

For faster reconnection, turn on your phone's Bluetooth before taking the earbuds out of the case.

Switching to another device:

Turn off Bluetooth on the currently connected device or delete "NC8i" from its paired list. The new device can then search and connect.

Restore Factory Setting



1. Clear Pairing Record:

Turn off phone Bluetooth. With earbuds on but unconnected, quickly tap the MFB 5 times (earbud will turn off after red light flashes).

2. Reset Earbuds

After reset, delete ' NC8i ', from your phone's Bluetoothlist and reconnect.

Charging

△ Low Battery Alert

A warning tone will play when battery is low until the earbuds power off.

△ Case Outof Power

If the case is dead, earbuds may not turn off and stay connected. Charge the case promptly.

△ Charging Note

Use a certified DC5V/1A charger to charge the case.

Earbuds indicator

Power On: White light flashes for 1S

Power Off: Red light flashes for 1S then turns off

Connected & Standby: No light

Music/Call Mode: No light

TWS Pairing Successful: Main earbud flashes white/red, secondary off.

Phone Pairing Mode: Main earbud flashes white/red, secondary off

Low Battery: Red light flashing

Charging: Solid red light

Fully Charged: Red light turns off

Product Specifications

●Model Number: NC8i

●Bluetooth Version:V6.0

●Compatible Mode: A2DP,AVRCP,HFP,HSP

●Transmission Distance:10Meters (No Barriers)

●Frequency Range:2.402GHz~2.480GHz

●Hi-Fi Equipment:Φ10mm*2 Impedance:32Ω

Standby Time: About 60hrs

●Play Time: About 7hrs

●Call Time: About 6hrs

●Battery Capacity: Earbud 50mAh , Charging Case 300mAh

●Charging Time: About 1.2 hour

●Weight (per Earbud):4.1g

Attention

If there's abnormal sound, clean with a cotton swab.

If there's a charging issue, clean the charging column.

NO waterproof

NO waterproof

NO waterproof

Ensure the product is completely dry to avoid water damage to the device.



Precautions

1.Charge in a safe environment. Disconnect the charging case from the cable once fully charged to avoid potential damage from prolonged charging.

2.Adjust volume to a moderate level during playback to prevent long-term hearing damage.

3.Avoid using the earbuds near interference sources to maintain optimal signal quality.

4.Avoid exposing the earbuds to corrosive environments to prevent functional damage.

(Friendly Reminder):

For your hearing heath, please keep the volume at a comfortable level during use.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.