

Mini smartphone instruction manual Do not disassemble the phone and accessories. Only authorized organizations can repair the phone. Install SIM or USIM card and battery When you order a mobile phone service, you will receive a Subscriber Identity Module (SIM) card with your order details, such as a Personal Identification Number (PIN) and optional services. To use the 3G (WCDMA) service, you can purchase a Universal Subscriber Identity Module (USIM) card. Install the SIM card or USIM card as follows. 1. On the right side of the phone, find the card slot of the SIM card. 2. There is a corresponding SIM card and memory card card insertion method on the card slot, please insert the card according to the pattern shown. If you do not have a SIM or USIM card inserted, you can only use your phone's non-network services and some of the menus. Do not insert the memory card into the SIM card slot. Charge the battery ✧ You must charge the battery before using it for the first time. You can use the provided travel charger or connect your phone to your computer via a computer cable to charge your phone. ✧ When the battery is low, the phone will sound a warning tone and display a low battery message. If the battery is too low, the phone will automatically shut down. You need to charge the battery before you can continue using your phone. ➢ Charge with a travel charger ✧ Plug the small end plug of the travel charger into the multi-function jack. Improper connection of the travel charger may result in serious damage to the mobile phone and will not be warranted for any damage caused by mishandling. 4	Mini smartphone instruction manual 1. Plug the big end plug of the travel charger into the power outlet. ✧ You can use your phone while charging, but this will extend the battery charging time. ✧ The phone will heat up when charging, this phenomenon is normal and will not affect the life or performance of the phone. 2. When the battery is fully charged, disconnect the travel charger from the phone and unplug it from the power outlet. Charge with computer data cable Make sure your computer is turned on before charging. 1. Plug one end of the computer data cable (micro USB) into the multi-function jack. 2. Connect the other end of the computer data cable to the computer's USB port. Depending on the type of computer data cable used, it may take a while to start charging. 3. When the battery is fully charged, disconnect the computer data cable from the phone and unplug it from the computer. ➢ Format SD card storage In the main menu, select Settings → Storage → Store Information → Format SD Storage. Before formatting the SD card storage, remember to back up all the important data stored on your phone. The manufacturer warranty service does not include data loss due to user actions. Power on and off To boot, press and hold [Power On/Off] the phone will turn on. In areas where wireless devices are prohibited (such as airplanes and hospitals), please follow all posted warnings and instructions from official staff. To use only your phone's non-network service, switch to 5
Mini smartphone instruction manual Document management Learn to quickly and fully open all your pictures, videos, music, documents and other kinds of files stored in your phone's storage. note 1. In addition to MP3, MP4 and picture files, please do not move or delete the system files. 2. It is recommended to install the APK installation package that comes with the phone storage. If you install the APK file package yourself, the phone will crash and restart, and you will not be responsible for it. Calendar You can view the date, view the lunar calendar, and set calendar events for easy use. e-mail Send or receive emails from your phone by configuring your personal or corporate email account. Video Can view, delete video files and sort videos. Contact All contacts Learn how to create and manage a list of personal or corporate contacts stored on your phone's memory or SIM card or USIM card. Save contact's name, mobile number, home phone number, email address, and more. Group Set up a phone contact group. Calculator Learn how to perform mathematical calculations directly on your phone, like a normal handheld or desktop calculator, switching to a scientific calculator when you are in landscape orientation. 13	Mini smartphone instruction manual Setting WLAN Set WLAN status, network notification, add network, etc Bluetooth Set Bluetooth status, search for Bluetooth devices, and modify Bluetooth names, etc. SIM card SIM card management. This function can choose to close or open the SIM card, select whether the data connection and international roaming are open. More Airplane mode; All language services can be disabled. Default SMS app; Set default SMS app Network and sharing and portable hotspots; WLAN hotspots, USB sharing networks, Bluetooth shared networks, network sharing and portable hotspot settings VPN; You can add a VPN profile. Mobile network; set up data connections, 4G services, preferences, etc. display Set functions related to mobile phone display, such as screen standby time, auto-rotate screen, interactive screen saver, screen lock notification, brightness adjustment, wireless display, etc. Sound and notification Set the phone mode. Default mode: standard, mute, conference, outdoor mode. Set phone ringtones, message ringtones, volume, etc., as well as set custom profiles. Storage View phone and SD card storage battery View phone battery usage Application 14