



2.4GHZ ASSEMBLED BATTLE CAR
USER INSTRUCTION


PACKING LIST



BATTERY INSTALLATION FOR REMOTE CONTROL CAR AND REMOTE




CHARGE THE CAR BATTERY




NOTICE: Assembled battle car movements slow and remote control is not sensitive, indicates insufficient electricity, and needs to be replaced.


HOW TO FILL IN WATER TO THE BATTLE CAR




METHOD FOR ADDING A WATER BOMB




METHOD FOR SOAKING WATER BOMBS




MAIN BODY INSTALLATION AND DISASSEMBLY




MOUNTING OF BULLETS AND EMITTERS




DISASSEMBLE EMITTER




START BATTLE CAR AND PAIR WITH THE CONTROLLER




FUNCTION DESCRIPTION




FUNCTION DESCRIPTION



FUNCTION DESCRIPTION



BATTLE CAR PLAY



FREQUENTLY ASKED QUESTIONS AND SOLUTION

PROBLEM	REASON	SOLUTION
Cannot launch bullets	The bullet jammed. Emitter not installed correctly.	Refer to how to install and launch on page 2 and 3. Remove and then re-install the emitter in place again.
The battle car can't match the remote control	The battery is low need to pair again	Replace the battery Refer to page 2 how to pair

FREQUENTLY ASKED QUESTIONS AND SOLUTION

PROBLEM	REASON	SOLUTION
No bullets fall after being hit	No correct installation	Refer to page 2 to learn how to properly install
The battle car does not work properly	No entering battle mode	Put the switch to "ON"
The LED of the battle car is alternately flashing	Battery is insufficient	Replace the battery

WARNING

The product includes smaller parts, not suitable for children under 3 years old. Suggested age: 14 years old or more. This product uses 2.4G digital transmission frequency. Do not shoot eye and face; Do not use it near the crowd; Do not use it close to your ears; Use only product original ejects; Do not emit the face to the ejector in the face at any time; Laser radiation, do not touch the light beam; Please retain this specification for future reference.

Notice

- Make sure the battery lid is closed.
- Use the correct model and the type of battery.
- Install the battery in accordance with the positive and negative electrode identification.
- Change the battery to the battery when replacing the battery.
- Remove the battery exhausted battery from the device.
- Take the battery out for a long time.
- Keep the battery away from young children to prevent young children from swallowing.
- If you appear or speculate on the child's swallowing battery, send a medical institution immediately.
- The battery should be installed in an adult.
- Do not close the battery near the fire source.

CAUTION

- Remote control use 7.4V rechargeable lithium battery, the remote control uses 2 capsules 1.5 "AA" non-rechargeable batteries.
- Non-rechargeable batteries are not charged;
- The charging battery can only be charged under adult monitoring;
- The charging battery should be taken from the toy before charging;
- How to remove and put the battery: release the screw with a screwdriver, unveil the battery cover, put it in and remove the battery according to the correct polarity;
- Take out and put the battery shall be carried out in the logo on the toy battery chamber;
- You can only use the same or the same battery as the recommended battery;
- Do not mix new and different types of batteries;
- The battery should be placed in the correct polarity;
- Exhausted batteries should be removed from the toys;
- The power terminal should not be shorted.
- Cannot connect more than the recommended number of power supplies;
- Toys cannot be used for children under 3 years old, toys can only use recommended USB charging lines, USB charging lines are not toys;
- Toy cleaning should be disconnected from the USB charging line;
- This product can only be charged using the USB charging line, and cannot use non-factory USB charging lines;
- USB charging cable is completed by parents;
- Regularly check the damaged wire, plug, housing and other components. If the damage should be stopped, please contact the merchant to replace or purchase it immediately.

WARNING: CHOKING HAZARD-Small parts. Not for children under 3 years.

WARNING: When the remote can not control the car, switch off the power of remote first, then switch off the power of remote control car. Turn on the power again to have pair by pulling controller on the remote.

CAUTION: 1. Keep away all small parts safely, avoid children swallow. 2. When the electric wave disturbs playing, please find somewhere else. 3. Stop playing when the battery is low. 4. Dispose all the package waste in the correct bin to avoid pollution. 5. Please keep the remote and the car in a cool and dry place. 6. Do not storage close to the fire, heat or wet place. 7. When the batteries soak with water, please dry it properly. Do not use the battery anymore when the shape of batteries has been changed.