



## 31 安装有刷车轮 Brush wheel installation

No.18101




## 32 安装无刷车轮 Brushless wheel installation

No.18101PRO




### 33 安装有刷车轮 Brush wheel installation

No.18102




### 34 安装无刷车轮 Brushless wheel installation

No.18102PRO




## 35 安装有刷车轮 Brush wheel installation

No.18108




## 36 安装无刷车轮 Brushless wheel installation

No.18108PRO




### 37 安装前车壳支柱 Install the front car shell strut

No.18101




### 38 安装前车壳支柱 Install the front car shell strut


No.18102



39 安装前车壳支柱 Install the front car shell strut




40 安装电池格栅 Install battery grid




41 安装电池格栅 Install battery grid

No.18102




42 安装电池格栅 Install battery grid

No.18108




43 安装电池 Battery pack installation

No.18101




44 安装电池 Battery pack installation

No.18102






45 安装电池 Battery pack installation



No.18108

46 连接电线 Connect wire



No.18101

## 47 连接电线 Connect wire

