

# Bone conduction earphone

## Instructions for user

### 1. Charge

Charge the headphones with the included micro-USB cable. The LED light will turn from red to blue when charging is complete.

### 2. Pair

Start with your headphones off. Enter pairing mode by pressing and holding volume+ until Audrey says “pairing” and the LED light flashes red and blue.

### 3. Connect

Open your device’s Bluetooth® menu and select. Audrey says “Connected” and the LED light will flash blue one time.

## Multifunction Button

| Function          | Action                              | Prompt/ “Audrey Says™” |
|-------------------|-------------------------------------|------------------------|
| Play/pause music  | Click once                          | One beep               |
| Skip to next song | Double-click while music is playing | One beep               |
| Answer/end call   | Click once                          | Two/One beep           |
| Reject a call     | Press and hold for 2 seconds        | Two beeps              |

## Volume Up/Power Button (+) ; Volume Down Button (-)

| Function      | Action                                              | Prompt/ “Audrey Says™” |
|---------------|-----------------------------------------------------|------------------------|
| Power on      | Press and hold volume+ for 3 seconds                | “power on              |
| Power off     | Press and hold volume+ for 3 seconds                | “Power off”            |
| Adjust volume | Click the volume up or down button to adjust volume | One beep               |

## LED Indicator

|                   |                      |
|-------------------|----------------------|
| Charging          | Solid red            |
| Charging complete | Solid blue           |
| Pairing mode      | Flashes red and blue |

## Specifications:

|                    |                |
|--------------------|----------------|
| Brand              | EKEN           |
| Part number        | E1             |
| Bluetooth® version | Bluetooth®v5.0 |

|                        |                    |
|------------------------|--------------------|
| Battery Capacity       | 200mAh             |
| Compatible profiles    | A2DP,AVRCP,HSP,HFP |
| Continuous play        | up to 6 Hours      |
| Charge time            | 2 Hours            |
| Maximum Charge Voltage | 5.25V              |
| Frequency response     | 20Hz~20KHz         |
| Microphone             | -40dB ± 3dB        |
| Wireless range         | 33 ft (10m)        |
| Weight                 | 0.95oz(25g)        |
| Standby time           | Up to 20 days      |
| Warranty               | 1 year             |
| Speaker Impedance      | 8ohm               |

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Multifunction Button  
多功能键



Microphone  
麦克风



LED Indicator  
LED 指示灯

Volume“-”  
音量“-”

Power and Volume“+”  
电源键和音量“+”

Charging Port  
Micro-USB  
USB充电口

