


X50 说明书
80g书写纸 单色双面印 风情折
成品尺寸: 70*87mm

Kinglucky®



X50 User Manual

Package Contents



Speaker




Charging Cable



User Manual

Product Diagram



Basic Operations



Power On: Press and hold the Power Button for 2 seconds.
Power Off: Press and hold the Power Button for 5 seconds.

Switch Mode



Press the Power Button twice to switch between Bluetooth and Sleep Mode.

Music Controls



Play / Pause: Press the Power Button once.



Volume Down: Press the Left Button once.



Volume Up: Press the Right Button once.



Previous Track: Press the Left Button twice.



Next Track: Press the Right Button twice.

Hands-free Calls



Answer / End Call: Press the Power Button once.
Reject Call: Press and hold the Power Button for 2 seconds.

Timer Settings



Set Timer: Press and hold the Right Button for 2 seconds.
●●● (The timer will cycle through 30, 60, and 90 minutes.)

Bluetooth Pairing



1. Power on the speaker.
2. Enter Bluetooth Mode.
3. Enable Bluetooth in your phone's settings.
4. Select "X50" from the device list to connect.

Lifetime Warranty & Customer Support



← SCAN ME TO ACTIVATE LIFETIME WARRANTY WITHIN 14 DAYS

Thank you for choosing Kinglucky! Explore our latest products, parts, and accessories at www.kingluckystore.com. For assistance, contact us at support@kingluckystore.com

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.