


English/英语 X9 Usage Manual

FCC ID: 2A5TA-X9

■ Charging indication

Headphone charging: Connect the magnetic charging cable, the red indicator light on the headphones will light up. After being fully charged, the red light will go out and the white light will come on.




■ Wireless Connection Guide

Method for connecting wireless headphones to mobile phone:

1. Please keep the distance between the Wireless headphones and the connected device within 1 meter.
2. Press and hold the power button for 3s to turn on the device and confirm that it enters the pairing mode.
3. Turn on the wireless search function of the mobile phone or other devices you want to connect. The name "X9" will be displayed on the phone.
4. Selecting the wireless name "X9" will automatically connect to the mobile phone.
5. The pairing time for the wireless headphones is 5 minutes. If it exceeds the time limit, it will automatically shut down. If you still need to connect to the mobile phone, please follow steps 1 to 4 again until the connection is successful.



■ Headphones Button Operation Guide



- Power on—Long press the power button for 3s
- Power off—Long press the power button for 5s
- Play/pause—Short press the power button
- Answer the phone—Short press the power button
- Hang up the phone—Short press the power button
- Reject the call—Short press the power button
- Previous song—Double click the - key
- Next song—Double click the + key
- Vol+—Short press the + key
- Vol—Short press the - key
- TF mode: Double click the power button to switch mode
- The song is downloaded to the TF card for storage, and then the TF is plugged into the headset to play the song.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.